

# **Network Camera Web 3.0**

## **Operation Manual**



ZHEJIANG DAHUA VISION TECHNOLOGY CO., LTD. V2.1.3



# Foreword

## General

This manual introduces the functions, configuration, general operation, and system maintenance of network camera.

## Safety Instructions

The following signal words might appear in the manual.

Signal Words	Meaning
	Indicates a medium or low potential hazard which, if not avoided, could result in slight or moderate injury.
	Indicates a potential risk which, if not avoided, may result in property damage, data loss, lower performance, or unpredictable result.
© <u>—</u> ™ TIPS	Provides methods to help you solve a problem or save you time.
	Provides additional information as the emphasis and supplement to the text.

## **Revision History**

Version	Revision Content	Release Date
V2.1.3	Updated the description of encode bar.	November 2021
V2.1.2	<ul> <li>Updated "4.2.4.1 Adjustment".</li> <li>Updated "4.5.1.1.1 Interface Layout".</li> <li>Updated "4.5.1.1.2 Picture".</li> <li>Updated "4.5.1.1.11 Image Correction".</li> <li>Updated "4.5.1.4 Splicing".</li> <li>Updated "4.5.2.1 Video".</li> <li>Updated "4.8.2 Date &amp; Time".</li> </ul>	September 2021
V2.1.1	<ul> <li>Updated "4.8.3.2 Adding User Group".</li> <li>Updated "5.18 Setting Relay-in".</li> </ul>	July 2021
V2.1.0	Updated "5.7 Setting Smart Plan"	July 2021
V2.0.9	Updated "4.5.2.1 Video".	May 2021
V2.0.8	<ul> <li>Updated "4.5.2.3.1 Configuring Privacy Masking".</li> <li>Updated "4.7.3.3 FTP".</li> <li>Updated "4.8.3.1 Adding a User" and "4.8.3.3 ONVIF User".</li> <li>Updated "5.4.2 Setting Video Tampering".</li> <li>Updated "5.11 Setting Face Detection".</li> <li>Updated "5.15 Setting Stereo Analysis".</li> <li>Updated "5.19.5 Setting Security Exception".</li> </ul>	December 2020



**Operation Manual** 

Version	Revision Content	Release Date
V2.0.7	<ul> <li>Modify "5.1.1.7 Warning Light Linkage".</li> <li>Add "4.6.12 5G".</li> <li>Modify "4.7.3.2 Local".</li> </ul>	July 2020
V2.0.6	<ul> <li>Added "4.5.2.3.11 Configuring GPS Position".</li> <li>Updated "5.2 Setting Smart Track".</li> </ul>	July 2020
V2.0.5	<ul> <li>Updated "4.5.1.1.8 Illuminator".</li> <li>Updated "4.7.3.2 Local".</li> <li>Added "5.19.6 Setting Disarming".</li> </ul>	June 2020
V2.0.4	<ul> <li>Updated "4.5.1.4 Splicing".</li> <li>Updated "5.14 Setting Vehicle Density".</li> <li>Updated "5.12 Setting People Counting".</li> </ul>	May 2020
V2.0.3	Added note in "4.7.3.2 Local".	May 2020
V2.0.2	<ul> <li>Modified the contents of "5.16 Setting ANPR".</li> <li>Added modeling in "5.11 Setting Face Detection".</li> </ul>	December 2019
V2.0.1	Added "5.5 Setting Smart Motion Detection".	August 2019
V2.0.0	<ul> <li>Consolidated the outline, and added baseline and safety contents, and some intelligent functions such as face recognition and ANPR.</li> <li>Deleted some old function such as stereo vision.</li> </ul>	July 2019
V1.0.4	<ul> <li>Updated the chapters of "5.12 Setting People Counting" and "5.13.1 Heat Map".</li> <li>Add VR mode of Fisheye device.</li> <li>Add video metadata function.</li> </ul>	March 2019
V1.0.3	Added Stereo Analysis function.	November 2018
V1.0.2	<ul> <li>Added chapters of "3 Device Initialization". and "Stereo vision."</li> <li>Updated the chapters of "4.8.3 Account", and "4.6.7 SNMP".</li> </ul>	October 2017
V1.0.1	First release.	September 2016

## **Privacy Protection Notice**

As the device user or data controller, you might collect the personal data of others such as their face, fingerprints, and license plate number. You need to be in compliance with your local privacy protection laws and regulations to protect the legitimate rights and interests of other people by implementing measures which include but are not limited: Providing clear and visible identification to inform people of the existence of the surveillance area and provide required contact information.

## About the Manual

- The manual is for reference only. Slight differences might be found between the manual and the product.
- We are not liable for losses incurred due to operating the product in ways that are not in compliance with the manual.



- The manual will be updated according to the latest laws and regulations of related jurisdictions. For detailed information, see the paper user's manual, use our CD-ROM, scan the QR code or visit our official website. The manual is for reference only. Slight differences might be found between the electronic version and the paper version.
- All designs and software are subject to change without prior written notice. Product updates might result in some differences appearing between the actual product and the manual. Please contact customer service for the latest program and supplementary documentation.
- There might be errors in the print or deviations in the description of the functions, operations and technical data. If there is any doubt or dispute, we reserve the right of final explanation.
- Upgrade the reader software or try other mainstream reader software if the manual (in PDF format) cannot be opened.
- All trademarks, registered trademarks and company names in the manual are properties of their respective owners.
- Please visit our website, contact the supplier or customer service if any problems occur while using the device.
- If there is any uncertainty or controversy, we reserve the right of final explanation.



# Important Safeguards and Warnings

## **Electrical Safety**

- All installation and operation shall conform to your local electrical safety codes.
- The power supply must conform to the requirements of ES1 in IEC 62368-1 standard and be no higher than PS2. Note that the power supply requirements are subject to the device label.
- Make sure that the power supply is correct before operating the device.
- A readily accessible disconnecting device shall be incorporated in the building installation wiring.
- Prevent the power cable from being trampled or pressed, especially the plug, power socket and the junction extruded from the device.

## Environment

- Do not aim the device at strong light to focus, such as lamp light and sun light; otherwise it might cause over brightness or light marks, which are not device malfunctions, and affect the longevity of Complementary Metal-Oxide Semiconductor (CMOS).
- Do not place the device in a damp, dusty extremely hot or cold environment, or the locations with strong electromagnetic radiation or unstable lighting.
- Keep the device away from any liquid to avoid damage to the internal components.
- Keep the indoor device away from rain or damp to avoid fire or lightning.
- Keep sound ventilation to avoid heat accumulation.
- Transport, use and store the device within the range of allowed humidity and temperature.
- Heavy stress, violent vibration or water splash are not allowed during transportation, storage and installation.
- Pack the device with standard factory packaging or the equivalent material when transporting the device.
- Install the device in the location where only the professional staff with relevant knowledge of safety guards and warnings can access. The accidental injury might happen to the non-professionals who enter the installation area when the device is operating normally.

## **Operation and Daily Maintenance**

- Do not touch the heat dissipation component of the device to avoid scald.
- Carefully follow the instructions in the manual when disassembling operation about the device; otherwise, it might cause water leakage or poor image quality due to unprofessional operations. Make sure that the gasket ring is flat and properly installed in the groove before installing the cover. Contact after-sales service for desiccant replacement if there is condensed fog on the lens after unpacking or when the desiccant turns green (Not all models are included with the desiccant).
- We recommend using the device together with lightning arrester to improve lightning protection effect.
- We recommend grounding the device to enhance reliability.
- Do not touch the image sensor (CMOS) directly. Dust and dirt could be removed with air blower, or you can wipe the lens gently with soft cloth that is moistened with alcohol.
- You can clean the device body with soft dry cloth, and for stubborn stains, use the cloth with



mild detergent. To avoid possible damage on device body coating which could cause performance decrease, do not use volatile solvent such as alcohol, benzene, diluent to clean the device body, nor can strong, abrasive detergent be used.

• Dome cover is an optical component. Do not touch or wipe the cover with your hands directly during installation or operation. For removing dust, grease or fingerprints, wipe gently with moistened oil-free cotton with diethyl or moistened soft cloth. You can also remove dust with an air blower.

### 

- Strengthen the protection of network, device data and personal information by adopting
  measures which include but not limited to using strong password, changing password regularly,
  upgrading firmware to the latest version, and isolating computer network. For some devices with
  old firmware versions, the ONVIF password will not be changed automatically along with
  changing the system password, and you need to upgrade the firmware or manually change the
  ONVIF password.
- Use standard components or accessories provided by manufacturer and make sure that the device is installed and maintained by professional engineers.
- Do not expose the surface of the image sensor to laser beam radiation in an environment where a laser beam device is used.
- Do not provide two or more power supply sources for the device unless otherwise specified. A failure to follow this instruction might cause damage to the device.



# **Table of Contents**

Foreword	
Important Safeguards and Warnings	IV
1 Overview	1
1.1 Introduction	1
1.2 Network Connection	1
1.3 Function	1
1.3.1 Basic Function	1
1.3.2 Intelligent Function	2
2 Configuration Flow	5
3 Device Initialization	6
4 Basic Configuration	9
4.1 Login	9
4.2 Live	10
4.2.1 Live Interface	10
4.2.2 Encode bar	11
4.2.3 Live View Function Bar	11
4.2.4 Window Adjustment Bar	14
4.2.4.1 Adjustment	14
4.2.4.2 Zoom and Focus	17
4.2.4.3 Fisheye	18
4.3 PTZ Operation	22
4.3.1 Configuring External PTZ Protocol	22
4.3.2 Configuring PTZ Function	22
4.3.2.1 Preset	22
4.3.2.2 Tour	23
4.3.2.3 Scan	24
4.3.2.4 Pattern	25
4.3.2.5 Pan	26
4.3.2.6 PTZ Speed	27
4.3.2.7 Idle Motion	27
4.3.2.8 PowerUp	28
4.3.2.9 PTZ Limit	29
4.3.2.10 Time Task	29
4.3.2.11 PTZ Restart	
4.3.2.12 Default	31



4.3.3 Calling PTZ	
4.3.3.1 PTZ Control	
4.3.3.2 PTZ Function	
4.4 Playback	
4.4.1 Playback Interface	
4.4.2 Playing back Video or Picture	
4.4.3 Clipping Video	
4.4.4 Downloading Video or Picture	40
4.4.4.1 Downloading A Single File	40
4.4.4.2 Downloading Files in Batches	40
4.5 Camera	41
4.5.1 Conditions	41
4.5.1.1 Conditions	41
4.5.1.1.1 Interface Layout	41
4.5.1.1.2 Picture	43
4.5.1.1.3 Exposure	
4.5.1.1.4 Backlight	46
4.5.1.1.5 WB	47
4.5.1.1.6 Day & Night	
4.5.1.1.7 Zoom and Focus	
4.5.1.1.8 Illuminator	50
4.5.1.1.9 Defog	51
4.5.1.1.10 Fisheye	52
4.5.1.1.11 Image Correction	53
4.5.1.1.12 Splicing Mode	54
4.5.1.2 Profile Management	54
4.5.1.3 Zoom and Focus	55
4.5.1.4 Splicing	55
4.5.2 Setting Video Parameters	56
4.5.2.1 Video	56
4.5.2.2 Snapshot	59
4.5.2.3 Overlay	60
4.5.2.3.1 Configuring Privacy Masking	60
4.5.2.3.2 Configuring Channel Title	63
4.5.2.3.3 Configuring Time Title	
4.5.2.3.4 Configure Text Overlay	
4.5.2.3.5 Configure Font Attribute	65



4.5.2.3.6 Configure Picture Overlay	65
4.5.2.3.7 Configure Custom Overlay	66
4.5.2.3.8 Configuring OSD Info	67
4.5.2.3.9 Configuring Counting	68
4.5.2.3.10 Configuring Structured Statistics	68
4.5.2.3.11 Configuring GPS Position	69
4.5.2.3.12 Configuring Ranging	69
4.5.2.3.13 Configuring ANPR	70
4.5.2.3.14 Configuring Face Statistics	71
4.5.2.4 ROI	71
4.5.2.5 Path	72
4.5.3 Audio	73
4.5.3.1 Configuring Audio Parameter	73
4.5.3.2 Configuring Alarm Audio	74
4.6 Network	75
4.6.1 TCP/IP	75
4.6.2 Port	
4.6.3 PPPoE	79
4.6.4 DDNS	80
4.6.5 SMTP (Email)	81
4.6.6 UPnP	84
4.6.7 SNMP	85
4.6.8 Bonjour	
4.6.9 Multicast	
4.6.10 802.1x	
4.6.11 QoS	
4.6.12 5G	
4.6.12.1 Dialing Setting	
4.6.12.2 Mobile Setting	
4.6.13 Access Platform	92
4.6.13.1 P2P	
4.6.13.2 ONVIF	93
4.6.13.3 RTMP	94
4.7 Storage	95
4.7.1 Setting Storage Plan	95
4.7.2 Setting Schedule	95
4.7.3 Setting Destination	



4.7.3.1 Path	96
4.7.3.2 Local	
4.7.3.3 FTP	
4.7.3.4 NAS	
4.8 System	
4.8.1 General	
4.8.2 Date & Time	
4.8.3 Account	
4.8.3.1 Adding a User	
4.8.3.2 Adding User Group	
4.8.3.3 ONVIF User	
4.8.4 Safety	
4.8.4.1 System Service	
4.8.4.2 HTTPS	
4.8.4.3 Firewall	
4.8.5 Peripheral	
4.8.5.1 Serial Port Settings	
4.8.5.2 External Light	
4.8.5.3 Wiper	
5 Event	
5.1 Setting Alarm Linkage	
5.1.1 Alarm Linkage	
5.1.1.1 Setting Period	
5.1.1.2 Record Linkage	
5.1.1.2.1 Setting Record Plan	
5.1.1.2.2 Setting Record Control	
5.1.1.2.3 Setting Record Linkage	
5.1.1.3 Snapshot Linkage	
5.1.1.3.1 Setting Snapshot Plan	
5.1.1.3.2 Setting Snapshot Linkage	
5.1.1.4 Relay-out Linkage	
5.1.1.5 Email Linkage	
5.1.1.6 PTZ Linkage	
5.1.1.7 Warning Light Linkage	
5.1.1.8 Audio Linkage	
5.1.2 Subscribing Alarm	
5.1.2.1 About Alarm Types	



5.1.2.2 Subscribing Alarm Information	
5.2 Setting Smart Track	
5.2.1 Setting Calibration Parameters for Smart Track	132
5.2.2 Enabling Alarm Track	134
5.3 Setting Panoramic Calibration	
5.4 Setting Video Detection	137
5.4.1 Setting Motion Detection	
5.4.2 Setting Video Tampering	
5.4.3 Setting Scene Changing	140
5.5 Setting Smart Motion Detection	141
5.6 Setting Audio Detection	142
5.7 Setting Smart Plan	144
5.7.1 Basic Smart Plan	144
5.7.2 Schedule	145
5.8 Setting IVS	147
5.8.1 Global Configuration	147
5.8.2 Rule Configuration	
5.9 Setting Crowd Map	
5.9.1 Global Configuration	
5.9.2 Rule Configuration	
5.10 Setting Face Recognition	
5.10.1 Setting Face Detection	
5.10.2 Setting Face Database	
5.10.2.1 Creating Face Database	
5.10.2.2 Adding Face Picture	
5.10.2.2.1 Single Adding	
5.10.2.2.2 Batch Importing	
5.10.2.3 Managing Face Picture	
5.10.2.3.1 Modifying Face Information	
5.10.2.3.2 Deleting Face Picture	
5.10.2.4 Face Modeling	
5.10.3 Setting Face Recognition Alarm Linkage	
5.10.4 Viewing Face Recognition Result	
5.10.4.1 Viewing Result in the Live Interface	
5.10.4.2 Viewing Result by Search Function	
5.11 Setting Face Detection	
5.12 Setting People Counting	



5.12.1 People Counting	
5.12.2 Calibration Configuration	
5.12.3 Queuing	
5.12.4 Viewing People Counting Diagram	
5.12.5 Viewing People Counting Report	
5.13 Setting Heat Map	
5.13.1 Heat Map	
5.13.2 Viewing Heat Map Report	
5.14 Setting Vehicle Density	
5.15 Setting Stereo Analysis	
5.15.1 Setting Rules for Stereo Analysis	
5.15.2 Calibration Configuration	
5.15.3 Zoom Calibration	
5.15.4 Viewing Report	
5.16 Setting ANPR	
5.16.1 Scene Configuration	
5.16.2 Setting Picture Overlay	
5.16.3 Viewing ANPR Report	
5.17 Setting Video Metadata	
5.17.1 Scene Configuration	
5.17.2 Setting Picture Information	
5.17.3 Viewing Video Metadata Report	
5.18 Setting Relay-in	
5.18.1 Relay-in (1)	
5.18.2 Relay-in (2)	
5.19 Setting Abnormality	
5.19.1 Setting SD Card	
5.19.2 Setting Network	
5.19.3 Setting Illegal Access	
5.19.4 Setting Voltage Detection	
5.19.5 Setting Security Exception	
5.19.6 Setting Disarming	
6 Maintenance	
6.1 Requirements	
6.2 Auto Maintain	
6.3 Resetting Password	
6.4 Backup and Default	



6.4.1 Import/Export	
6.4.2 Default	213
6.5 Upgrade	214
6.6 Information	
6.6.1 Version	
6.6.2 Log	
6.6.3 Remote Log	
6.6.4 Online User	
Appendix 1 Cybersecurity Recommendations	



## 1 Overview

## **1.1 Introduction**


IP camera (Internet Protocol camera), is a type of digital video camera that receives control data and sends image data through internet. They are commonly used for surveillance, requiring no local recording device, but only a local area network.

IP camera is divided into single-channel camera and multi-channel camera according to the channel quantity. For multi-channel camera, you can set the parameters for each channel.

## **1.2 Network Connection**

In the general IPC network topology, IPC is connected to PC through network switch or router.

Figure 1-1 General IPC network



Get IP address by searching on ConfigTool, and then you can start accessing IPC through network.

## **1.3 Function**

Functions might vary with different devices.

## 1.3.1 Basic Function

**Real-time Monitoring** 

- Live view.
- When live viewing the image, you can enable audio, voice talk and connect monitoring center for quick processing on the abnormality.
- Adjust the image to the proper position by PTZ.
- Snapshot and triple snapshot abnormality of the monitoring image for subsequent view and processing.

1



- Record abnormality of monitoring image for subsequent view and processing.
- Configure coding parameters, and adjust live view image.

### Record

- Auto record as schedule.
- Play back recorded video and picture as needed.
- Download recorded video and picture.
- Alarm linked recording.

### Account

- Add, modify and delete user group, and manage user authorities according to user group.
- Add, modify and delete user, and configure user authorities.
- Modify user password.

## **1.3.2 Intelligent Function**

### Alarm

- Set alarm prompt mode and tone according to alarm type.
- View alarm prompt message.

### Smart Track

- Set calibration and parameters for smart track and enable alarm track.
- Switch between smart track and speed dome auto track.

### Video Detection

- Motion detection, video tampering detection and scene changing detection.
- When an alarm is triggered, the system performs linkages such as recording, alarm output, sending email, PTZ operation, and snapshot.

## **Smart Motion Detection**

- Avoid the alarms triggered by the environment changes.
- When an alarm is triggered, the system performs linkages such as recording, alarm output, sending email, PTZ operation, and snapshot.

## Audio Detection

- Audio input abnormal detection and intensity change detection.
- When an alarm is triggered, the system performs linkages such as recording, alarm output, sending email, PTZ operation, and snapshot.

IVS

- Tripwire, intrusion, abandoned object, moving object, fast moving, parking detection, people gathering, and loitering detection.
- When an alarm is triggered, the system performs linkages such as recording, alarm output, sending email, and snapshot.



**Operation Manual** 

• When an alarm is triggered, the system performs linkages such as recording, alarm output, sending email, PTZ operation, and snapshot.

## Face Detection

- Detect face and display the related attributes on the live interface.
- When an alarm is triggered, the system performs linkages such as recording, alarm output, sending email, PTZ operation, and snapshot.

## **Face Recognition**

- After detecting face, make comparison between the detected face with the face in face database, and activates alarm output.
- Query the recognition result.

## **People Counting**

- Count the people flow in/out the detection area, and generate report.
- When an alarm is triggered, the system performs linkages such as recording, alarm output, sending email, PTZ operation, and snapshot.

## Heat Map

- Count cumulative density of moving objects.
- View report of heat map.

## Vehicle Density

- Supports traffic congestion detection and parking upper limit detection.
- View the statistic data on the live interface.
- When an alarm is triggered, the system performs linkages such as recording, alarm output, sending email, and snapshot.

## **Stereo Analysis**

- Include Activation Analysis, Back Detection, Fall Detection, Walking Detection, Blackboard Writing Detection, Violence Detection, People No. Error, Stand Detection, Running Detection, People Approaching Detection, and Strand Detection.
- When an alarm is triggered, the system performs linkages such as recording, alarm output, sending email, PTZ operation, and snapshot.

### ANPR

- Recognize plate number in detection area, and display the related information on live interface.
- When an alarm is triggered, the system links alarm output and snapshot.

## Video Metadata

- Snap people, non-motor vehicle and vehicle, and display the related information on the live interface.
- When an alarm is triggered, the system links alarm output.



## Alarm Setting

- The alarm is triggered when an external alarm input device inputs alarm.
- When an alarm is triggered, the system performs linkages such as recording, alarm output, sending email, PTZ operation, and snapshot.

## Abnormality

- SD card error, network disconnection, illegal access, voltage detection and security exception.
- When SD card error or illegal access is triggered, the system links alarm output and sending email.
- When network disconnection alarm is triggered, the system links recording and alarm output.
- When the input voltage is more or less than the rated voltage, the alarm is triggered and the system links sending email.



# **2 Configuration Flow**

For the device configuration flow, see Figure 2-1. For details, see Table 2-1. Configure the device according to the actual situation.




Table 2-1 Description of flow

Configuration		Description	Reference
Login		Open IE browser and enter IP address to log in to the web interface, The camera IP address is 192.168.1.108 by default.	"4.1 Login"
Initialization		Initialize the camera when you use it for the first time.	"3 Device Initialization"
Basic parameters	IP address	Modify IP address according to network planning for the first use or during network adjustment.	"4.6.1 TCP/IP"
	Date & time	Set date and time to ensure the recording time is correct.	"4.8.2 Date & Time"
	lmage parameters	Adjust image parameters according to the actual situation to ensure the image quality.	"4.5.1 Conditions"
Intelligent Event	Detection rules	Configure the necessary detection rules, such as video detection and IVS.	"5 Event"
	Subscribe alarm	Subscribe alarm event. When the subscribed alarm is triggered, the system will record the alarm on the alarm tab.	"5.1.2 Subscribing Alarm"



# **3 Device Initialization**

Device initialization is required for the first use. This manual is based on the operation on the web interface. You can also initialize device through ConfigTool, NVR, or platform devices.

	L	
	L	
-	-	-
	_	

- To ensure the device safety, keep the password properly after initialization and change the password regularly.
- When initializing device, keep the PC IP and device IP in the same network.
- <u>Step 1</u> Open IE browser, enter the IP address of the device in the address bar, and then press Enter key.

The IP is 192.168.1.108 by default.

Figure 3-1 Device initialization

Device Initialization	
Usemame	aamo
Passwird	The minimum pass phrase length is 8 characters
	West NUMB 28070
Confirm Password	
	Use a passworth that has 8 to 32 characters, it can be a completation of letter(s), number(s) and sympology with at least two rands of them (please do hollose special sympoles like (1): 6.)
7 Email Address	To reset password, please input property or update in time
	Saw

<u>Step 2</u> Set the password for admin account.

Table 3-1 Description of password configuration

Parameter	Description	
Username	The default username is admin.	
Password	The password must consist of 8 to 32 non-blank characters and	
Confirm password	contain at least two types of characters among upper case, lower case, number, and special character (excluding ' " ; : &). Set a high security level password according to the password security notice.	
	Enter an email address for password reset, and it is selected by default.	
email	When you need to reset the password of the admin account, a security code for password resetting will be sent to the reserved email address.	

Step 3 Click Save.



#### Figure 3-2 End-user license agreement

runding rauna	chrologies Co. 1.12. Software End User License Agreement	100
1. NOTICE		E
	E. PLEASE READ CAREFULLY. This Zireliang Dahua Technology Co. LTD (Dahua) License Agreement	
(Agreenment) se	orth the terms and conditions under which You are licensed to use the Software. By installing, copying,	
downloading the	Rware or using the same by any other means, you are desmed to have accepted this Agreement, if you do not	
12. E. Contraction 11.	le or in part, you do not have the right to use this Software, in which case you should immediately stop installing.	
	e of using the same by any other means.	
2 DEFINITIONS		
	formation management program(s) or supporting document(s) consisting of several modulus or functions.	
States and the second sec	rit(s) includes all or part of the source codes and object codes of the Software, as well as the images,	
	animations, audio, video, music, words and codes incorporated therein, it also includes all relevant paper or	
	an and technical documentation which describe the functions, characteristics, contents, quality, teats, customer	k
manual and a second	emente, etc. (Software Product or Software).	
	ignee to all terms	

<u>Step 4</u> Select the I have read and agree to all terms checkbox, and then click Next.

Figure 3-3 Easy4ip



<u>Step 5</u> You can register the camera to Easy4ip, select the checkbox as needed, and then click **Next**.



#### Figure 3-4 Online upgrade

Online	Upgrade
(27)	Nuto-check for updates
3	Notify automatically when updates available. The system checks for updates every day.
2	Online Upgrade is a service that provides you with timware updates by cloud. This service will collect device information in order to inform you about available timware updates. Such attormation may include your device name, timware version and device dentification numbers. Such information is processed for the sole purpose of informing you about firmware updates.
	Baye

<u>Step 6</u> Select the upgrading method as needed.

If you select **Auto-check for updates**, the system checks new version once a day automatically. There will be system notice on **Upgrade** interface and **Version** interface if any new version is available.

Select **Setting > System > Upgrade > Online Upgrade**, and you can enable the auto-check function.

Step 7 Click Save.



# **4 Basic Configuration**

The chapter introduces the basic configuration, including login, live view, PTZ operation, playback, camera configuration, network configuration, storage configuration and system configuration.

## 4.1 Login

This section introduces how to log in to and log out of the web interface. This section takes IE Explorer 9 as an example.

 $\square$ 

- You need to initialize the camera before logging in to the web interface. For details, see "3 Device Initialization".
- When initializing the camera, keep the PC IP and device IP in the same network.
- Follow the instruction to download and install the plug-in for the first login.
- <u>Step 1</u> Open IE browser, enter the IP address of the camera (192.168.1.108 by default) in the address bar and press Enter.

alhua	7		
Usemame:			1
Password			Forgol pasaword?
	Login	Cancel	

Figure 4-1 Login

Step 2Enter the username and password.The username is admin by default.

⊙-~ر

Click **Forget password?**, and you can reset the password through the email address that is set during the initialization. For details, see "6.3 Resetting Password".

#### Step 3 Click Login.

- Live: Click **Live**, and you can view the real-time monitoring image.
- Playback: Click **Playback**, and you can play back or download recorded video or image files.
- Setting: Click **Setting**, and you can configure the basic and intelligent functions of the camera.
- For the camera with multiple channels, through selecting channel numbers, you can set the parameters of the channels.



- Alarm: Click Alarm, and you can subscribe and view alarm information.
- Logout: Click **Logout** to go to login interface.
- The system will sleep automatically after idling for a period of time.



## 4.2 Live

This section introduces the layout of the interface and function configuration.

## 4.2.1 Live Interface

This section introduces system menu, encode bar, live view function bar, and window adjustment bar.

Log in and click the **Live** tab.

 $\square$ 

The functions and interfaces of different models might vary.





No.	Function	Description
1	Encode bar	Sets stream type and protocol.
2	Live view	Displays the real-time monitoring image.
3	Live view function bar	Functions and operations in live viewing.
4	Window adjustment bar	Adjustment operations in live viewing.

## 4.2.2 Encode Bar

Figure	4-4	Encode	bar

	Main Stream	Sub Stream 1	Sub Stream 2	Protocol TCP	•
--	-------------	--------------	--------------	--------------	---

- **Main Stream**: It has large bit stream value and image with high resolution, but also requires large bandwidth. This option can be used for storage and monitoring. For details, see "4.5.2.1 Video".
- **Sub Stream**: It has small bit stream value and smooth image, and requires less bandwidth. This option is normally used to replace main stream when bandwidth is not enough. For details, see "4.5.2.1 Video".
- **Protocol**: You can select the network transmission protocol as needed, and the options are **TCP**, **UDP** and **Multicast**.

```
\square
```

Before selecting Multicast, make sure that you have set the Multicast parameters.

## 4.2.3 Live View Function Bar

For the live view function bar, see Table 4-2.



Table 4-2 Description of live view function bar			
lcon	Function	Description	
		Manually position the tracking speed dome to the selected location of corresponding panoramic camera.	
		Click the icon and click or select randomly on the image of panoramic camera channel, the tracking speed dome will automatically position the selected location.	
	Manual Position	<ul> <li>For multi-sensor panoramic network camera + PTZ camera, before enabling manual position, make sure that you have enabled alarm track and smart track calibration. For details, see "5.2 Setting Smart Track".</li> <li>For panoramic network camera, before enabling manual position, make sure that you have enabled panoramic linkage. For details, see "5.3 Setting Panoramic Calibration".</li> </ul>	
$\Xi$	Regional Focus	Select channel image of the tracking speed dome, click the icon and click or select randomly on the channel image of the tracking speed dome, and then the speed dome can realize auto focus upon the selected region.	
¢	Wiper	Controls the wiper of the camera. Click the icon to enable or disable wiper function.	
	Ranging	Click the icon, select a point on the ground, and the distance between the camera and the selected point will be displayed. Before using this function, you need to set the installation of device first. For details, see "4.5.2.3.12 Configuring Ranging".	
-	Gesture	Controls PTZ by operating the mouse on the live view of tracking speed dome. Select the live view of tracking speed dome, click the icon, press left-button and drag image to control PTZ. And you can zoom in or out the image through rolling mouse wheel.	
$\bigcirc$	Manual Track	Click the icon, and select tracking target on the live view of tracking speed dome, the camera tracks the selected target automatically.	

### Table 4-2 Description of live view function bar



lcon	Function	Description	
	Vehicle Density	Click the icon, and select an area on the live image, the camera will automatically count the number of the vehicles in the selected area, and display the number on the <b>Live</b> interface.	
	Relay-out	<ul> <li>Displays alarm output state. Click the icon to force to enable or disable alarm output.</li> <li>Alarm output state description:</li> <li>Red: Alarm output enabled.</li> <li>Grey: Alarm output disabled.</li> </ul>	
Q	Warning Light	Displays the warning light state. Click the icon to enable or disable the warning light forcibly.	
<b>.</b>	Alarm	Displays alarm sound state. Click the icon to enable or disable the alarm sound forcibly.	
	Crowd Map	<ul> <li>Click the icon to display the crowd map on the Live interface.</li> <li>Only after enabling the function, can you see the icon on the Live interface.</li> <li>The positions of the icon might vary depending on models.</li> </ul>	
•	Digital Zoom	<ul> <li>You can zoom in or out video image through two operations.</li> <li>Click the icon, and then select an area in the video image to zoom in; right-click on the image to resume the original size. In zoom in state, drag the image to check other area.</li> <li>Click the icon, and then scroll the mouse wheel in the video image to zoom in or out.</li> </ul>	
	Snapshot	Click the icon to capture one picture of the current image, and it will be saved to the configured storage path. About viewing or configuring storage path, see "4.5.2.5 Path".	
	Triple Snapshot	Click the icon to capture three pictures of the current image, and they will be saved to the configured storage path. About viewing or configuring storage path, see "4.5.2.5 Path".	



lcon	Function	Description	
D'	Record	Click the icon to record video, and it will be saved to the configured storage path. About viewing or configuring storage path, see "4.5.2.5 Path".	
[+]	Easy Focus	<ul> <li>4.3.2.5 Patn .</li> <li>Click the icon, the AF Peak (focus eigenvalue) and AF Max (max focus eigenvalue) are displayed on the video image.</li> <li>AF Peak: The eigenvalue of image definition, it displays during focus.</li> <li>AF Max: The best eigenvalue of image definition.</li> <li>The smaller the difference between AF pe value and the AF max value, the better the focus is.</li> <li>Easy focus closes automatically after five minutes.</li> </ul>	
$\rightarrow$	Audio	Click the icon to enable or disable audio output.	
<b>.</b>	Talk	Click the icon to enable or disable the audio talk.	

## 4.2.4 Window Adjustment Bar

## 4.2.4.1 Adjustment

This section introduces the adjustment of image.



Table 4-3 Description of adjustment bar			
lcon	Function	Description	
	Image Adjustment	<ul> <li>Click the icon, and then the Image Adjustment interface is displayed at the right side of the Live interface. You can adjust brightness, contrast, hue, and saturation.</li> <li>The adjustment is only available on the web interface, and it does not adjust the camera parameters.</li> <li>Image (Brightness adjustment): Adjusts the overall image brightness, and change the value when the image is too bright or too dark. The bright and dark areas will have equal changes.</li> <li>Image (Contrast adjustment): Change the value when the image brightness is proper but contrast is not enough.</li> <li>Image (Hue adjustment): Makes the color deeper or lighter. The default value is made by the light sensor, and it is recommended.</li> <li>Image (Saturation adjustment): Adjusts the image saturation. This value does not change image brightness.</li> </ul>	
100%	Original Size	Click the icon, and it changes to and then the video displays with original size; click <sup>100%</sup> , and the video displays with adapted size.	
X	Full Screen	Click the icon to enter full screen mode; double-click or press Esc to exit.	
W:H	Width : Height	Click the icon to resume original ratio or change ratio.	

#### Table 4-3 Description of adjustment bar



lcon	Function	Description
	Fluency	<ul> <li>Click the icon to select the fluency from Realtime, Fluency and Normal.</li> <li>Realtime: Guarantees the real-time display of the image. When the bandwidth is not enough, the image might not be smooth.</li> <li>Fluency: Guarantees the fluency of the image. There might be delay between live view image and real-time image.</li> <li>Normal: It is between Realtime and Fluency.</li> </ul>
+ <u></u> ₀	Rule Info	Click the icon, and then select <b>Enable</b> to display smart rules and detection box; select <b>Disable</b> to stop the display. It is enabled by default.
PTZ	PTZ	Click the icon, and the <b>PTZ</b> control panel is displayed at the right side of the <b>Live</b> interface. You can control and call PTZ function. For details, see"4.3.3 Calling PTZ".
<b>E</b>	Zoom and Focus	Adjust focal length to zoom in and out video image. Click the icon, and the <b>Zoom and Focus</b> configuration interface is displayed at the right side of the <b>Live</b> interface. You can control and call PTZ function. For details, see "4.2.4.2 Zoom and Focus".
Ο	Fisheye	Click the icon, and then the Fisheye configuration interface is displayed at the right side of the <b>Live</b> interface. For details, see "4.2.4.3 Fisheye".
	Face	<ul> <li>Click the icon, and the face detection or face recognition results are displayed on the Live interface.</li> <li>For face recognition, see "5.10.1 Setting Face Detection".</li> <li>For face detection: see "5.11 Setting Face Detection".</li> </ul>
	ANPR	Click the icon, and the ANPR results are displayed on the <b>Live</b> interface. For details, see "5.16 Setting ANPR".
	Video Metadata	Click the icon, the video metadata results are displayed on the <b>Live</b> interface. For details, see "5.17 Setting Video Metadata".



lcon	Function Description	
	Window Layout	<ul> <li>When viewing the multi-channel image, you can select display layout.</li> <li>For Multi-Sensor Panoramic + PTZ Camera: <ul> <li>The live interface will show</li> <li>Panorama 1 and Panorama 2 by default if you choose dual-channel mode.</li> </ul> </li> <li>If you switch from three-channel mode or dual-channel mode to single-channel mode, the live window will show Panorama 1 by default. Click <ul> <li>Panorama 1 Panorama 2 PTZ Camera</li> <li>and select the camera you want to view.</li> </ul> </li> </ul>
<b>m</b>	Crowd Map	Click the icon and select the <b>Enable</b> checkbox. The <b>Crowd Map</b> interface is displayed. For details, see"5.9 Setting Crowd Map".


## 4.2.4.2 Zoom and Focus

You can adjust focal length to zoom in or out video image and the image clarity.

 $\square$ 

The focus would adjust automatically after zooming in or out.

Figure 4-5 Zoom and focus





Parameter	Description		
Zoom	<ul> <li>Changes the focal length of the camera to zoom in or out the image.</li> <li>1. Set the <b>Speed</b> value. The <b>Speed</b> is the adjustment range in one click. The larger the value is, the more the image would zoom in or out in one click.</li> <li>2. Click or hold + or- button, or drag the slider to adjust zoom.</li> </ul>		
Focus	<ul> <li>Adjusts the optical back focal length to make the image clearer.</li> <li>1. Set the <b>Speed</b> value. The <b>Speed</b> is the adjustment range in one click. The larger the value is, the more the adjustment in one click.</li> <li>2. Click or hold + or- button, or drag the slider to adjust focus.</li> </ul>		
Auto Focus	Adjusts image clarity automatically. Do not make any other operation during auto focus process.		
Restore All	Restores focus to default value and corrects errors. You can restore the focus if the image has poor clarity or has been zoomed too frequently.		
Regional Focus	Focus on the subject of a selected area. Click <b>Regional Focus</b> , and then select an area in the image, the camera performs auto focus in that area.		
Refresh	Get the latest zoom setting of the device.		

Table 4-4 Description of zoom and focus

## 4.2.4.3 Fisheye

You can select the installation mode, display mode and VR mode of fisheye devices as needed. For details, see Table 4-5.

- Install Mode: Select the installation mode according to the actual situation.
- **Display Mode**: Select the display mode of live view.
- **VR Mode**: Select VR mode to display images in stereo mode.





Table 4-5 Description of fisheye configuration

Parameter	Description		
Installation mode	Includes ceiling mount, wall mount, and ground mount.		
Display mode	<ul> <li>The display mode of the current image. There are different display modes for each installation mode.</li> <li>Ceiling: 1P+1, 2P, 1+2, 1+3, 1+4, 1P+6, 1+8.</li> <li>Wall: 1P, 1P+3, 1P+4, 1P+8.</li> <li>Ground: 1P+1, 2P, 1+3, 1+4, 1P+6, 1+8.</li> <li>The image will be on original size by default when switching installation mode.</li> </ul>		
Ceiling/Wall/Gro und mount	Original image The original image before correction.		



Parameter	Description	
	(→ 1P+1	<ul> <li>360° rectangular panoramic image screen + independent sub-screens.</li> <li>You can zoom or drag the image in all the screens.</li> <li>You can move the start point (left and right) on rectangular panoramic image screen.</li> </ul>
	t → 2P	Two associated 180° rectangular image screens, and at any time, the two screens form a 360° panoramic image. It is also called dual-panoramic image. You can move the start point (left and right) on the two rectangular panoramic image screens, and the two screens link each other.
	Q Q 1+2	<ul> <li>Original image screen + two independent sub-screens. Ground Mount does not support this display mode.</li> <li>You can zoom or drag the image in all the screens.</li> <li>You can rotate the image on the original image screen to change the start point.</li> </ul>
Ceiling/Ground mount	Q 1+3	<ul> <li>Original image screen + three independent sub-screens.</li> <li>You can zoom or drag the image in all the screens.</li> <li>You can rotate the image on the original image screen to change the start point.</li> </ul>
	Q-Q-1+4	<ul> <li>Original image screen + four independent sub-screens.</li> <li>You can zoom or drag the image in all the screens.</li> <li>You can rotate the image on the original image screen to change the start point.</li> </ul>
	1P+6	<ul> <li>360° rectangular panoramic screen + six independent sub-screens.</li> <li>You can zoom or drag the image in all the screens.</li> <li>You can move the start point (left and right) on rectangular panoramic image screen.</li> </ul>
	Q 1P+8	<ul> <li>Original image screen + eight independent sub-screens.</li> <li>You can zoom or drag the image in all the screens.</li> <li>You can rotate the image on the original image screen to change the start point.</li> </ul>



Parameter	Description	
	1P	180° rectangular panoramic image screen (from left to right). You can drag the image in all the screens (up and down) to adjust the vertical view.
	1P+3	<ul> <li>180° rectangular panoramic image screen + three independent sub-screens.</li> <li>You can zoom or drag the image in all the screens.</li> <li>You can drag the image in all the screens (upper and lower) to adjust the vertical view.</li> </ul>
Wall mount	1P+4	<ul> <li>180° rectangular panoramic image screen + four independent sub-screens.</li> <li>You can zoom or drag the image in all the screens.</li> <li>You can drag the image in all the screens (upper and lower) to adjust the vertical view.</li> </ul>
	1P+8	<ul> <li>180° rectangular panoramic image screen + eight independent sub-screens.</li> <li>You can zoom or drag the image in all the screens.</li> <li>You can drag the image in all the screens (upper and lower) to adjust the vertical view.</li> </ul>
	Panorama	Drag or cross the screen 360° to unfold the distortion panorama, and you can drag the image in left/right direction.
VR mode	Semi-circle	<ul> <li>You can drag the image in upper/lower/left/right direction. Press I to display the panorama, and press O to resume the original size.</li> <li>Press S to rotate the image in anticlockwise direction, and press E to stop the rotation.</li> <li>Scroll the mouse wheel to zoom the image.</li> </ul>
	<b>Cylinder</b>	<ul> <li>Display the distortion panorama in 360°circularity.</li> <li>You can drag the image in upper/lower/left/right direction. Press I to display the panorama, and press O to return to the original size.</li> <li>Press S to rotate the image in anticlockwise direction, and press E to stop the rotation.</li> <li>Scroll the mouse wheel to zoom the image.</li> </ul>



Parameter	Description	
	Asteroid	<ul> <li>You can drag the image in upper/lower/left/right direction. Press I to display the panorama, and press O to return to the original size.</li> <li>Press the left mouse-button to slide down to display the image on the plane surface.</li> <li>Scroll the mouse wheel to zoom the image.</li> </ul>

## 4.3 PTZ Operation

This section introduces PTZ parameter configuration, PTZ control and PTZ function configuration.

## 4.3.1 Configuring External PTZ Protocol

You need to configure PTZ protocol when accessing external PTZ camera; otherwise the camera cannot control external PTZ camera.

### Prerequisites

- Access external PTZ through RS-485.
- You have configured the parameters of serial port. For details, see "4.8.5.1 Serial Port Settings".

### Procedure

#### <u>Step 1</u> Select **Setting** > **PTZ Setting** > **Protocol**.

	Figure 4-7 PTZ setting				
	PTZ Settings				
	Protocol	PELCOD Default	Refresh	Save	
Step 2	Select the PTZ	protocol.			

Step 3 Click OK.

## **4.3.2 Configuring PTZ Function**

### 4.3.2.1 Preset

Preset means a certain position that the camera can make quick orientation to. It includes PTZ pan and tilt angles, camera focus, and location.

<u>Step 1</u> Select Setting > PTZ Settings > Function > Preset.



Figure 4-8 Preset

	+ Ennat + Tour + Doars	Hernber	Produkt Tillio	San Doa
	Pattern     Part     Part     PT2 Densel     Ide Motors     PowerUp     PT2 Land     PT2 Land		2 Rotati	B Remove All
23 (→) 200m (→) (→) 200m (→	+ PT2 Restart + Default			

- <u>Step 2</u> Set the speed, and click  $\bigotimes$ ,  $\bigcirc$  and  $\bigoplus$  to adjust the parameters of direction, zoom, focus and iris, to move the camera to the position you need.
- <u>Step 3</u> Click **Add** to add the current position to be a preset, and the preset is displayed in preset list.
- <u>Step 4</u> Double-click the preset title to edit it.
- <u>Step 5</u> Click 🔙 to save the preset.

### **Related Operations**

- Click 🥏 to delete the preset.
- Click **Remove All** to remove all presets.

## 4.3.2.2 Tour

Tour means a series of movements that the camera makes along several presets.

### Prerequisites

You have set several presets.

### Procedure

<u>Step 1</u> Select **Setting** > **PTZ settings** > **Function** > **Tour**.



Figure 4-9 Tour

	+ Frank	Tour Micol Sti Original Path
AND A DESCRIPTION OF A	139 + Scan	Tourns Tainame Deek
Contraction of the second	· Patient	
	+ Pan + PTZ Speed	
- SALAR I PERSONAL SE	+ Ille Beign	
	+ Powertio	
at a share of	PTZUNIT	
	+ Time Talk	-
N	+ Difault	• • • • • • • • • • • • • • • • • • •
Con the second	0.0000000	taves Prest Destings land D
fipser 5 💽		
		+Add Base # Ration

<u>Step 2</u> Click **Add** to add tour. Double-click the tour name to edit the name.

- <u>Step 3</u> Click **Add**<sup>②</sup> to add preset. Double-click the duration to set the duration.
- <u>Step 4</u> Select the tour mode.
  - Original path: The PTZ camera moves in the order of the selected presets.
  - Shortest path: The PTZ camera ranks presets by distance, and moves in the optimal path.
- Step 5 Click Save.
- Step 6 Click Start to start touring.

#### 

- If you operate PTZ during tour, the camera will stop tour.
- Click **Stop** to stop touring.

# 4.3.2.3 Scan

Scan means the camera moves horizontally at a certain speed between the configured left and right limits.

<u>Step 1</u> Select **Setting > PTZ settings > Function > Scan**.



Figure 4-10 Scan

	+ Preset + Tour	Scan No. Spood	1 © 0	
	Fottern			O Setup
A STATE AND AND A STATE AND A	+ Pan		Set Left Limit	Set rouges Land
	+ PTZ Speed			
	+ title Matters			
	+ PowerUp			
TR. WINDOW STREET	+ PTZ Limit			
	+ Time Tash + PTZ Restart			
2 (-) ZNUT (+)	+ Detaut			
Tonue (+)				
(v) ⊖ … ⊕				

- <u>Step 2</u> Select the scan number, and set the speed.
- <u>Step 3</u> Click **Setup** to set left limit and right limit.
  - 1) Click Set Left Limit to set the current position to be the left limit.
  - 2) Click **Set Right Limit** to set the current position to be the right limit.
- Step 4Click Start to start scanning.Click Stop to stop scanning.

# 4.3.2.4 Pattern

Pattern means a recording of a series of operations that you make to the camera, and when pattern starts, the camera performs the operations repeatedly. The operations include horizontal and vertical movements, zoom and preset calling. Record and save the operations, and then you can call the pattern path directly.

<u>Step 1</u> Select Setting > PTZ settings > Function > Pattern.




Figure 4-11 Pattern

	+ Prest	Patam No.	1	
<b>3</b> 年十月1日日世日世纪特出期	+ Teur + Scan		► Ctatt	@ Belap
C. C	+ Pattern	0	Starl Rec.	Stop Rec
	+ Pan			
	* FTZ Speed			
	+ tolie Motion			
	+ PowerUp			
THE COURSE STORE STORE	+ FTZ.Umit.			
	+ Time Task			

- <u>Step 2</u> Select the pattern number.
- <u>Step 3</u> Click **Setup**, and then click **Start Rec**. Adjust the parameters of direction, zoom, focus and iris according to the actual situation.
- <u>Step 4</u> Click **Stop Rec** to stop recording.
- <u>Step 5</u> Click **Start** to start patterning.
- <u>Step 6</u> Click **Stop** to stop patterning.

### 4.3.2.5 Pan

Enable Pan, the camera can realize continuous 360° horizontal rotation at a certain speed. <u>Step 1</u> Select **Setting** > **PTZ settings** > **Function** > **Pan**.







Click **Stop** to stop rotation.

# 4.3.2.6 PTZ Speed

PTZ speed means the rotation speed of the PTZ camera during touring, pattern, or auto tracking. <u>Step 1</u> Select **Setting** > **PTZ settings** > **Function** > **PTZ Speed**.



	+ Pissot + Tour + Scarl + Pattern	PTZ Speed 🖒 Low	9 800×	O Han
	Par     Par     Par     Parassered     Idia Notion     PowerUp     PTZ Land     Time Task			
Direct 5	+ PTZ Rustart + Debuilt			



### 

**Speed** under the direction buttons refers to the rotation angle of the PTZ camera for each press of the direction button.

# 4.3.2.7 Idle Motion

Idle motion means that the PTZ camera implements the operation which is configured in advance when it does not receive any valid command within the set time.

#### Prerequisites

You have configured the PTZ motions, including preset, scan, tour, or pattern.

#### Procedure

<u>Step 1</u> Select Setting > PTZ settings > Function > Idle Motion.




Figure 4-14 Idle motion



- <u>Step 2</u> Select the **Enable** checkbox to enable the idle motion function.
- Select the idle motion and set the idle time.
   You need to select the corresponding number for some selected idle motions, such as
   Preset001.
- Step 4 Click Save.

# 4.3.2.8 PowerUp

After setting Powerup motion, the camera will perform the configured motion after it is powered on. <u>Step 1</u> Select **Setting > PTZ settings > Function > PowerUp**.



<u>Step 2</u> Select the **Enable** checkbox to enable the power up function.



<u>Step 3</u> Select the power up motion.

 $\square$ 

When you select **Auto**, the system will perform the last motion that is executed for more than 20 s before power-off.

Step 4 Click **OK**.

## 4.3.2.9 PTZ Limit

After setting PTZ limit, the camera can only rotate within the configured area.

<u>Step 1</u> Select Setting > PTZ settings > Function > PTZ Limit.

Figure 4-16 PTZ limit Function Tradia . Wants its to be + DOAR DOWNLIN · Patters Past n hi bee 772 Courd · PT2 licest 1041 Whe Horney · Powetta Citris Tand · PTZ Hastor + Tista.# - Joint (+) Fatta (+)

<u>Step 2</u> Adjust the direction buttons, and then click **Setting**(1) to set the up line; click **Setting**(2) to set the down line.

Click **Live** to view the configured up line and down line.

<u>Step 3</u> Select the **Enable** checkbox to enable the PTZ limit function.

# 4.3.2.10 Time Task

After setting time task, the camera performs the motions during the configured period.

#### Prerequisites

You have configured the PTZ motions, including preset, scan, tour, and pattern.

### Procedure

<u>Step 1</u> Select Setting > PTZ settings > Function > Time Task.



#### Figure 4-17 Time task

	receit 🖉 Encola	
	ter Task Sel	Clover All     Clover All     Prepart O Tour     Sourt O Pattern     1. Prepart/001     *      38     a (5-3038)
s	TR Taxk Mo. Corp. To Taxk Mo. Refeat	t <u>el can</u>

- <u>Step 2</u> Select the **Enable** checkbox to enable time task function.
- <u>Step 3</u> Select the time task number.
- <u>Step 4</u> Select the time task action.

You need to select the corresponding action number for some selected time task actions.

- Set the auto home time in AutoHome.
   AutoHome: When you call PTZ, the time task will be interrupted. After setting AutoHome time, the camera will resume the time task automatically.
- <u>Step 6</u> Click **Period setting** to set the time of the task, and then click **Save**. For setting arm time, see "5.1.1.1 Setting Period".
- Step 7 Click Save.

#### **Related Operations**

You can copy the configurations of existing task number to other task number.

- 1. Select the existing task number in **Time Task num**.
- 2. Select the task number to be configured in Copy To Task No.
- 3. Click Copy.
- 4. Click Save.

# 4.3.2.11 PTZ Restart

<u>Step 1</u> Select Setting > PTZ settings > Function > PTZ Restart.





<u>Step 2</u> Click **PTZ Restart** to restart PTZ.

# 4.3.2.12 Default

 $\wedge$ 

Be careful when doing this operation. It will restore the camera to default configuration, and result in data loss.

<u>Step 1</u> Select Setting > PTZ settings > Function > Default.





<u>Step 2</u> Click **Default** and the PTZ function is restored to default.

# 4.3.3 Calling PTZ

Click **m** on **Live** interface, and the PTZ configuration panel is displayed. You can control PTZ and call PTZ function.

# 4.3.3.1 PTZ Control

You can rotate device, zoom image, and adjust iris through PTZ control or virtual joystick. See Figure 4-20 and Figure 4-21.



#### Figure 4-20 PTZ control



#### Figure 4-21 Joystick



• Rotate PTZ direction through direction button. PTZ supports eight directions:

left/right/up/down/upper left/upper right/bottom left/bottom right. Click (a), and draw a box in the image, PTZ will rotate, focus and quickly position the defined scene.

• Rotate PTZ direction through joystick. Select and hold 🕋, and drag it to the direction

that you need, then PTZ will move to the defined direction.

- Speed: Measure the rotation speed. The higher the speed value is, the faster the speed becomes.
- Zoom, focus and iris: Click  $\bigcirc$  or  $\bigoplus$  to adjust zoom, focus and iris.



## 4.3.3.2 PTZ Function

Select the PTZ function from the drop-down list to call the corresponding functions, including Scan, Preset, Tour, Pattern, Pan, Go to, Assistant and Light Wiper. See Figure 4-22. For details, see Table 4-6. Before calling PTZ function, see "4.3.2 Configuring PTZ Function" to configure PTZ function.

 $\square$ 

- If an external PTZ is connected to the camera, the configurations are valid only when the corresponding functions are available on the external PTZ.
- The range of PTZ function (such as preset and tour) depends on the PTZ protocol.




Table 4-6 Description of PTZ function

Parameter	Description
Scan	Set the scan number and click <b>Start</b> , the camera moves horizontally at a certain speed between the set left and right limit. Click <b>Stop</b> to stop scanning.
Preset	Set the preset number and click <b>Go to</b> , the camera quickly positions the corresponding preset.
Tour	Set the tour number and click <b>Start</b> , the camera moves in the order of the selected presets. Click <b>Stop</b> to stop touring.
Pattern	Set the pattern number and click <b>Start</b> , the camera moves continuously according to the operation recording. Click <b>Stop</b> to stop patterning. Operation recording includes the information of manual operation, focus and zoom.
Pan	Click <b>Start</b> , and the camera rotates 360° at a certain speed in horizontal direction.
Go to	Set the horizontal angle, vertical angle, and zoom. Click <b>Go to</b> to position a certain point accurately.
Assistant	Set the assistant number and click <b>Aux On</b> to enable the corresponding assistant function, and then you can adjust the camera. Click <b>Aux Off</b> to disable the corresponding assistant function.
	Set the light or wiper of the camera.
Light/Wiper	Click <b>Enable</b> to enable light/wiper function.
	Click <b>Disable</b> to disable light/wiper function.

# 4.4 Playback

This section introduces playback related functions and operations, including video playback and picture playback.



 $\square$ 

- Before playing back video, configure record time range, record storage method, record schedule and record control. For details, see "5.1.1.2.1 Setting Record Plan".
- Before playing back picture, configure snapshot time range, snapshot storage method, snapshot plan. For details, see"5.1.1.3.1 Setting Snapshot Plan".

# 4.4.1 Playback Interface

Click the **Playback** tab, and the **Playback** interface is displayed.




Figure 4-23 Video playback

Figure 4-24 Picture playback





No.	Function	Description
	Fisheye	Click , you can select display mode according to the installation mode during playback.
1	Rules Info	Click Solution of the state of
2	Sound	<ul> <li>Controls the sound during playback.</li> <li>Substant Mute mode.</li> <li>Ocal state. You can adjust the sound.</li> </ul>
3	Play control bar	<ul> <li>Controls playback.</li> <li>Click the icon to play back recorded videos.</li> <li>Click the icon to stop playing back recorded videos.</li> <li>Click the icon to play the next frame.</li> <li>Click the icon to slow down the playback.</li> <li>Click the icon to speed up the playback.</li> </ul>
4	Progress bar	<ul> <li>Displays the record type and the corresponding period.</li> <li>Click any point in the colored area, and the system will play back the recorded video from the selected moment.</li> <li>Each record type has its own color, and you can see their relations in <b>Record Type</b> bar.</li> </ul>
5	Record/Snapshot Type	<ul> <li>Select the record type or snapshot type.</li> <li>Record type includes General, Event, Alarm, Manual.</li> <li>Snapshot type includes General, Event, Alarm.</li> </ul>
6	Assistant	<ul> <li>You can zoom in or out video image of the selected area through two operations.</li> <li>Click the icon to capture one picture of the current video, and it will be saved to the configured storage path.</li> </ul>
7	Playback video	You can select the file type, data source, and record date.
8	Video clip	Clip a certain recorded video and save it. For details, see "4.4.3 Clipping Video".

Table 4-7 Playback interface description



No.	Function	Description
9	Time format of progress bar	Includes 4 time formats: 24hr, 22hr, 21hr, 30min. Take 24hr as an example, the whole progress stands for 24 hours.

# 4.4.2 Playing back Video or Picture

This section introduces the operation of video playback and picture playback. This section takes video playback as an example.

<u>Step 1</u> Select **dav** from the **Record Type** drop-down list and **SD card** from the **Data Src** drop-down list.

Select **jpg** from **Record Type** drop-down list when playing back pictures, and you do not need to select data source.




Figure 4-25 File type selection

<u>Step 2</u> Select the record type in **Record Type**.


Figure 4-26 Record type selection

Record Type	🗹 All	🗹 General 📕	🗹 Motion 📃	🗹 Alarm 📕	🗹 Manual 📕	
When selecti	ng <b>Even</b>	<b>t</b> as the record t	ype, you can se	lect the specifi	c event types fror	n the

playback file list, such as Motion Detection, Video Tamper and Scene Changing.



Figure 4-27 Specific event types



<u>Step 3</u> Select the month and year of the video that you want to play.

```
\square
```

Those dates with blue color indicate there were videos recorded in those days.

- Step 4 Play video.
  - Click **•** in the control bar.

The system plays the recorded video of the selected date (in the order of time).

- The system plays the recorded video of the selected date (in the order of time).
- Click any point in the colored area on the progress bar. The playback starts from that moment.

#### Figure 4-28 Progress bar

- - Click I click cli




#### Figure 4-29 Playback file list



# 4.4.3 Clipping Video

- <u>Step 1</u> Click **I** , the video files of the selected date are listed.
- Select dav or mp4 in Download Format. Step 2
- Click on the progress bar to select the start time of the target video, and then click Step 3 See Figure 4-30.

Figure 4-30 Clipping video





<u>Step 5</u>	Click 🔛 to download the video.
	The system will prompt that it cannot play back and download at the same time.
<u>Step 6</u>	Click <b>OK</b> .
	The playback stops and the clipped file is saved in the configured storage path. For the
	configuration of storage path, see "4.5.2.5 Path".

# 4.4.4 Downloading Video or Picture

Download video or picture to a defined path. You can download single video or picture file, or download them in batches. This section takes downloading video as an example.

 $\square$ 

- Playback and downloading at the same time is not supported.
- Operations might vary with different browsers.
- For details of viewing or setting storage path, see "4.5.2.5 Path".

# 4.4.4.1 Downloading a Single File

<u>Step 1</u> Select **dav** from the **Record Type** drop-down list and **SD card** from the **Data Src** drop-down list.

Select **jpg** from **Record Type** drop-down list when playing back pictures, and you do not need to select data source.

- Step 2 Click 📕 , the video files of the selected date are listed. See Figure 4-29.
- Step 3 Select dav or mp4 in Download Format. Click next to the file to be download. The system starts to download the file to the configured path. When downloading pictures, you do not need to select the download format.

# 4.4.4.2 Downloading Files in Batches

<u>Step 1</u> Click ■ on the playback interface.



Figure 4-31 Batch download

Egok	All Vicience	-											
Slart Term	2019-06-18	56		66	-01	the Tree	2019-35-18	1	23	59			Seath ()
	Harton P	AN TALANCE	ī.			pe think	500	104		161	ŵ.	100AU	out Print th
													and the
											н	(41))	и т і
10 510 10	=										H	( 4 1/1 )P	мата
											H	( 4 1/1 )	м т Б
14 Sco 30 744 Fab	the										н	(41/19	H I (j

- Step 2Select the record type, set the start time and end time, and then click Search.The searched files are listed.
- <u>Step 3</u> Select the files to be downloaded, select dav or mp4 from the Format drop-down list, and then set the storage path. Click Download.
   The system starts to download the file to the configured path. When downloading picture, you do not need to select the download format.

# 4.5 Camera

This section introduces the camera setting, including conditions, video and audio.

 $\square$ 

Camera parameters of different devices might vary.

# 4.5.1 Conditions

Configure camera parameters of the camera to ensure surveillance goes properly.

# 4.5.1.1 Conditions

Configure camera parameters according to the actual situation, including picture, exposure, backlight and white balance.

#### 4.5.1.1.1 Interface Layout

Configure camera parameters to improve the scene clarity, and ensure that surveillance goes properly. See Figure 4-32.

• Under profile, you can select between 9 different styles, such as normal, day, night or flowing light mode. Parameters (such as contrast and saturation) will change to match the style. You can



also further modify the configurations for select modes (such as picture, exposure and backlight) after changing the main style. Flowing light is suitable for situations where there is slight light, and the panoramic function is unable to effectively detect targets.

 $\square$ 

- After switching to flowing light, the mode in the exposure menu is automatically set to manual. The shutter time is adaptive, working at a maximum speed of 333 ms.
- By default the backlight is off. The wide dynamic effect start or not can be determined by identifying the overexposure in the picture. This gives you control over overexposure in the picture.
- Camera with PTZ function supports zoom, focus and iris operations. See Figure 4-33. Configure speed, click direction button, 

   and I to adjust the direction, zoom, focus and iris and so on, to adjust the camera to the proper position.






Figure 4-33 Camera conditions (PTZ camera)

		Postla Day		-
	Content     Concerns     Concerns     Concerns     Concerns     Concerns     Concerns     Concerns     Concerns     Concerns     Concerns	OH Surfar Brythess - Control - Standed - Chana CH - Shagness CH -	000000	
Detual Referit Save		Gavera [ Fig (* 685 Ov s Ritus Fasar Ov s		



#### 4.5.1.1.2 Picture

You can configure picture parameters as needed.

<u>Step 1</u> Select Setting > Camera > Conditions > Conditions > Picture.

Figure 4-34 Picture

Channel	PTZ Camera	•	
	Profile Day		~
▶ Picture	Style Standar	rd	~
Exposure	Brightness -	-0	
<ul> <li>Backlight</li> </ul>	Contrast -	<u>0</u>	+ 50
▶ WB	Saturation -	-0	
Day & Night	Chroma CNT 📃	-0	+ 50
ZoomFocus	Sharpness -	-0	+ 50
<ul> <li>Illuminator</li> </ul>	Sharpness CNT 📃	-0	+ 50
▶ Defog	Gamma 🗕	-0	+ 50
	Flip 0°		~
	Optical Dejitte   On	Off	
	Picture Freeze 🔿 On (	<ul> <li>Off</li> </ul>	

#### <u>Step 2</u> Configure picture parameters.

Parameter	Description
Style	<ul> <li>Select the picture style from soft, standard and vivid.</li> <li>Soft: Default image style, displays the actual color of the image.</li> <li>Standard: The hue of the image is weaker than the actual one, and contrast is smaller.</li> <li>Vivid: The image is more vivid than the actual one.</li> </ul>
Brightness	Changes the value to adjust the picture brightness. The higher the value is, the brighter the picture will be, and the smaller the darker. The picture might be hazy if the value is configured too big.
Contrast	Changes the contrast of the picture. The higher the value is, the more the contrast will be between bright and dark areas, and the smaller the less. If the value is set too big, the dark area would be too dark and bright area easier to get overexposed. The picture might be hazy if the value is set too small.
Saturation	Makes the color deeper or lighter. The higher the value is, the deeper the color will be, and the lower the lighter. Saturation value does not change image brightness.
Sharpness	Changes the sharpness of picture edges. The higher the value is, the clearer the picture edges will be, and if the value is set too big, picture noises are more likely to appear.



Parameter	Description
Gamma	Changes the picture brightness and improves the picture dynamic range in a non-linear way. The higher the value is, the brighter the picture will be, and the smaller the darker.
Mirror	Select <b>On</b> , and the picture would display with left and right side reversed.
Flip	<ul> <li>Changes the display direction of the picture, see the options below.</li> <li>0°: Normal display.</li> <li>90°: The picture rotates 90° clockwise.</li> <li>180°: The picture rotates 90° counterclockwise.</li> <li>270°: The picture flips upside down.</li> <li>Image: For some models, please set the resolution to be 1080p or lower when using 90° and 180°. For details, see "4.5.2.1 Video".</li> </ul>
EIS	Corrects the device shaking with difference comparison algorithm and improves the image clarity, effectively solves the picture shaking problem.
Optical Dejitering	The lens vibration is sensed by the gyroscope sensor, and the corresponding compensation is calculated using the intelligent anti-shake algorithm. The movable parts inside the lens are driven to offset the vibration, which greatly reduces blurring of the image caused by the vibration.
Picture Freeze	When you call a preset, the image displays the preset location, not the rotation image.

Step 3 Click Save.

### 4.5.1.1.3 Exposure

Configure iris and shutter to improve image clarity.



Cameras with true WDR do not support long exposure when WDR is enabled in **Backlight**. <u>Step 1</u> Select Setting > Camera > Conditions > Conditions > Exposure.

#### Figure 4-35 Exposure

	Profile	Day		+
<ul> <li>Picture</li> </ul>	Anti-flicker	Outdoor		
+ Exposure	Mode	Auto		-
<ul> <li>Backlight</li> </ul>	30 NR	a on O	Off	2.02
⊧WB	Grade	=	0	- (± 50
<ul> <li>Day &amp; Night</li> </ul>				
+ Illuminator				
+ Image Correction				
<ul> <li>Splicing Mode</li> </ul>				



# <u>Step 2</u> Configure exposure parameters.

Table 4-9 Description of exposure parameters

Parameter	Description
Anti-flicker	<ul> <li>You can select from 50 Hz, 60 Hz and Outdoor.</li> <li>50 Hz: When the electric supply is 50 Hz, the system adjusts the exposure according to ambient light automatically to ensure that there is no stripe appears.</li> <li>60 Hz: When the electric supply is 60 Hz, the system adjusts the exposure according to ambient light automatically to ensure that there is no stripe appears.</li> <li>Outdoor: You can select any exposure mode as needed.</li> </ul>
Mode	<ul> <li>Device exposure modes.</li> <li>Auto: Adjusts the image brightness according to the actual condition automatically.</li> <li>Gain Priority: When the exposure range is normal, the system prefers the configured gain range when auto adjusting according to the ambient lighting condition. If the image brightness is not enough and the gain has reached upper or lower limit, the system adjusts shutter value automatically to ensure the image at ideal brightness. You can configure gain range to adjust gain level when using gain priority mode.</li> <li>Shutter priority: When the exposure range is normal, the system prefers the configured shutter range when auto adjusting according to the ambient lighting condition. If the image brightness is not enough and the shutter value has reached upper or lower limit, the system prefers the configured shutter range when auto adjusting according to the ambient lighting condition. If the image brightness is not enough and the shutter value has reached upper or lower limit, the system adjusts gain value automatically to ensure the image at ideal brightness.</li> <li>Iris priority: The iris value is set to a fixed value, and the device adjusts shutter value has reached upper or lower limit, the system adjusts gain value automatically to ensure the image at ideal brightness.</li> <li>Manual: Configure gain and shutter value manually to adjust image brightness.</li> <li>Manual: Configure gain and shutter value manually to adjust image brightness.</li> <li>When the Anti-flicker is set to Outdoor, you can select Gain priority or Shutter priority in the Mode list.</li> </ul>
Exposure Comp	Sets the value, and it ranges from 0 to 50. The higher the value is, the brighter the image will be.
Shutter	Set the effective exposure time. The smaller the value, the shorter the exposure time will be.



Parameter	Description
Shutter range	When selecting <b>Shutter Priority</b> or <b>Manual</b> in <b>Mode</b> , and setting <b>Customized Range</b> in <b>Shutter</b> , you can set shutter range, and the unit is ms.
Gain	When selecting <b>Gain Priority</b> or <b>Manual</b> in <b>Mode</b> , you can set shutter range. With minimum illumination, the camera increases Gain automatically to get clearer images.
Iris	When selecting <b>Aperture Priority</b> in <b>Mode</b> , you can set iris range.
	This configuration is available only when the camera is equipped with auto-iris lens.
	When auto iris is enabled, the iris size changes automatically
Auto Iris	according to the ambient lighting condition, and the image
	brightness changes accordingly.
	When auto iris is disabled, the iris stays at full size and does not
	change no matter how ambient lighting condition changes.
2D NR	Average single-frame dots and other dots around to reduce noise.
3D NR	Works with multi-frame (no less than 2 frames) images and reduces noise by using the frame information between previous and latter frames.
Curada	This configuration is available only when the 3D DNR is enabled.
Grade	The higher the DNR level is, the better the result will be.
Step 3 Click Save	The higher the DNR level is, the better the result will be.

Step 3 Click Save.

### 4.5.1.1.4 Backlight

You can select backlight mode from Auto, BLC, WDR, and HLS.

#### <u>Step 1</u> Select Setting > Camera > Conditions > Conditions > Backlight.

Figure 4-36 Backlight

	5	3	
	Profile	Day	•
▶ Picture	Mode	Off	T
Exposure			
▶ Backlight			
▶ WB			
Day & Night			
Illuminator			
Image Correction			
<ul> <li>Splicing Mode</li> </ul>			

<u>Step 2</u> Configure backlight parameters.



Backlight mode	Description		
Auto	The system adjusts image brightness according to ambient lighting condition automatically to ensure image clarity.		
	Enable BLC, the camera can get clearer image of the dark areas on the target when shooting against light. You can select <b>Default</b> mode or <b>Customized</b> mode.		
	• When in <b>Default</b> mode, the system adjusts exposure according to		
BLC	ambient lighting condition automatically to ensure the clarity of the darkest area.		
	• When in <b>Customized</b> mode, the system auto adjusts exposure only		
	to the set area according to ambient lighting condition to ensure		
	the image of the set area at ideal brightness.		
WDR	The system dims bright areas and compensates dark areas to ensure the clarity of all the area. The higher the value is, the brighter the dark will be, but the more the noise will be.		
	Lu There might be a few seconds of video loss when the device is		
	There might be a few seconds of video loss when the device is switching to WDR mode from other mode.		
HLS	Enable HLS when extreme strong light is in the environment (such as toll station or parking lot), the camera will dim strong light, and reduce the size of Halo zone to lower the brightness of the whole image, so that the camera can capture human face or car plate detail clearly. The higher the value is, the more obvious the HLS effect will be.		
Stop 3 Click <b>Save</b>			

Table 4-10 Description of backlight parameters

Step 3 Click Save.


#### 4.5.1.1.5 WB

WB function makes the image color display precisely as it is. When in WB mode, white objects would always display white color in different environments.

#### <u>Step 1</u> Select Setting > Camera > Conditions > WB.

Figure 4-37 WB

	Profile Day	-
▶ Picture	Mode Auto	•
▶ Exposure	nous nate	
▶ Backlight		
▶ WB		
► Day & Night		
► Illuminator		
Image Correction		
<ul> <li>Splicing Mode</li> </ul>		





Description
The system compensates WB according to color temperature to ensure color precision.
The system auto compensates WB to environments without artificial light to ensure color precision.
The system compensates WB to outdoor night scene to ensure color precision.
The system auto compensates WB to most outdoor environments with natural or artificial light to ensure color precision.
Configure red and blue gain manually; the system auto compensates WB according to color temperature.
The system compensates WB only to the set area according to color temperature to ensure color precision.

Step 3 Click Save.

### 4.5.1.1.6 Day & Night

Configure the display mode of the image. The system switches between color and black-and-white mode according to the actual condition.

#### <u>Step 1</u> Select Setting > Camera > Conditions > Conditions > Day & Night.

	Profile	Day	•
<ul> <li>Picture</li> </ul>	Mode	Auto	•
Exposure	Sensitivity	Medium	•
<ul> <li>Backlight</li> </ul>	Delay	6s	•
▶ WB			
▶ Day & Night			
Illuminator			
Image Correction			
<ul> <li>Splicing Mode</li> </ul>			

Figure 4-38 Day and night

<u>Step 2</u> Configure day and night parameters.



Description		
<ul> <li>You can select device display mode from Color, Auto, and B/W.</li> <li>Day &amp; Night configuration is independent from profile management configuration.</li> <li>Color: The system displays color image.</li> <li>Auto: The system switches between color and black-and-white displays color image.</li> </ul>		
<ul> <li>display according to the actual condition.</li> <li>B/W: The system displays black-and-white image.</li> </ul>		
This configuration is available only when you set <b>Auto</b> in <b>Mode</b> . You can configure camera sensitivity when switching between color and black-and-white mode.		
This configuration is available only when you set <b>Auto</b> in <b>Mode</b> . You can configure the delay when camera switching between color and black-and-white mode. The lower the value is, the faster the camera switches between color and black-and-white mode.		

Table 4-12 Description of day and night parameters

Step 3 Click Save.

#### 4.5.1.1.7 Zoom and Focus

Initialize lens to adjust zoom and focus. Only PTZ camera supports lens initialization.

#### <u>Step 1</u> Select Setting > Camera > Conditions > Conditions > ZoomFocus.

Figure 4-39 Zoom and focus

	Profile Day	/	~
Picture	Mode Mar	nuat	~
<ul> <li>Exposure</li> </ul>	NearLight -	-0-	+ 50
▶ Backlight	FarLight 🗐	)	+ 0
⊧ WB		54	
► Day & Night			
ZoomFocus			
<ul> <li>Illuminator</li> </ul>			
+ Defog			

<u>Step 2</u> Configure zoom and focus parameters.

Parameter	Description
Digital Zoom	Select <b>On</b> to enable digital zoom function. After the optical zoom reached the upper limit, enable digital zoom function, you still can do digital zoom operation.



Parameter	Description		
Zoom Speed	Adjusts zoom speed. The higher the value is, the higher the speed will be.		
Mode	<ul> <li>Sets focus mode.</li> <li>Auto: When image moves or object changes in the scene, the camera will focus automatically.</li> <li>Semi Auto: Click - or + corresponding to Focus or Zoom, the camera will focus. Calling preset, positioning accurately or rotating PTZ also will trigger focus.</li> <li>Manual: Click - or + corresponding to Focus to adjust the focus.</li> </ul>		
Focus Limit	When the focus length is too short, the camera will focus on the dome cover. Sets the shortest focus distance to avoid focusing on the dome cover. You can also change the focus speed by changing focus length.		
Sensitivity	The sensitivity of triggering focus. The higher the value is, the easier the focus will be triggered.		

Step 3 Click Save.


 $\square$ 

Click Lens Initialization, the lens will adjust the zoom and focus parameters.

#### 4.5.1.1.8 Illuminator

This configuration is available only when the device is equipped with illuminator.Step 1Select Setting > Camera > Conditions > Conditions > Illuminator.

Figure 4-40 Illuminator







Illuminator         Fill Light         Manual         Auto         Smart I         Mode		Description
Auto Smart I Mode		<ul> <li>Set Fill Light for sound and siren cameras.</li> <li>IR Mode: Enable the IR illuminator, and the white light is disabled.</li> <li>White Light: Enable the white light, and the IR illuminator is disabled.</li> <li>Smart illumination. They system will switch the illuminators according to the actual condition. When the ambient light reaches the threshold of IR illuminator, the IR illuminator is enabled. The white light is enabled when the target appears in surveillance area, disabled when the target is out of the surveillance area, and then the IR illuminator is enabled according to the ambient light.</li> <li>When selecting Smart Illumination as Fill Light, you need to set the illuminator delay. It is 60 seconds by default, and the range is 30–300 seconds.</li> </ul>
Smart I Mode		Adjust the brightness of illuminator manually, and then the system will supply illuminator to the image accordingly.
	2	The system adjusts the illuminator intensity according to the ambient lighting condition.
ZoomP	rio	<ul> <li>The system adjusts the illuminator intensity automatically according to the change of the ambient light.</li> <li>When the ambient light turns darker, the system turns on the low beam lights first, if the brightness is still not enough, it turns on the high beam lights then.</li> <li>When the ambient light turns brighter, the system dims high beam lights until they are off, and then the low beam lights.</li> <li>When the focus reaches certain wide angle, the system will not turn on high beam light in order to avoid over-exposure in short distance. In the meantime, you can configure light compensation manually to fine-tune IR light intensity.</li> </ul>
Off		Illuminator is off.

#### Table 4-14 Description of illuminator parameters

#### 4.5.1.1.9 Defog

The image quality is compromised in foggy or hazy environment, and defog can be used to improve



image clarity.

```
<u>Step 1</u> Select Setting > Camera > Conditions > Conditions > Defog.
```

Figure 4-41 Defog

	Profile	Day	-
▶ Picture	Mode	Off	•
▶ Exposure	mode	011	
<ul> <li>Backlight</li> </ul>			
▶ WB			
Day & Night			
<ul> <li>Illuminator</li> </ul>			
► Defog			

#### <u>Step 2</u> Configure defog parameters.

Table 4-15 Description of defog parameters

Defog	Description	
Manual	Configure function intensity and atmospheric light mode manually, and then the system adjusts image clarity accordingly. Atmospheric light mode can be adjusted automatically or manually.	
Auto	Auto The system adjusts image clarity according to the actual condition.	
Off	Defog function is disabled.	

Step 3 Click Save.

#### 4.5.1.1.10 Fisheye

Select install mode and record mode according to the actual installation scene. When the camera accesses the platform with corrective stream, the platform displays the corrective image.



This function is only available on fisheye device.

```
<u>Step 1</u> Select Setting > Camera > Conditions > Conditions > Fisheye.
```

Figure 4-42 Fisheye

	Profile	Day	•
Picture	Install Mode	Ceiling	•
<ul> <li>Exposure</li> </ul>			
<ul> <li>Backlight</li> </ul>			
▶ WB			
► Day & Night			
► Illuminator			
▶ Fisheye			

<u>Step 2</u> Set install mode and record mode.



Parameter	Description		
Install Mode	You can select <b>Ceiling</b> , <b>Wall</b> , or <b>Ground</b> .		
Install Mode Record Mode	<ul> <li>10: The original image before correction.</li> <li>1P: 360° rectangular panoramic image.</li> <li>2P: When the install mode is <b>Ceiling</b> or <b>Ground</b>, you can set this mode. Two associated 180° rectangular image screens, and at any time, the two screens form a 360° panoramic image.</li> <li>1R: Original image screen + independent sub-screen. You can zoom or drag the image in all the screens.</li> <li>2R: Original image screen + two independent sub-screens. You can zoom or drag the image in all the screens.</li> <li>4R: Original image screen + four independent sub-screens. You can zoom or drag the image in all the screens.</li> <li>10 + 3R: Original image screen + three independent sub-screens.</li> </ul>		
	You can zoom or drag the image in original image screen, and move the image (upper and lower) in sub-screens to adjust the vertical view.		


Table 4-16 Description of fisheye parameters

Step 3 Click Save.

#### 4.5.1.1.11 Image Correction

Enable the image correction function to correct some bent objects (such as roads) in the image of panoramic splicing cameras, but it will influence the field of view.

#### Figure 4-43 Image correction



 $\square$ 

- If the camera has multiple sensors, the image correction function will only displayed when the number of splicing sensors is 4 or less.
- When the device enables image correction, intelligent event and sub stream 2 are closed automatically.



### 4.5.1.1.12 Splicing Mode

Select the splicing mode to splice several images of different lens to a panoramic image. You can select **Merged Splicing** or **Splicing** for **Mode**.

Figure 4-44 Splicing mode

	Profile	Day	•
▶ Picture	Mode	Merged Splicing	•
Exposure			
<ul> <li>Backlight</li> </ul>			
▶ WB			
► Day & Night			
<ul> <li>Illuminator</li> </ul>			
Image Correction			
▶ Splicing Mode			

# 4.5.1.2 Profile Management

The surveillance system works in different ways as profile configured in different time.

# <u>Step 1</u> Select Setting > Camera > Conditions > Profile Management.

The **Profile Management** interface is displayed.

- Step 2 Manage profile.
  - When **Profile Management** is set as **General**, the surveillance system works under **General** configuration.

Figure 4-45 General				
Conditions P	rofile Managemen	Zoom and Foc	us	
Profile Managemen	t 💿 General 🔿 Fu	ll Time 🔘 Schedu	le 🔿 Day/Night	
	Default	Refresh	Save	

• When **Profile Management** is set as **Full Time**, you can select **Day** or **Night** in the **Always Enable** list, the surveillance system works under **Always Enable** configuration.



Figure 4-46 Full time				
Conditions Pro	ofile Managemer	T Zoom and Foc	us	
Profile Management Always Enable	○ General ● Fu Day	ull Time 🕥 Schedu	le 🕥 Day/Night	
	Default	Refresh	Save	

When Profile Management is set as Schedule, you can drag the slide block to set • certain time as Day or Night. For example, set 8:00–18:00 as day, and 0:00–8:00 and 18:00-24:00 as night.

Figure 4-47 Schedule

Coedmnns	Protile Manageme	ant Zoom an					
Profile Manage		Full Time 💩 S	ichedule 🔿 I	22/Migth			
Period setting							- 0
	0.00	4:00	8:00	12:00	16.00	20:00	24:00
	🧧 Day 🗰 M	pht					
	Dyfailt	Ratrach		sava			

• When Profile Management is set as Day & Night, the surveillance system works under Day & Night configuration.

Figure 4-48 Day/Night				
(	Conditions	Profile Managemen	t Zoom and Foc	us
	Profile Managem	ent 🔘 General 🔘 Fu	- Ill Time 🔘 Schedul	le 🖲 Day/Night
		Default	Refresh	Save



### 4.5.1.3 Zoom and Focus

You can adjust image clarity through auto or manual focus; and adjust the image size through zoom. For details, see "4.2.4.2 Zoom and Focus".

# 4.5.1.4 Splicing

When the panorama contains multiple images captured by different lenses, enable this function. Before splicing, make sure that the surveillance scene is large and there are no objects blocking the



camera from taking a clear picture, otherwise, the splicing might fail.

<u>Step 1</u> Select Setting > Camera > Conditions > Splicing.

Figure 4-49 Splicing



<u>Step 2</u> Select the lenses that need to be spliced.

When splicing the image through selecting lenses, you need to select the continuous splicing screens. The screen with the icon 🧖 (deeper color) is the first screen of the splicing. You can select any screen as the first one, and then select the following screens continuously. The system supports the splicing of 2 lenses to 8 lenses.

 $\square$ 

- This function is available on select models. And it is all sensors splicing by default.
- For Multi-Sensor Panoramic + PTZ Camera, the 4-sensor device supports 2 to 4 lenses splicing; the 6-sensor device supports 2 to 6 lenses splicing; the 8-sensor device supports 2-8 lenses splicing.

#### Step 3 Click Start.

The system starts to splice the image.

- Some cameras restart automatically after splicing is complete, You can view the results of the splicing in the **Live** window.
- Some cameras display splicing live window after splicing is complete. Click **OK**, and then the default window appears. Click **OK** and the splicing will take effect.

# 4.5.2 Setting Video Parameters

This section introduces video parameters, such as video, snapshot, overlay, ROI (region of interest), and path.

 $\square$ 

Click **Default**, and the device is restored to default configuration. Click **Refresh** to view the latest configuration.

# 4.5.2.1 Video

Configure video stream parameters, such as stream type, encode mode, resolution, frame rate, bit rate type, bit rate, I frame interval, SVC, and watermark.

<u>Step 1</u> Select Setting > Camera > Video > Video.



Mass Streets			SLO: Stream		
			2 Exercit	Sub Stream 1	
E eroes Mode	H.201	•	Emple Node	H 266	(+)
Encoding Situation	Al Codec		Recoldon	784/576(D1)	
Republic	384012168(3848+2168)		Frame Rate(FPS)	38	
Previo Makements	24	•	Bit Rate Type	CBR	•
HIE FORD TYDE	CBH		Reference \$8 Plate	(55-120066/5	
Reference Bit Role	1441-6182/0/8		nenate	512	00070
#ERate	Customized	•	1 Piorna Montar	48	(229-7993)
	3072	(3-8162) (93/6)	Shoan Schooly	E	
(Frame Interval	48				
Webrensch Gelfings					
Webernert Chanada	Digital COTV	10			
TRAFT TRAFT	0-0-1	-1 40			

<u>Step 2</u> Configure video parameters.

Parameter	Description
Enable	<ul> <li>Select the <b>Enable</b> checkbox to enable sub stream. It is enabled by default.</li> <li>You can enable multiple sub streams simultaneously.</li> <li>When the device enables image correction, intelligent event and sub stream 2 are closed automatically.</li> </ul>
Encode Mode	<ul> <li>Select encode mode.</li> <li>H.264: Main profile encode mode. Compared with H.264B, it requires smaller bandwidth.</li> <li>H.264H: High profile encode mode. Compared with H.264, it requires smaller bandwidth.</li> <li>H.264B: Baseline profile encode mode. It requires smaller bandwidth.</li> <li>H.265: Main profile encode mode. Compared with H.264, it requires smaller bandwidth.</li> <li>MJPEG: When under this mode, the image requires high bit rate value to ensure clarity, you are recommended to set the Bit Rate value to the biggest value in the Reference Bit Rate.</li> </ul>

Table 4-17 Description of video parameters



Parameter	Description
Encoding Strategy	<ul> <li>Select the encoding strategy as needed.</li> <li>General: Disable smart codec.</li> <li>Smart Codec: Enable smart codec to improve video compressibility and save storage space. It is applicable to static scenes.</li> <li>Al Code: When the bandwidth and storage space are restricted, the camera will select the encoding strategy with lower bit rate to save storage space. It is applicable to dynamic scenes.</li> <li>After Al codec is enabled, <b>Bit Rate Type</b> is <b>CBR</b>, and it cannot be changed. Comparing with general mode, Al codec has lower bite rate. This function is only available on cameras with Al functions.</li> </ul>
	After smart codec and AI codec are enabled, the camera would stop supporting the third stream, ROI, and smart event detection, and the actual interface shall prevail.
Resolution	The resolution of the video. The higher the value is, the clearer the image will be, but the bigger the bandwidth will be required.
Video Clip	<ul> <li>This function is available only for sub stream 2 of some select models.</li> <li>Main stream <ol> <li>Select the resolution as needed, and click in next to</li> <li>Resolution.</li> <li>The Area interface is displayed.</li> </ol> </li> <li>Clip the image on the Area interface, and then click Save.</li> <li>View the clipped video on Live interface.</li> <li>Sub stream 2 <ol> <li>Select Video Clip, and click is.</li> <li>The Area interface is displayed.</li> </ol> </li> <li>View the clipped video on Live interface.</li> </ul>
Frame Rate (FPS)	The number of frame in one second of video. The higher the value is, the clearer and smoother the video will be.
Bit Rate Type	<ul> <li>The bit rate control type during video data transmission. You can select bit rate type from:</li> <li>CBR (Constant Bit Rate): The bit rate changes a little and keeps close to the defined bit rate value.</li> <li>VBR (Variable Bit Rate): The bit rate changes as monitoring scene changes.</li> <li>The Bit Rate Type can be only be set as CBR when Encode Mode is set as MJPEG.</li> </ul>
Quality	This parameter can be configured only when the <b>Bit Rate Type</b> is set as <b>VBR</b> . The better the quality is, the larger the bandwidth will be requested.



Parameter	Description
Reference Bit Rate	The most suitable bit rate value range recommended to user according to the defined resolution and frame rate.
Max Bit Rate	This parameter can be configured only when the <b>Bit Rate Type</b> is set as <b>VBR</b> .
	You can select the value of the <b>Max Bit Rate</b> according to the <b>Reference Bit Rate</b> value. The bit rate then changes as monitoring scene changes, but the max bit rate keeps close to the defined value.
	This parameter can be configured only when the <b>Bit Rate Type</b> is set as <b>CBR</b> .
Bit Rate	Select bit rate value in the list according to actual condition. You can also customize the value.
	This parameter can be configured only when <b>Encoding Strategy</b> is set as <b>General</b> or <b>AI Codec</b> .
l Frame Interval	The number of P frames between two I frames. The smaller the value, the higher the image quality, and the range changes as <b>Frame</b> <b>Rate(FPS)</b> changes. It is recommended to set <b>I Frame Interval</b> twice as big as <b>Frame Rate(FPS)</b> .
	When selecting <b>AI Codec</b> in <b>Encoding Strategy</b> , you can only select the value same as or twice as big as <b>Frame Rate(FPS)</b> .
SVC	Scaled video coding, able to encode a high quality video bit stream that contains one or more subset bit streams. When sending stream, to improve fluency, the system will quit some data of related lays according to the network status.
	<ul> <li>1: The default value, which means that there is no layered coding.</li> <li>2, 3 and 4: The lay number that the video stream is packed.</li> </ul>
Watermark Settings	You can verify the watermark to check if the video has been tampered.
Watermark Character	<ol> <li>Select the checkbox to enable watermark function.</li> <li>The default character is DigitalCCTV.</li> </ol>
	Click 🖃, 🖽 or drag 🕕 to set the value of <b>Stream Smooth</b> .
Stream Smooth	The higher the value is, the less smooth the stream, but the higher the image definition; the lower the value is, the more smooth the stream, but the lower the image definition.
	The value of <b>Stream Smooth</b> is 100 by default.

Step 3 Click Save.

# 4.5.2.2 Snapshot

You can configure snapshot parameters, including snapshot type, image size, quality and interval. <u>Step 1</u> Select **Setting > Camera > Video > Snapshot**.



Figure 4-51 Snapshot

V988	Shapehot	(Deirlie	101	4/14/	a
Deansteel Type -	General	•			
inigi Ska	10007-11007-0000				
Quarter .	10	* C			
inenal	18				
	Dehul	inter [ 1	-		

<u>Step 2</u> Configure snapshot parameters.

Parameter	Description			
Snapshot Type	<ul> <li>You can select General and Event.</li> <li>General: The system takes snapshot as scheduled. For details, see "4.7.2 Setting Schedule".</li> <li>Event: The system takes snapshot when the video detection, audio detection, event, or alarm is triggered. This function requires the corresponding snapshot being enabled.</li> </ul>			
Image Size	The same resolution with main stream.			
Quality	Configures the snapshot quality. There are six levels of Image quality, and the sixth is the best.			
Interval	Configures the snapshot frequency. Select <b>Customized</b> , and then you can configure snapshot frequency manually.			

Table 4-18 Description of snapshot parameter

Step 3 Click Save.

## 4.5.2.3 Overlay

Configure overlay information, and it will be displayed on the **Live** interface.

## 4.5.2.3.1 Configuring Privacy Masking

You can enable this function when you need to protect privacy of some area on the video image.

## $\square$

Functions might vary with different models.

## Privacy Masking (1)

<u>Step 1</u> Select Setting > Camera > Video > Overlay > Privacy Masking.



## Figure 4-52 Privacy masking (1)



#### Figure 4-53 Privacy masking (PTZ dome)

	Channel	PTZ Camar	1	
Image: select intervention       Image: select intervention         Image: select intervention       Image: select in	<ul> <li>Chasses Title</li> <li>Chasses Title</li> <li>Chasses Title</li> <li>Chasses Title</li> <li>Chasses Title</li> <li>Chasses Title</li> <li>Phone Chastes</li> <li>Phone Chastes</li></ul>	D24	1.	A GOD

#### <u>Step 2</u> Configure privacy masking.

- PTZ dome
  - 1. Select the SN.
  - 2. Adjust the live image to the proper location through PTZ, select the color, and then click **Draw**. Press the mouse button to draw rectangles. The configuration takes effect immediately.
  - 3. Other operations:
    - $\diamond$  Select the SN, and click **Go to**, the speed dome rotates to the masked area.
    - ♦ Select the SN, and click **Delete** to delete the masking rectangles.
    - ♦ Click **Clear**, and the click **OK** to clear all masking rectangles.



• Other cameras

1. Select **Enable**, and then drag the block to the area that you need to cover.


Ш

- You can drag 4 rectangles at most.
- Click Remove All to delete all the area boxes; select one box, and then click
   Delete or right-click to delete it.
- 2. Adjust the size of the rectangle to protect the privacy.
- 3. Click Save.

## Privacy Masking (2)

You can select the type of the masking from **Color Lump** and **Mosaic**.

- When selecting **Color Lump** only, you can draw triangles and convex quadrilaterals as blocks. You can drag 8 blocks at most, and the color is black.
- When selecting **Mosaic**, you can draw rectangles as blocks with mosaic. You can draw 4 blocks at most.
- **Color Lump** + **Mosaic** (<4): You can draw 8 blocks at most.
- <u>Step 1</u> Select Setting > Camera > Video > Overlay > Privacy Masking.
- Step 2 Select Enable.
- <u>Step 3</u> Click **Add**, select the masking type, and then draw blocks in image as needed.



## **Related Operations**

• View and edit the block

Select the privacy masking rule to be edited in the list, then the rule is highlighted, and the block frame is displayed in the image. You can edit the selected block as needed, including moving the position, and adjusting the size.

- Edit the block name Double-click the name in **Name** to edit the block name.
- Delete the block
  - Click to delete blocks one by one.
  - Click Clear to delete all blocks.



## 4.5.2.3.2 Configuring Channel Title

You can enable this function when you need to display channel title in the video image. <u>Step 1</u> Select **Setting** > **Camera** > **Video** > **Overlay** > **Channel Title**.

Figure 4-55 Channel title



- <u>Step 2</u> Select the **Enable** checkbox, enter the channel title, and then select the text align.
  - $\square$
  - Click 🐈 to expand the channel title, and you can expand 1 line at most.
- <u>Step 3</u> Move the title box to the position that you want in the image.
- Step 4 Click Save.

#### 4.5.2.3.3 Configuring Time Title

You can enable this function when you need to display time in the video image.

<u>Step 1</u> Select Setting > Camera > Video > Overlay > Time Title.





- <u>Step 2</u> Select the **Enable** checkbox.
- <u>Step 3</u> Select the **Week Display** checkbox.
- <u>Step 4</u> Move the time box to the position that you want in the image.
- Step 5 Click Save.

### 4.5.2.3.4 Configure Text Overlay

You can enable this function if you need to display text in the video image.

 $\square$ 

Text overlay and picture overlay cannot work at the same time, and the IPC that connects to mobile NVR with private protocol would display GPS information as priority.

```
<u>Step 1</u> Select Setting > Camera > Video > Overlay > Text Overlay.
```



Step 2 Select the **Enable** checkbox, enter the text you need, and then select alignment. The text is

displayed in the video image.

	Click 🕂 to expand the text overlay, and you can expand 9 lines at most.
<u>Step 3</u>	Move the text box to the position that you want in the image.
Step 4	Click <b>Save</b> .

### 4.5.2.3.5 Configure Font Attribute

You can enable this function if you need to adjust the font size in the video image. <u>Step 1</u> Select **Setting > Camera > Video > Overlay > Font Attribute**.

Ideo Snapohot Overlay ROI	Patti		_		
	Privacy Basting     Channel Title     Time Dis     Time Dis     Time Dis     Toot Channel     Polyre Overlay     Caston Overlay     Pessee Count.     Foce Battotice	Conv Port Sun 48°43	6	•	1

- Step 2Select the font color and size.Click More Color to customize the font color.
- Step 3 Click Save.

#### 4.5.2.3.6 Configure Picture Overlay


You can enable this function if you need to display picture information on the video image.

 $\square$ 

Text overlay and picture overlay cannot work at the same time.

<u>Step 1</u> Select Setting > Camera > Video > Overlay > Picture Overlay.





<u>Step 2</u> Select the **Enable** checkbox, click **Upload Picture**, and then select the picture to be overlaid.


The picture is displayed on the video image.

- <u>Step 3</u> Move the overlaid picture to the position that you want in the image.
- Step 4 Click Save.

#### 4.5.2.3.7 Configure Custom Overlay

You can enable this function if you need to display custom information on the video image.

<u>Step 1</u> Select Setting > Camera > Video > Overlay > Custom Overlay.



<u>Step 2</u> Select the **Enable** checkbox, and then select the text align.

- Click F to expand the custom overlay, and you can expand 1 line at most. Move the custom box to the position that you want in the image.
- Step 4 Click Save.

Step 3



## 4.5.2.3.8 Configuring OSD Info

You can enable this function if you want to display the information of preset, PTZ coordinates, zoom, tour and location on the video image.



Only tracking speed dome supports OSD info function.

<u>Step 1</u> Select Setting > Camera > Video > Overlay > OSD Info.

Figure 4-61 OSD information Overtay 900 Е Patt + Daniel - Privacy Mas Ince Sec. Nots TIME - Betaut 1.644 THEARD Right •

<u>Step 2</u> Configure OSD information.

#### Table 4-19 Description of OSD information

Parameter	Description			
Preset	Select <b>Enable</b> , and the preset name is displayed in the image when the camera turns to the preset, and it will disappear 3 s later.			
Temperature	Select <b>Enable</b> and the internal temperature of the current device is displayed.			
Coordinates	Select <b>Enable</b> and the PTZ coordinates info is displayed in the image.			
Zoom	Select <b>Enable</b> and the zoom info is displayed in the image. such as P 89 4 T 126 T 12, which means 12x zoom rate.			
North	Select <b>Enable</b> and the north direction is displayed in the image.			
RS485	Select <b>Enable</b> and it will enable RS-485 communication function.			
Text				
Input Text	Select <b>Enable</b> and set text, and the text is displayed in the image.			
Text Align	Alignment mode of the displayed information in the image.			
Step 3 Move the OSD	box to the position that you want in the image.			

Step 4 Click Save.




## 4.5.2.3.9 Configuring Counting

The image displays statistics of the enter number and leave number. When the overlay function is enabled during intelligent rules configuration, this function is enabled simultaneously.

<u>Step 1</u> Select Setting > Camera > Video > Overlay > Counting.

Figure 4-62 Counting



<u>Step 2</u> Select the **Enable** checkbox, and then configure counting method and alignment.


<u>Step 3</u> Move the counting box to the position that you want in the image.

Step 4 Click Save.

### 4.5.2.3.10 Configuring Structured Statistics

The image displays structured statistics. When the overlay function enabled during intelligent rules configuration, this function is enabled simultaneously.

```
<u>Step 1</u> Select Setting > Camera > Video > Overlay > Structured Statistics.
```



<u>Step 2</u> Select the **Enable** checkbox, select the statistics type, and then select text align.

<u>Step 3</u> Move the structured statistics box to the position that you want in the image.



Step 4 Click Save.

### 4.5.2.3.11 Configuring GPS Position

The image displays GPS position. When the overlay function enabled during intelligent rules configuration, this function is enabled simultaneously.

#### <u>Step 1</u> Select Setting > Camera > Video > Overlay > GDP Position.

Figure 4-64 GDP position



<u>Step 2</u> Select the **Enable** checkbox, and then select the **Mode** to **Auto** or **Manual**.

- Auto: The GPS positions the longitude and latitude automatically.
- Manual: Enter the longitude and latitude manually.
- <u>Step 3</u> Move GPS position box to the position that you want in the image.
- Step 4 Click Save.

### 4.5.2.3.12 Configuring Ranging

Configure camera height and the display time of overlay information. Click any point on the ground that the pole is installed on the image, and the overlay information between camera and the selected point is displayed.

<u>Step 1</u> Select Setting > Camera > Video > Overlay > Ranging.






Step 2Select the **Enable** checkbox, and then set the installation height and time display.Time display: The display time of the ranging information on live image.

Step 3 Click Save.

## 4.5.2.3.13 Configuring ANPR

The image displays ANPR statistics information. When the overlay function enabled during intelligent rules configuration, this function is enabled simultaneously.

<u>Step 1</u> Select **Setting > Camera > Video > Overlay > ANPR**.



<u>Step 2</u> Select the **Enable** checkbox, select the statistics type, and then select text align.

- <u>Step 3</u> Move the ANPR box to the position that you want in the image.
- Step 4 Click Save.



## 4.5.2.3.14 Configuring Face Statistics

The image displays face statistics information. When the overlay function enabled during intelligent rules configuration, this function is enabled simultaneously.

<u>Step 1</u> Select Setting > Camera > Video > Overlay > Face Statistics.




- <u>Step 2</u> Select the **Enable** checkbox, and select text align.
- <u>Step 3</u> Move the structured statistics box to the position that you want in the image.
- Step 4 Click Save.

## 4.5.2.4 ROI

Select ROI (region of interest) on the image and configure the image quality of ROI, and then the selected image is display at defined quality.

<u>Step 1</u> Select **Setting** > **Camera** > **Video** > **ROI**.





<u>Step 2</u> Select the **Enable** checkbox, draw the area on the image, and then configure the image quality of ROI.

 $\prod$ 

- You can draw four area boxes at most. •
- The higher the image quality value is, the better the quality will be. ٠
- Click Remove All to delete all the area boxes; select one box, and then click Delete or • right-click to delete it.

Step 3 Click Save.

## 4.5.2.5 Path

You can configure the storage path for live snapshot, live record, playback snapshot, playback download, and video clips.

Select Setting > Camera > Video > Path. <u>Step 1</u>

#### Figure 4-69 Path

-Video	Cryspeties	Overan .	Path	- <u>8</u>	ŝ
in man	C.C.S.Samueleskii/Add	DisrokaNitedespatiet		[	
(mu Kiolah)	C. 6. New substrate the bit (how deared), he block on all			ET antesis	
Planet braver it	C.A. Serre and the Web Devente add Philadeach Triagging			Dentaria	
Pietosch Denmined	C Charried and Web Conner Preparative and			fit to the	
sideo Class	C Line and Web	Drverke Midso Cilja		Description of the local division of the loc	



Click Browse to select the storage path for live snapshot, live record, playback snapshot, playback download, and video clips.



Parameter	Description	
Live Snapshot	The snapshot of live interface. The default path is C:\Users\admin\WebDownload\LiveSnapsh ot.	
Live Record	The recorded video of live interface. The default path is C:\Users\admin\WebDownload\LiveRecord.	
Playback Snapshot	The snapshot of playback interface. The default path is C:\Users\admin\WebDownload\PlaybackSn apshot.	Admin in the path refers to the account being used.
Playback Download	The downloaded video of playback interface. The default path is C:\Users\admin\WebDownload\PlaybackRe cord.	
Video Clips	The clipped video of playback interface. The default path is C:\Users\admin\WebDownload\VideoClips.	

Table 4-20 Description of path

Step 3 Click Save.

## 4.5.3 Audio

You can configure audio parameters and alarm audio.

## 4.5.3.1 Configuring Audio Parameter

This section introduces audio parameters, including encode mode, sampling frequency, audio in type, and noise filter.

<u>Step 1</u> Select **Setting > Camera > Audio > Audio**.



Figure 4-70 Audio

D-mith)				
Stars Mount				
2 TRAFFE				
Excess Note:	6.71tA	3		
Samoly (Pressence	194	4		
Sad Dream				
Ex100	Sub-Stream 1	+		
-Execute Month	G.711A	+		
Swedenstreamers	19	•		
ana -				
	Linell	-		
	Evele.	2		
Miranine a Velume	E-0-			
	and the second se			
Tatata made	a ()	-E *		

#### <u>Step 2</u> Select the **Enable** checkbox in **Main Stream** or **Sub Stream**.

For the camera with multiple channels, select the channel number.

# $\wedge$

Please carefully activate the audio acquisition function according to the actual requirements of the application scenario.

<u>Step 3</u> Configure audio parameters.

Parameter	Description
Encode Mode	You can select audio <b>Encode Mode</b> from <b>G.711A</b> , <b>G.711Mu</b> , <b>AAC</b> , <b>G.726</b> .
Encode mode	The configured audio encode mode applies to both audio and intercom. The default value is recommended.
Sampling Frequency	Sampling number per second. The higher the sampling frequency is, the more the sample in a second will be, and the more accurate the restored signal will be. You can select audio <b>Sampling Frequency</b> from <b>8K</b> , <b>16K</b> , <b>32K</b> , <b>48K</b> , <b>64K</b> .
	You can select audioin type from:
Audioin Type	Linein: Requires external audio device.
	Mic: Not require external audio device.
Noise Filter	Enable this function, and the system auto filters ambient noise.
Microphone Volume	Adjusts microphone volume.
Speaker Volume	Adjusts speaker volume.

Step 4 Click Save.

## 4.5.3.2 Configuring Alarm Audio

You can record or upload alarm audio file. The audio file will be played when the alarm is triggered.

• Click **O** to play the selected audio.




• Click 👱 to download the audio to local storage.

#### <u>Step 1</u> Select **Setting > Camera > Audio > Alarm Audio**.

Astal Ala	rm Astrip				
Dente	a desta la	and they	Desethad	Linte	Table .
	alarent acces	0	*		
	manyer pint		*		





Add Audio F	File	×
Record	O Upload	
Audio File	.pcm	
	Record	

<u>Step 3</u> Configure the audio file.

- Select **Record**, enter the audio name in the input box, and then click **Record**.
- Select **Upload**, click 📄 to select the audio file to be uploaded, and then click **Upload**.

#### $\square$

The camera supports audio file with .pcm format only, and you can upload audio files with .pcm or .wav2 formats.

<u>Step 4</u> Select the file that you need.

# 4.6 Network

This section introduces network configuration.

## 4.6.1 TCP/IP

You can configure IP address and DNS (Domain Name System) server and so on according to network planning.

## Prerequisites

The camera has connected to the network.

### Procedure

<u>Step 1</u> Select **Setting > Network > TCP/IP**.



lost Name	IPC			1	
				1	
Ethernet Card	Wire(	DEFAU	LT)		Set as Default
lode	<ul> <li>State</li> </ul>	atic C	DHCP		
IAC Address			1	hr.	E. =
P Version	IPv4			•	
P Address	100 Million	100	1	Béi [	
Subnet mask	200	1986	-14	10	
Default Gateway	-	12	1	1	
Preferred DNS Server	-				
lternate DNS Server		-	ili.	ni	
Enable ARP/Ping to s	et IP ad	dress s	ervice		

## Step 2 Configure TCP/IP parameters.

Table 4-22 Description of TCP/IP para	meters

Parameter	Description		
Host Name	Enter the host name, and the maximum length is 15 characters.		
Ethernet Card	Select the Ethernet card that need to be configured, and the default one is <b>Wire</b> .		
	The mode that the camera gets IP:		
	Static		
	Configure IP Address, Subnet Mask, and Default Gateway		
Mode	manually, and then click <b>Save</b> , the login interface with the		
mode	configured IP address is displayed.		
	• DHCP		
	When there is DHCP server in the network, select <b>DHCP</b> , and the		
	camera acquires IP address automatically.		
MAC Address	Displays host MAC address.		
IP Version	Select IPv4 or IPv6.		
IP Address	When you select <b>Static</b> in <b>Mode</b> , enter the IP address and subnet		
Subnet Mask	mask that you need.		



Parameter	Description		
raiameter			
Default Gateway	<ul> <li>IPv6 does not have subnet mask.</li> <li>The default gateway must be in the same network segment with the IP address.</li> </ul>		
Preferred DNS	IP address of the preferred DNS.		
Alternate DNS	IP address of the alternate DNS.		
	Select the checkbox, get the camera MAC address, and then you can modify and configure the device IP address with ARP/ping command. This is enabled by default. During reboot, you will have no more than 2 minutes to configure the device IP address by a ping packet with certain length, the server will be turned off in 2 minutes, or it will be turned off immediately after the IP address is successfully configured. If this is not enabled, the IP address cannot be configured with ping packet. <b>A demonstration of configuring IP address with ARP/Ping.</b> 1. Keep the camera that needs to be configured and the PC within		
Enable ARP/Ping to set IP address service	<ol> <li>Keep the camera that needs to be configured and the PC within the same local network, and then get a usable IP address.</li> <li>Get the MAC address of the camera from device label.</li> <li>Open command editor on the PC and enter the following command.</li> <li>Windows syntax*?         <ul> <li>arp -s <ip address=""> <mac> *'</mac></ip></li> <li>ping -l 480 -t <ip address=""> *?</ip></li> <li>Windows example*?                 <ul> <li>arp -s 192.168.0.125 11-40-8c-18-10-11*'</li> <li>ping -l 480 -t 192.168.0.125*?</li> </ul> </li> </ul> </li> </ol>		
	UNIX/Linux/Mac syntax+?         arp -s <ip address=""> <mac> +?         ping -s 480 <ip address=""> +?         UNIX/Linux/Mac example+?         arp -s 192.168.0.125 11-40-8c-18-10-11+?         ping -s 480 192.168.0.125+?</ip></mac></ip>		
Step 3 Click <b>Save</b> .	<ol> <li>Restart the camera.</li> <li>Check the PC command line, if information such as <b>Reply from</b> 192.168.0.125is displayed, the configuration succeeds, and you can turn it off then.</li> <li>Enter http://(IP address) in the browser address bar to log in.</li> </ol>		

Step 3 Click Save.



## 4.6.2 Port

Configure the port numbers and the maximum number of users (includes web, platform client, and mobile phone client) that can connect to the device simultaneously.

<u>Step 1</u> Select **Setting > Network > Port**.

		Figure 4-74 Port	t		
Port					
Max Connect	ion 10			(1~20)	
TCP Port	37	777		(1025~65534)	
UDP Port	37	778		(1025~65534)	
HTTP Port	80				
RTSP Port	554	4			
RTMP Port	193	35		(1025~65534)	
HTTPS Port	44	3			
		Default	Ref	fresh	Save

<u>Step 2</u> Configure port parameters.

- $\square$
- 0-1024, 1900, 3800, 5000, 5050, 9999, 37776, 37780-37880, 39999, 42323 are occupied for specific uses.
- Do not use the same value of any other port during port configuration.

Table 4-23 Description of port parameters

Parameter Description	
Max Connection	The max number of users (web client, platform client or mobile phone client) that can connect to the device simultaneously. The value is 10 by default.
TCP Port	Transmission control protocol port. The value is 37777 by default.
UDP Port	User datagram protocol port. The value is 37778 by default.
HTTP Port	Hyper text transfer protocol port. The value is 80 by default.



Parameter	Description
RTSP Port	<ul> <li>Real time streaming protocol port, and the value is 554 by default. If you play live view with QuickTime, VLC or Blackberry smart phone, the following URL format is available.</li> <li>When the URL format requiring RTSP, you need to specify channel number and bit stream type in the URL, and also user name and password if needed.</li> <li>When playing live view with Blackberry smart phone, you need to turn off the audio, and then set the codec mode to H.264B and resolution to CIF.</li> <li>URL format example: rtsp://username:password@ip:port/cam/realmonitor?channel=1⊂ type=0</li> <li>Among that:</li> <li>Username: The user name, such as admin.</li> <li>Password: The password, such as admin.</li> <li>IP: The device IP, such as 192.168.1.112.</li> <li>Port: Leave it if the value is 554 by default.</li> <li>Channel: The channel number, which starts from 1. For example, if you are using channel 2, then the channel=2.</li> <li>Subtype: The bit stream type; 0 means main stream (Subtype=0) and 1 means sub stream (Subtype=1).</li> <li>Example: If you require the sub stream of channel 2 from a certain device, then the URL should be: rtsp://admin:admin@10.12.4.84:554/cam/realmonitor?channel=2&amp;su btype=1</li> <li>If user name and password are not needed, then the URL can be: rtsp://ip:port/cam/realmonitor?channel=1&amp;subtype=0</li> </ul>
RTMP Port	Real Time Messaging Protocol. The port that RTMP provides service. It is 1935 by default.
HTTPS Port	HTTPS communication port. It is 443 by default.
Step 3 Click Save.	

Step 3 Click Save.

The configuration of **Max Connection** takes effect immediately, and others will take effect after reboot.

# **4.6.3 PPPoE**

Point-to-Point Protocol over Ethernet, it is one of the protocols that device uses to connect to the internet. Get the PPPoE username and password from the internet service provider, and then set up network connection through PPPoE, the camera will acquire a WAN dynamic IP address.

## Prerequisites

• The camera has connected to the network.



• You have gotten the account and password from Internet Service Provider.

## Procedure

```
<u>Step 1</u> Select Setting > Network > PPPoE.
```

PPPOE		
Enable		
Username		
Password		
	4.2	

<u>Step 2</u> Select the **Enable** checkbox, and then enter user name and password.

#### $\square$

- Disable UPnP while using PPPoE to avoid possible influence.
- After making PPPoE connection, the device IP address cannot be modified through web interface

#### Step 3 Click Save.

The success prompt box is displayed, and then the real-time WAN IP address is displayed. You can visit camera through the IP address.

# 4.6.4 DDNS

Properly configure DDNS, and then the domain name on the DNS server matches your IP address and the matching relation refreshes in real time. You can always visit the camera with the same domain name no matter how the IP address changes.

### Prerequisites

Check the type of DNS server supported by the camera.

## Procedure

<u>Step 1</u> Select **Setting** > **Network** > **DDNS**.

 $\square$ 

- Third party server might collect your device information after DDNS is enabled.
- Register and log in to the DDNS website, and then you can view the information of all the connected devices in your account.



Figure 4-76 DDNS

DDNS				
(⊋) Type	NO-IP DONS	💌 Atter enabl		any server may collect your device into
Address	Optimization in a second	torn -		
Domain Name	none	test		
Usemame	none			
Password	••••			
Interval	1440	Min (7440	2880)	
	Default	Refresh	Save .	

<u>Step 2</u> Select **Type**, and configure the parameters as needed.

Table 4-24 Description of DDNS parameters

Parameter	Description			
Туре	The name and web address of the DDNS service provider, see the matching relationship below:			
	<ul> <li>CN99 DDNS web address: www.3322.org</li> </ul>			
Web Address	<ul> <li>NO-IP DDNS web address: dynupdate.no-ip.com</li> </ul>			
	Dyndns DDNS web address: members.dyndns.org			
Domain Name	The domain name you registered on the DDNS website.			
Test	Only when selecting <b>NO-IP DDNS</b> type, you can click <b>test</b> to check whether the domain name registration is successful.			
Username	Enter the username and password that you got from the DDNS server			
Password	provider. You need to register an account (includes username and password) on the DDNS server provider's website.			
Interval	The update cycle of the connection between the device and the server, and the time is 10 minutes by default.			

Step 3 Click Save.

### Result

Open the browser on PC, enter the domain name at the address bar, and then press Enter, the login interface is displayed.

# 4.6.5 SMTP (Email)

Configure email parameter and enable email linkage. The system sends email to the defined address when the corresponding alarm is triggered.

<u>Step 1</u> Select Setting > Network > SMTP (Email).



Figure 4-77 SMTP (Email)

	Figure 4-77 SIVITP (Email)
SMTP(Email)	
SMTP Server	none
Port	25
Anonymity	
Username	anonymity
Password	••••
Sender	none
Authentication	TLS
Title	IPC Message + V Attachment
Mail Receiver	+
	-
Health Mail	Update Period 30 Min.(30~1440)
	Test
	Default Refresh Save

<u>Step 2</u> Configure SMTP (Email) parameters.

Parameter	Description		
SMTP Server	SMTP server address		
Port	The port number of the SMTP server.		
Username	The account of SMTP server. For details, see Table 4-26.		
Password	The password of SMTP server.		
Anonymity	Select the checkbox, and the sender's information is not displayed in the email.		
Sender	Sender's email address.		
Authentication	Select <b>Authentication</b> from <b>None</b> , <b>SSL</b> and <b>TLS</b> .		
Title	Enter maximum 63 characters in Chinese, English, and Arabic numerals. Click 🐺 to select title type, including <b>Name</b> , <b>Device ID</b> , and <b>Event Type</b> , and you can set maximum 2 titles.		
Attachment	Select the checkbox to support attachment in the email.		
Mail Receiver	Receiver's email address. Supports 3 a	ddresses at most.	



Parameter	Description
Health Mail	The system sends test mail to check if the connection is successfully configured. Select <b>Health Mail</b> and configure the <b>Update Period</b> , and then the system sends test mail as the set interval.

For the configuration of major mailboxes, see Table 4-26.

Mailbox	SMTP server	Authentica tion	Port	Description
	smtp.qq.co	SSL	465	<ul> <li>The authentication type cannot be None.</li> <li>You need to enable SMTP service in your mailbox.</li> <li>The authentication code is required, the QQ password or email password is not applicable.</li> <li>Authentication code: The code you receive when enabling SMTP service.</li> </ul>
QQ	m	TLS	587	<ul> <li>The authentication type cannot be None.</li> <li>You need to enable SMTP service in your mailbox.</li> <li>The authentication code is required, the QQ password or email password is not applicable.</li> <li>Authentication code: The code you receive when enabling SMTP service.</li> </ul>



Mailbox	SMTP server	Authentica tion	Port	Description
		SSL	465/994	<ul> <li>You need to enable SMTP service in your mailbox.</li> <li>The authentication code is required; the email password is not applicable.</li> <li>Authentication code: the code you receive when enabling SMTP service.</li> </ul>
163	smtp.163.co m	TLS	25	<ul> <li>You need to enable SMTP service in your mailbox.</li> <li>The authentication code is required; the email password is not applicable.</li> <li>Authentication code: the code you receive when enabling SMTP service.</li> </ul>
		none	25	<ul> <li>You need to enable SMTP service in your mailbox.</li> <li>The authentication code is required; the email password is not applicable.</li> <li>Authentication code: the code you receive when enabling SMTP service.</li> </ul>
Circo	smtp.sina.co	SSL	465	
Sina	m	none	25	Enable SMTP service in your mailbox.
126 Step 3 Clic	smtp.126.co m	none	25	Enable SMTP service in your mailbox.

Step 3 Click Save.

<u>Step 4</u> Click **Test** to test whether the emails can be sent and received successfully.

# 4.6.6 UPnP

UPnP (Universal Plug and Play), a protocol that establishes mapping relation between local area and wide area networks. This function enables you to visit local area device through wide area IP address.

Prerequisites

- Make sure the UPnP service is installed in the system.
- Log in the router, and configure WAN IP address to set up internet connection.
- Enable UPnP in the router.
- Connect your device to the LAN port of the router.



 Select Setting > Network > TCP/IP, in IP Address, enter the local area IP address of the router or select DHCP and acquires IP address automatically.

## Procedure

<u>Step 1</u> Select **Setting** > **Network** > **UPnP**.

	1 70	
Figure	4-70	UFIIF

	Service Marine	Pertone	Televisit Part	Education Text	Fater	Riskity
10	HETE	WebService:TDP	1000	10.00	Vegsing Falled	1
	TUP	Predaryics 70P	3005	1000	Vacating Failed	1
10	COF.	PrideviceUDP	175	1000	Vepping Failed	1
×	HCSP	RTSFSenace TCP	-		Vegang Palent	1

<u>Step 2</u> Select the **Enable** checkbox, and there are two mapping modes: **Custom** and **Default**.

- Select **Custom**, click 💉 and then you can modify external port as needed.
- Select **Default**, and then the system finishes mapping with unoccupied port automatically, and you cannot modify mapping relation.

#### Step 3 Click Save.

Open web browser on PC, enter http:// wide area IP address: external port number, and then you can visit the local area device with corresponding port.

## 4.6.7 SNMP

SNMP (Simple Network Management Protocol) can be used to enable software such as MIB Builder and MG-SOFT MIB Browser to connect to the camera and manage and monitor the camera.

## Prerequisites

- Install SNMP monitoring and managing tools such as MIB Builder and MG-SOFT MIB Browser.
- Get the MIB file of the matched version from technical support.

## Procedure

<u>Step 1</u> Select **Setting** > **Network** > **SNMP**.



	Figure 4-79 S	NMP (1)		
SNMP				
Version	🗆 v1	🗌 v2		🗆 v3
SNMP Port	161		(1~65535)	
Read Community				
Write Community				
Trap Address				
Trap Port	162			
	Default	Re	fresh	Save

Figure 4-80 SNMP (2)

SNMP					
Version	v1	v2		🗸 v3 (Recom	nen
SNMP Port	161		(1~65535)		
Read Community					
Write Community					
Trap Address					
Trap Port	162				
Read only Lipernama					
Read-only Username					
Authentication Type	MD5	⊚ SH/	A,		
Authentication Pas			The minim	um pass phrase le	ngth is 8 characters
Encryption Type	OBC-DES				
Encryption Password			The minim	um pass phrase le	ngth is 8 characters
Read&write Userna	private				
Authentication Type	<ul> <li>MD5</li> </ul>	⊜ SH	IA		
Authentication Pas		0		um pass phrase le	ngth is 8 characters
Encryption Type	CBC-DES		1		
Encryption Password			The minimi	um pass phrase le	ngth is 8 characters
	Default	Re	fresh	Save	

<u>Step 2</u> Select SNMP version to enable SNMP.

- Select **V1**, and the system can only process information of V1 version.
- Select **V2**, and the system can only process information of V2 version.
- Select V3, and then V1 and V2 become unavailable. You can configure user name,



password and authentication type. It requires corresponding user name, password and authentication type to visit your device from the server.

 $\square$ 

Using **V1** and **V2** might cause data leakage, and **V3** is recommended.

In **Trap Address**, enter the IP address of the PC that has MIB Builder and MG-SOFT MIB Browser installed, and leave other parameters to the default.

Parameter	Description
SNMP Port	The listening port of the software agent in the device.
Read Community, Write Community	The read and write community string that the software agent supports.
Trap Address	The target address of the Trap information sent by the software agent in the device.
Trap Port	The target port of the Trap information sent by the software agent in the device.
Read-only Username	Set the read-only username accessing device, and it is <b>public</b> by default. You can enter number, letter, and underline to form the name.
Read/Write Username	Set the read/write username access device, and it is <b>public</b> by default.
Authentication Type	You can select from <b>MD5</b> and <b>SHA</b> . The default type is <b>MD5</b> .
Authentication Password	It should be no less than 8 digits.
Encryption Type	The default is CBC-DES.
Encryption Password	It should be no less than 8 digits.

Table 4-27	Description	of SNMP	parameters
------------	-------------	---------	------------

Step 3 Click Save.

### Result

View device configuration through MIB Builder or MG-SOFT MIB Browser.

- 1. Run MIB Builder and MG-SOFT MIB Browser.
- 2. Compile the two MIB files with MIB Builder.
- 3. Load the generated modules with MG-SOFT MIB Browser.
- 4. Enter the IP address of the device you need to manage in the MG-SOFT MIB Browser, and then select version to search.
- 5. Unfold all the tree lists displayed in the MG-SOFT MIB Browser, and then you can view the



configuration information, video channel amount, audio channel amount, and software version.

Ш

Use PC with Windows OS and disable SNMP Trap service. The MG-SOFT MIB Browser will display prompt when alarm is triggered.

## 4.6.8 Bonjour

Enable this function, and the OS and clients that support Bonjour would find the camera automatically. You can have quick visit to the camera with Safari browser.

 $\square$ 

Bonjour is enabled by default.

## Procedure

<u>Step 1</u> Select **Setting > Network > Bonjour**.

	Figure 4-81 Bonjo	ur	
Bonjour			
Enable			
Server Name	2F03XXXXXXXXXXX		
	Default	Refresh	Save

<u>Step 2</u> Select the **Enable** checkbox, and then configure server name.

Step 3 Click Save.

### Result

In the OS and clients that support Bonjour, follow the steps below to visit the network camera with Safari browser.

- 1. Click Show All Bookmarks in Safari.
- 2. Enable **Bonjour**. The OS or client automatically detects the network cameras with Bonjour enabled in the LAN.
- 3. Click the camera to visit the corresponding web interface.

## 4.6.9 Multicast

When multiple users are previewing the device video image simultaneously through network, it might fail due to limited bandwidth. You can solve this problem by setting up a multicast IP (224.0.1.0–238.255.255.255) for the camera and adopt the multicast protocol.

<u>Step 1</u> Select **Setting > Network > Multicast**.



#### Figure 4-82 Multicast

Their Minister.		fat Monan			
ef 2162		2 DAME	Sup Street 1		
failure + renter	221 T 2 & 1294 and add and any	(B.MIDAT NETWOOR	224 1 1	4	10+111-09-09-07-07-07
free.	49400 (7925-00008)	Pert.	490.16		1525-00500

<u>Step 2</u> Select the **Enable** checkbox, and enter IP address and port number.

Table 4-28 Description of multicast parameters

Parameter	Description
Multicast Address	The multicast IP address of <b>Main Stream/Sub Stream</b> is 224.1.2.4 by default, and the range is 224.0.0.0–239.255.255.255.
Port	The multicast port of corresponding stream: <b>Main Stream</b> : 40000; <b>Sub Stream1</b> : 40016; <b>Sub Stream2</b> : 40032, and all the range is 1025–65500.

Step 3 Click Save.

### Result

In the **Live** interface, select **RTSP** in **Multicast**, and then you can view the video image with multicast protocol.

## 4.6.10 802.1x

Cameras can connect to LAN after passing 802.1x authentication.

#### <u>Step 1</u> Select **Setting > Network > 802.1x**.

	Figure 4-83 802.1	Х	
802.1x			
Enable			
Authentication	PEAP	T.	
Username	none		
Password			
	Default	Refresh	Save

<u>Step 2</u> Select the **Enable** checkbox, and then configure parameters.

Table 4-29 Description of 802.1x parameters

Parameter	Description
Authentication	PEAP (protected EAP protocol).
Username	The user name that was authenticated on the server.
Password	Corresponding password.

Step 3 Click Save.



# 4.6.11 QoS

You can solve problems such as network delay and congestion with this function. It helps to assure bandwidth, reduce transmission delay, packet loss rate, and delay jitter to improve experience. 0–63 means 64 degrees of priority; 0 for the lowest and 63 the highest.

<u>Step 1</u> Select **Setting > Network > QoS**.

QoS			
Realtime Monitor	0	(0~63)	
Command	0	(0~63)	
	Default	Refresh	Save

<u>Step 2</u> Configure QoS parameters.

Table 4-30 Description of QoS parameters

Parameter	Description
Realtime Monitor	Configure the priority of the data packets that used for network surveillance. 0 for the lowest and 63 the highest.
Command	Configure the priority of the data packets that used for configure or checking.

Step 3 Click Save.

## 4.6.12 5G

5G configuration includes dialing configuration and mobile configuration. Install SIM card (Subscriber Identification Module) to the camera, and connect it to 5G network through dialing configuration and mobile configuration.

- Dialing configuration: Connect the camera to 5G network in a specific period.
- Mobile configuration: Configure the mobile phone to receive the linkage message. When an alarm is triggered, the system sends an alarm message to the receiver, and then the receiver can active the camera and connect it to 5G network through message or call.

## 4.6.12.1 Dialing Setting

Configure the camera to connect it to 5G network.

- <u>Step 1</u> Select Setting > Network > 5G > Dialing Setting.
- <u>Step 2</u> Select the **Enable** checkbox, and configure the parameters.



Figure 4-85 Dialing setting

Wireless Not Type	Auto	Y Finable		
APN	cmnet			
Authorize Mode	No	~		
Dial-up Number	*98*1#	- N		
Usemante				
Pasoword		••		
Interval	30	4		
Time Range	Soup			
Wireless Network 3	itate			
Dial-up Status	Online		IP Address	10.15.17.5
SIM State	Exists		Subnet Mask	Conclusion and Date
Work Mode	NR		Gateway	100 100 100 1
IMSI	ACCOUNT OF A		IMEI	arrangements.
ICCID	dimension of the second			
Wireless Signal	NR		67 %	

#### Table 4-31 Dialing setting parameters

Parameter	Description			
Wireless Net Type	Select the wireless net type according to the carrier.			
APN	Acquired from the carrier.			
Authentication Mode	Select the authentication mode according to different carrier.			
Dial-up Number	The number is different according to different carrier, and it can be acquired from carrier.			
Username	Acquired from the carrier.			
Password	Acquired from the carrier.			
Interval	It is the period beyond the dial-up period which has been configured, it is 30 s by default, during which means the camera can auto connect to 5G network. After the period is over, the camera automatically cuts off the connection to save flow.			
Time Range	The camera can connect to 5G network during the configured period. For details, see "5.1.1.1 Setting Period".			
Wireless Network State	When the dialing is successful, the wireless network status is displayed.			
Wireless Signal	When the dialing is successful, the wireless net type and signal strength are displayed.			

Step 3 Click Save.



## 4.6.12.2 Mobile Setting

Configure the mobile phone, and all alarm messages support sending message the configured receiver. After receiving a message, the receiver can active the camera and connect it to 5G network through message or call.

- Message send: Set the receiver's phone number, and when an alarm is triggered, the system will send message to the receiver.
- Message activation: Set the sender's phone number, the sender can send command message to active the camera. The commands are as following:
  - On: Make the camera online.
  - ◇ Off: Make the camera offline.
  - ◇ Reboot: Restart the camera.
- Phone activation: Set the receiver's phone number, the caller can call the camera to active the camera, and make it online.
- <u>Step 1</u> Select **Setting > Network > 5G > Mobile Setting**.

<u>Step 2</u> Select **Message send**, **Message activation**, or **Phone activation** as needed.

<u>Step 3</u> Enter the phone numbers of receiver, sender, or caller, and click 👫 to add it to the list.

- Select a phone number, and click 📃 to delete it.
- You can edit the message in **Title** during configuration.

Figure	4-86	Mobile	setting
rigare	100	moone	Security

Z Message		1000	2 Message		10.0	Phone A		-11
Receiver	16 mar in 18	+	Sender	1515.00	*	Caller	1510411 (0.444)	
		_			_			
Title	Event Message							

## 4.6.13 Access Platform

## 4.6.13.1 P2P

P2P is a private network traversal technology which enables users to manage devices easily without requiring DDNS, port mapping or transit server.

Scan the QR code with your smart phone, and then you can add and manage more devices on the



#### mobile phone client.

<u>Step 1</u>	Select Setting > Network > Access Platform > P2	2 <b>P</b>
---------------	---	------------

	Figure 4	4-87 P2P	
P2P	ONVIF	RTMP	
Enable			
Status	Offline		
S/N	4M02	10-10-0	
QR Code	Please scan the QR code on the actual interface.		
	Default	Refresh	Save

- When P2P is enabled, remote management on device is supported.
- When P2P is enabled and the device accesses to the network, the status shows online. The information of the IP address, MAC address, device name, and device SN will be collected. The collected information is for remote access only. You can cancel **Enable** selection to reject the collection.
- <u>Step 2</u> Log in to mobile phone client and tap **Device management**.
- <u>Step 3</u> Tap the + at the upper right corner.
- <u>Step 4</u> Scan the QR code on the **P2P** interface.
- <u>Step 5</u> Follow the instructions to finish the settings.

## 4.6.13.2 ONVIF

The ONVIF authentication is **On** by default, which allows the network video products (including video recording device and other recording devices) from other manufacturers to connect to your device.

 $\square$ 

ONVIF is enabled by default.

<u>Step 1</u> Select **Setting** > **Network** > **Port** > **ONVIF**.



Figure 4-88 ONVIF				
P2P	ONVIF	RTMP		
Authentication	n ⊚ On ⊙ C	off		
	Default	Refresh	Save	

<u>Step 2</u> Select **On** in **Authentication**.

Step 3 Click Save.

### 4.6.13.3 RTMP


Through RTMP, you can access the third-party platform (such as Ali and YouTube) to realize video live view.

 $\square$ 

- RTMP can be configured by admin only.
- RTMP supports the H.264, H.264 B and H.264H video formats, and the AAC audio format only.
- <u>Step 1</u> Select **Setting > Network > Port > RTMP**.

	Figure 4-8	9 RTMP
P2P	ONVIF	RTMP
Enable		
Stream Type	Main Stream	○ Sub Stream 1 ○ Sub Stream 2
Address Type	Non-custom	◯ Custom
IP Address	0.0.0.0	
Port	1935	(0~65535)
Custom Address		
	Default	Refresh Save

<u>Step 2</u> Select the **Enable** checkbox.



Step 3 Configure RTMP parameters..

Table 4-32 Description of RTMP parameters

Parameter	Description
Stream Type	The stream for live view. Make sure that the video format is the H.264, H.264 B and H.264H, and the audio format is AAC.



Parameter	ter Description	
	Includes Non-custom and Custom.	
Address Type	• <b>Non-custom</b> : Enter the server IP and domain name.	
	• <b>Custom</b> : Enter the path allocated by the server.	
IP Address	When selecting <b>Non-custom</b> , you need to enter server IP address and port.	
Port	• IP address: Support IPv4 or domain name.	
	• <b>Port</b> : We recommend that you use the default one.	
Custom Address	When selecting <b>Custom</b> , you need to enter the path allocated by the server.	

Step 4 Click Save.

# 4.7 Storage

This section introduces how to manage saved resources (such as recorded video) and storage space. The storage management helps to make best use of storage space.

# 4.7.1 Setting Storage Plan

- Setting record plan and record control to achieve all-time recording, recording in specific period or alarm linked recording. For details, see "5.1.1.2.1 Setting Record Plan" and "5.1.1.2.2 Setting Record Control".
- Set the snapshot schedule as needed. For details, see "5.1.1.3.1 Setting Snapshot Plan".

# 4.7.2 Setting Schedule

You can configure record schedule, snapshot schedule and holiday schedule. Set certain days as holiday, and when the **Record** or **Snapshot** is selected in the holiday schedule, the system takes snapshot or records video as holiday schedule defined.

## Prerequisites

- Set the record mode to be **Auto** in **Record Control**. For details, see "5.1.1.2.1 Setting Record Plan".
- Configure holiday record and snapshot schedule. For details, see "5.1.1.2.1 Setting Record Plan" and "5.1.1.3.1 Setting Snapshot Plan".

## Procedure

<u>Step 1</u> Select Setting > Storage > Schedule > Holiday Schedule.



		Fi	gure 4-	90 Ho	liday so	hedule	_	
Record		Sr	napsho	t	Holida	ay Schedi	ule	
Record	d 🔳 S	napsho	t					
Calenda	Ir				Jul	-		
Sun	Mon	Tue	Wen	Thu	Fri	Sat		
	1	2	3	4	5	6		
7	8	9	10	11	12	13		
14	15	16	17	18	19	20		
21	22	23	24	25	26	27		
28	29	30	31					
Refr	esh		Save				1	

#### <u>Step 2</u> Select **Record** or **Snapshot**.

<u>Step 3</u> Select the days you need to set as holiday.

Those days with yellow color indicates that they were set as holidays.

 $\square$ 

When holiday schedule setting is not the same as the general setting, holiday schedule setting is prior to the general setting. For example, with **Holiday Schedule** enabled, if the day is holiday, the system snapshots or records as holiday schedule setting; otherwise, the system snapshots or records as general setting.

Step 4 Click Save.

# 4.7.3 Setting Destination

This section introduces the configuration of the storage method for the recorded videos and snapshots.

## 4.7.3.1 Path

You can select different storage paths for the recorded videos and snapshots according to event type. You can select from SD card, FTP and NAS.

 $\square$ 

Local is displayed only on models that support SD card.

<u>Step 1</u> Select Setting > Storage > Destination > Path.



Path	Local		109.0	HAS			
0000				Siesebot			
Event type	Scheduled	Realisin Detection	Alart	Elect Type	Schulling	Matter Delector	Alarm
Local	0		-E	Local	10	0	
FTP	12	10	12	FTF	20	20	8
N/O	0		10	. Fakes	10	.0	101
Didailt	Artun	[] . Sec ]					

<u>Step 2</u>	Select the storage method that you need for the recorded videos and snapshots of
	different types.

Parameter	Description
Event Type	Select from Scheduled, Motion Detection and Alarm.
Local	Save in the internal SD card.
FTP	Save in the FTP server.
NAS	Save in the NAS (network attached storage).

#### Table 4-33 Description of path parameters

Step 3 Click Save.

## 4.7.3.2 Local

Display the information of the local SD card. You can set it as read only or read & write; you can also hot swap and format SD card.

 $\square$ 

Functions might vary with different models.

#### Select Setting > Storage > Destination > Local.

- Click **Read Only**, and then the SD card is set to read only.
- Click **Read & Write**, and then the SD card is set to read & write.
- Click Hot Swap, and then you can pull out the SD card.
- Click **Refresh**, and then you can format the SD card.
- Click **Format**, and you can format the SD card.

### $\square$

When reading SD card on PC, if the SD card capacity is much less than the nominal capacity, you need to format the SD card. Then the data in SD card will be cleared, and the SD card is formatted to be private file system. The private file system can greatly improve SD card multimedia file read/write performance. Download Diskmanager from Toolbox to read the SD card. For details, contact aftersales technicians.

<sup>&</sup>lt;u>Step 4</u> Configure other path parameters on **Destination**, **FTP** or **NAS** interface. For details, see "4.7.3 Setting Destination", "4.7.3.3 FTP" or "4.7.3.4 NAS".



			Figure 4-92 Local	
		-		-
Contraction of the second second	um I	harmal		in the second

## 4.7.3.3 FTP

FTP can be enabled only when it was selected as a destination path. When the network does not work, you can save all the files to the internal SD card for emergency.

- <u>Step 1</u> Select Setting > Storage > Destination > FTP.
- <u>Step 2</u> Select the **Enable** checkbox, and select the FTP type.

	$\cap$	h
_		

You select **FTP** or **SFPT** from the drop-down list. **SFTP** is recommended to enhance network security.

<u>Step 3</u> Configure FTP parameters.

	Figure 4-95 FTF		
Path	Local	FTP	NAS
Enable	SFTP(Recommended)	]	
Server Address	1999 B.	]	
Port	20	(0~65535)	
Username	a		
Password	•••••	•	
Remote Directory	share		
Directory Structure	Use Level 3 Directory 💌	]	
Level 1 Directory	Name 💌	]	
Level 2 Directory	Date 💌	]	
Level 3 Directory	Channel NO.	]	_
Customized Picture	Date&Time	Setting	
Emergency (Local)			
	test		
	Default Re	fresh	Save

Figure 4-93 FTP



### **Operation Manual**

## Figure 4-94 Picture name settings

	No.	Picture Name Confunt	Separator		Cedera
Mii.	18	Date&Time		8	++
	2	Milisecond	-	9-0	++
X	3	Name	-		++
Z	4	IP Address	100		++
	5	Channel NO	125		++
П	6	Snapshot Type	-		++
E1:	70	Custom	20		++

Table 4-34 Description of FTP parameters

Parameter	Description			
Server Address	The IP address of the FTP server.			
Port	The port number of the FTP server.			
Username	The user name to log in to the FTP server.			
Password	The password to log in to the FTP server.			
Remote Directory	The destination path in the FTP server, and it is shared by default.			
Directory Structure	Set the directory structure, which supports three levels at most.			
Level 1 Directory	Set the directory name, and you can customize the name.			
Level 2 Directory	When you select <b>Custom</b> , enter the custom directory name, which supports numbers, English letters, underlines and dashes.			
Level 3 Directory				



Parameter	Description
Customized Picture Name	<ul> <li>Click Setting to set picture name.</li> <li>Date&amp;Time is required, and it is selected by default.</li> <li>Select the other fields of the name, and the corresponding instruction will be displayed on the screen.</li> <li>Double-click the symbols under Separator, you can customize the separator.</li> <li>Double-click Custom, you can customize the files of the picture name.</li> <li>Click the arrow under Ordering, and you can adjust the ordering of the file.</li> <li>Date&amp;Time and Millisecond is a whole, click the arrow of any one of the two fields, the two moves together.</li> <li>The real-time value of Millisecond will be displayed for precise snapshot, and for schedule and normal event, the millisecond displays 0000.</li> </ul>
Emergency (Local)	Select <b>Emergency (Local)</b> , and when the FTP server does not work, all the files are saved to the internal SD card.

Step 4 Click Save.

<u>Step 5</u> Click **test** to test whether FTP function works normally.

## 4.7.3.4 NAS

This function can be enabled only when NAS was selected as a destination path. Enable this function, and you can save all the files in the NAS.

#### <u>Step 1</u> Select Setting > Storage > Destination > NAS.

		Figure 4	-95 NAS	
(Path)	COSTE	FIP	NAS	
Crafely	185			
Server Address	1010			
Mansala Cleadure	-			
	Cotalt	THREE T	we	

<u>Step 2</u> Select the **Enable** checkbox to enable NAS function, and select NAS protocol type.

- **NFS** (Network File System): A file system which enables computers in the same network to share files through TCP/IP.
- SMB (Server Message Block): Provides shared access for clients and the server.

<u>Step 3</u> Configure NAS parameters.

Table 4-35 Description of NAS parameters	Table 4-35 Descr	iption of NAS	parameters
--	------------------	---------------	------------

Parameter	Description
Server Address	The IP address of the NAS server.
Username	When selecting <b>SMB</b> protocol, you are required to enter user



Parameter	Description
Password	name and password. Enter them as needed.
Remote Directory	The destination path in the NAS server.
Step / Click Save	

Step 4 Click Save.

# 4.8 System

This section introduces system configurations, including general, date & time, account, safety, PTZ settings, default, import/export, remote, auto maintain and upgrade.

# 4.8.1 General

You can configure device name, language and video standard.

#### <u>Step 1</u> Select Setting > System > General > General.

	Figure 4-96 General	
General	Date&Time	
Name	4M0292DYAG2B100	
Language	English 💌	
Video Standard	PAL 💌	
TVOut	TV	
	Default Refresh	Save

<u>Step 2</u> Configure general parameters.

Table 4-36 Description of general parameters

Parameter	Description
	The name of the device.
Name	
	Each device has its own name.
Language	Select system language.
Video Standard	Select video standard from <b>PAL</b> and <b>NTSC</b> .
	Select <b>On</b> or <b>Off</b> . This function is available on models with analog output.
TVOut	• If the TV out is <b>On</b> , smart plans will be disabled; if the smart plans
	are enabled, the TV out will be set as <b>Off</b> .
	<ul> <li>SDI and HDCVI are available on select models.</li> </ul>



Step 3 Click Save.

# 4.8.2 Date & Time

You can configure date and time format, time zone, current time, DST (Daylight Saving Time) or NTP server.

#### <u>Step 1</u> Select **Setting > System > General > Date & Time**.

	Figure 4-97 Date and time
General D	ate& Time
Date Format Time Format Time Zone	YYYY-MM-DD V 24-Hour V (UTC) Coordinated Universal Time V
Current Time	2021-08-24 09 : 15 : 23 Sync PC
DST	
DST Type	Date O Week
Start Time	Jan 💙 1 💙 00 : 00 : 00
End Time	Jan 💙 2 💙 00 : 00 : 00
□ NTP	
Server	clock.isc.org
Port	123
Interval	10 Min. (0~30)
Positioning System	GPS V
Positioning System	·
Interval	30 Min. (1~1440)
	Default Refresh Save




Table 4-37 Description of date and time parameters

Parameter	Description
Date Format	Configure the date format.
Time Format	Configure the time format. You can select from <b>12-Hour</b> or <b>24-Hour</b> .
Time Zone	Configure the time zone that the camera is at.
Current Time	Configure system time. Click <b>Sync PC</b> , and the system time changes to the PC time.



Parameter	Description
	Enable DST as needed.
DST	Select the checkbox, and configure start time and end time of DST with <b>Date</b> or <b>Week</b> .
NTP	
NTP Server	Select the checkbox, and then NTP (network time protocol) is enabled,
Time Zone	the system then syncs time with the internet server in real time.
Port	You can also enter the IP address, time zone, port, and interval of a PC which installed NTP server to use NTP.
Interval	
Positioning System	Supports both GPS and BeiDou.
Positioning System Time Synchronization	Select <b>Position System Time Synchronization</b> and configure <b>Interval</b> to enable this function. After enabling this function, the device will
Interval	synchronize the system time according to the interval you set.

Step 3 Click Save.

# 4.8.3 Account

Manage all the users. You can add, delete, or modify users. Users include admin, added users and ONVIF users.

Managing users and groups are only available for administrator users.

- The max length of the user or group name is 31 characters which consisted of number, letters, underline, dash, dot and @.
- The password must consist of 8 to 32 non-blank characters and contain at least two types of characters among upper case, lower case, number, and special character (excluding ' ";: &).
- You can have 18 users and 8 groups at most.
- You can manage users through single user or group, and duplicate user names or group names are not allowed. A user can be in only one group at a time, and the group users can own authorities within group authority range.
- Online users cannot modify their own authority.
- There is one admin by default which has highest authority.
- Select **Anonymous Login**, and then log in with only IP address instead of user name and password. Anonymous users only have preview authorities. During anonymous login, click **Logout**, and then you can log in with other username.

## 4.8.3.1 Adding a User

You are admin user by default. You can add users, and configure different authorities.


<u>Step 1</u> Select Setting > System > Account > Account > Username.



Figure 4-98 Username

Vectors	GRUE NVIA	100000000000000000000000000000000000000	244 W.4	I CONTRACTOR IN CALLS	And the second second	Carlo Art
16	1001470	GENERALINA	Plantes	NUMBER	MARY	DHER
1	adrm	atre)	where a sector of	1	1.1.2	
1	Freetas	adreb.		Q	1	0
	114	Render	beilen	Section 100		
Reflocitly John Manual Control	Uvi Na Demo	Harbash Storage	System Dant	System Wite Rations &		

#### Step 2 Click Add User.



	-		
Usemante		Must	
Password	[		
	The minimum gas	is phrasis length is 8	
	characters -		
	Weat Middle	Storp	
Confirm Password	-		
Group Name	admin	•	
Nema			
Operation Permiss	itin Ra	strided Login	
17 MI			
User			
IV LIVE			
2 Playback			
2 System			
🗵 System Into			
I Manual Control			
🛛 File Bathup			
😨 Slorage			
1 Event			
2 Network			
2 Peripheral			
Peripheral			
I All Parameter			



Figure 4-100 Add user (restricted login)



<u>Step 3</u> Configure user parameters.

Table 4-38 Description of user parameters (1)

Parameter	Description
Username	User's unique identification. You cannot use existed user name.
Password	Enter password and confirm it again.
Confirm Password	The password must consist of 8 to 32 non-blank characters and contain at least two types of characters among upper case, lower case, number, and special character (excluding '";: &).
Group Name	The group that users belong to. Each group has different authorities.
Memo	Describe the user.
Operation Permission	Select authorities as needed. We recommend you giving fewer authorities to normal users than advance users.



Parameter	Description
	Set the PC address that allows the defined user to log in to the camera and the validity period and time range. You can log in to web with the defined IP in the defined time range of validity period.
	<ul> <li>IP address: You can log in to web through the PC with the set IP.</li> </ul>
	<ul> <li>Validity period: You can log in to web in the set validity period.</li> </ul>
	• Time range: You can log in to web in the set time
	range.
Restricted Login	Set as following:
5	1. Select IP Address: Select IP type and set IP address.
	<ul> <li>IP Address: Enter the IP address of the host to be added.</li> </ul>
	<ul> <li>IP segment: Enter the start address and end</li> </ul>
	address of the host to be added.
	2. Select Validity Period: Set the begin time and end
	time.
	3. Select <b>Time Range</b> : Set the time range that allow
	user to log in. For details, see "5.1.1.1 Setting
	Period".

Step 4 Click Save.

The newly added user is displayed in the user name list.

## **Related Operations**

• Edit user information

Click 🛃 to change password, group, memo, operation authorities, and login authorities.

 $\square$ 

You can only change the password of the admin.

The methods of changing password vary with different accounts.

- Login with the admin account, you can change password through Old Password and Admin Account.
- Login with non-admin account (an added account with the permission of user management), you can change password through **Old Password**.
- **Old Password**: Change the password through entering the old password to be changed, and then the new password.



igure 4-101 Change password th	nrough old password (login with non-admin account)	
Modify User		×
Username	11 💌	
Modify Password		
Old Password		
New Password		
	The minimum pass phrase length is 8 characters	
	Weak Medium Strong	
Confirm Password		
Group Name	user	
Memo		
Authority	All	
	✓ Live	
	Playback	
	Save Cancel	

Fi

• Admin Account: Change the password through entering the admin password, and then the new password for the non-admin account to be changed.

Figure 4-102 Change password through admin password (login with admin account)

Modify User			
Lisemene	11		
7 Modily Password			
Modification Mode	Admin Account	•	
Admin Usemame	admin		
Admin Password			
New Password			
	The maximum poiss pr	nace length is 8 characters	
	West Medan	Sitera	
Confirm Password			
Group Name	user		
Merno	11		

• Delete users

Click  $\bigcirc$  to delete the added users.



 $\square$ 

Admin account cannot be deleted.

• View the authorities If the current account has with the permission of user management, click **Q** to view the login

authorities of other accounts. If not, you can only view the login authorities of the current account.

## 4.8.3.2 Adding User Group

You have two groups named admin and user by default, and you can add new group, delete added group or modify group authority and memo.

```
<u>Step 1</u> Select Setting > System > Account > Account > Group Name.
```

	CFOIA MARKI		HERD (		MARTIN	DISC
1	40019		administrator group		10	a
2	USER.		1947 (2012)		1	0.0
volivity.						
LW.	6.000	Plastack	Spittere:	System Into		
	Contraction of the	Storpan.	Enter	Metwork		
arkul Control	FileBaseau	Constraints and a	Security.			

Figure 4-103 Group name

Step 2 Click Add Group.



Figure 4-104 Add group

Add Group		×
Group Name	Must	
Memo		
Authority	All	
	Live	<b>^</b>
	Playback	1
	System	
	System Info	-
	Save Cancel	

<u>Step 3</u> Enter the group name and memo, and then select group authorities.

The default authorities of Admin group includes live, playback, storage, file backup, user, system, system info, manual control, maintenance, peripheral, PTZ, security, network, event and AV parameters; the default authorities of User group include live and playback.

Group Authority	Admin	User	Functions
User	YES	NA	Add, delete and check user/user group.
Live	YES	YES	Real-time stream view.
Playback	YES	YES	Playback view.
System	YES	NA	System time setting and more.
System Info	YES	NA	Version information, system logs and more.
Manual Control	YES	NA	PTZ settings.
File Backup	YES	NA	File backup.
Storage	YES	NA	Storage point configuration, snapshot recording time configuration, SFTP configuration and more.
Event	YES	NA	Video detection settings, audio detection settings, alarm settings and more.
Network	YES	NA	IP settings, SMTP settings, SNMP settings, AP Hotspot settings and more.

Table 4-39 Description of user group parameters



Group Authority	Admin	User	Functions
Peripheral	YES	NA	External light, wiper and serial port settings.
AV Parameter	YES	NA	Camera property settings, audio and video settings and more.
PTZ	YES	NA	Preset settings, tour settings and more.
Security	YES	NA	HTTPS settings, RTSP over TLS settings and more.
Maintenance	YES	NA	Automatic maintenance settings and more.

- $\square$
- Any user in the **Admin** group has **User** authorities to modify group suthorities. The **User** group does not have this authorities.
- The function of the device correspond to the authority control respectively. Only user with specified authority can use corresponding function; the **Admin** group has all the authorities.
- <u>Step 4</u> Click **Save** to finish configuration.

The newly added group displays in the group name list.

- $\square$
- After adding group, click is to modify group memo or authorities; click is to delete the added group, admin group and user group cannot be deleted.
- Click 🥂 in the row of admin group or user group to modify group memo.

## 4.8.3.3 ONVIF User

You can add, delete ONVIF user, and modify their passwords.

#### Procedure

<u>Step 1</u> Select Setting > System > Account > ONVIF User.

Figure 4-105 ONVIF user

Step 2 Click Add User.



Figure 4-106 Add user

Add User	×
Username	Must
Password	
	The minimum pass phrase length is 8 characters Weak Middle Strong
Confirm Password	
Group Name	admin
	Save Cancel

#### <u>Step 3</u> Configure user parameters.

#### Table 4-40 Description of user parameters

Parameter	Description
Username	User's unique identification. You cannot use existed user name.
Password	Enter password and confirm it again.
Confirm Password	The password must consist of 8 to 32 non-blank characters and contain at least two types of characters among upper case, lower case, number, and special character (excluding ' ";:&).
Group Name	The group that users belong to. Each group has different authorities.

Step 4 Click Save.

The newly added user displays in the user name list.

#### **Related Operations**

• Edit user information

Click 🛃 to change password, group, memo, operation authorities, and login authorities.



You can only change the password of the admin.

The methods of changing password vary with different accounts.

 Log in with admin account, you can change password through Old Password and Admin Account.

The password of admin account can be changed through **Old Password** only.

- Login with non-admin account (an added account with the permission of user management), you can change password through **Old Password**.
- **Old Password**: Change the password through entering the old password to be changed, and then the new password.



gure 4-107 Change password t	hrough old password (login with non-admin account)	
Modify User		×
Username Modify Password	11 💌	
Old Password New Password	The minimum pass phrase length is 8 characters	
	Weak Medium Strong	
Confirm Password		
Group Name	user	
Memo		
Authority	All	
	✓ Live	
	Playback	
	Save Cancel	

• Admin Account: Change the password through entering the admin password, and then the new password for the non-admin account to be changed.

Figure 4-108 Change password through admin password (login with admin account)

Modify User			
Usemene	11		
7 Modily Password			
Modification Mode	Admin Account	•	
Admin Usemame	admin		
Admin Pessword	1		
New Password	-		
	The minimum pass pr	mase length is 8 characters	
	West Medan	Share	
Confirm Password			
Group Name	user		
Memo	1		

Delete users •

Click 😑 to delete the added users.



 $\square$ 

Admin account cannot be deleted.

View the authorities
 If the current account has the permission of user management, click to view the login
 authorities of other accounts. If not, you can only view the login authorities of the current
 account.

# 4.8.4 Safety

You can configure system service, HTTPS, and firewall.

## 4.8.4.1 System Service

Configure the IP hosts (devices with IP address) that are allowed to visit the device. Only the hosts in the trusted sites list can log in to the web interface. This is to enhance network and data security. <u>Step 1</u> Select **Setting** > **System** > **Safety** > **System Service**.

rigu	ile 4-109 System service
HTTPS	Firewal
[2] Enable	
. 🕢	
(V) Enable	
2 Enable	
🖉 Enativ	
🗵 Enable	
Enable	"Please make sure matched device or software supports video decoption function
VI Enoble	
2 Enable	
	HTTPS

Figure 4-109 System service

<u>Step 2</u> Enable the system service according to the actual needs.

Function	Description	
SSH	You can enable SSH authentication to perform safety management.	
Multicast/Broadcast Search	Enable this function, and then when multiple users are previewing the device video image simultaneously through network, they can find your device with multicast/broadcast protocol.	
Password Reset	Manage system security with this function.	



Function	Description
CGI Service	Enable this function, and then other devices can access through this service.
Onvif Service	Enable this function, and then other devices can access through this service.
Genetec Service	Enable this function, and then other devices can access through this service.
Audio and Video Transmission Encryption	Enable to encrypt audio/video transmission.
Mobile Push	Enable this function, and then the system would send the snapshot that was taken when alarm is triggered to your phone, this is enabled by default.

Step 3 Click Save.

## 4.8.4.2 HTTPS

Create a certificate or upload an authenticated certificate, and then you can log in through HTTPS with your PC. The HTTPS can protect page authenticity on all types of websites, secure accounts, and keep user communications, identity, and web browsing private.

<u>Step 1</u> Select **Setting** > **Network** > **HTTPS**.

		Figure	4-110 HTTPS	
System Service	HTTPS	Preval		
E EnderHTTPS				
Protocol Variant				
W Enable TLEv1.0				
Create Certificate				
Gisste				
Request Created				
SeguestCraster			Contra 1	Downas
In stall Signed Corts	in the second			40
Certificate Pum			Browne	
Dettilizate Key Pe	6		Browse.	ind and its
Cartificate bridade	ŧ			
Conflicte Install RODate	-		- Cutom	
	fished	<u>Dee</u>		

<u>Step 2</u> Create a certificate or upload an authenticated certificate.

• For creating a certificate, click **Create**.



Figure 4-111 HTTPS dialog box

HTTPS		×
Country IP or Domain name Validity Period	365	*e.g. CN * Day*Range :1-5000
Province Location Organization	none none	
Organization Unit Email	none	
	Create Car	ncel

- For uploading the authenticated certificate, click **Browse** to select the certificate and certificate key, click **Upload** to upload them, and then skip to <u>Step5</u>.
- <u>Step 3</u> Enter the required information and then click **Create**.
  - $\square$

The entered **IP or Domain name** must be the same as the IP or domain name of the device.

Step 4 Click Install.

Figure 4-112 Certificate installation

1414				
eparat Crastell				
Requirement	Investment of the ISS of the Workshop	- Delate	and held	
ADD Speed Cattern	0			
Centrols Path		living.		
Contraits Kity Path		Byrna		
ertificatio indicating				
Controlational		(million)		
400.00				

<u>Step 5</u> Click **Download** to download root certificate.

<u>Step 6</u> Click **Download Root Certificate**.



Figure 4-113 File download

File Dow	rnload - Security Warning 🛛 🔀
Do you	want to open or save this file?
	Name: ca.crt Type: Security Certificate From: Internet Open <u>S</u> ave Cancel
1	While files from the Internet can be useful, this file type can potentially harm your computer. If you do not trust the source, do not open or save this software. <u>What's the risk?</u>

Step 7 Click **Open**.

Figure 4-114 Certificate information

Certificate	?	×
General Details Certification Path		_
Certificate Information	_	
This CA Root certificate is not trusted. To enable trust, install this certificate in the Trusted Root Certification Authorities store.		
Issued to: Product Root CA		
Issued by: Product Root CA		
Valid from 2013-6-18 to 2023-6-16		
Install Certificate	ent	
	ж	

Step 8 Click Install Certificate.



Figure 4-115 Certificate import wizard (1)



Step 9 Click Next.



tificate Import Wizard	
Certificate Store Certificate stores are system area	s where certificates are kept.
	a certificate store, or you can specify a location for
Automatically select the cer	tificate store based on the type of certificate
O Place all certificates in the f	ollowing store
Certificate store;	
	Browse
	< Back Next > Cano

#### <u>Step 10</u> Select the storage location and click **Next**.



#### Figure 4-117 Certificate import wizard (2)

Certificate Import Wizard		×
	Completing the Certificate Import Wizard	
	You have successfully completed the Certificate Import wizard.	
	You have specified the following settings:	
	Certificate Store Selected Automatically determined by t Content Certificate	
	< <u>B</u> ack Finish Cancel	

Step 11 Click Finish and a dialog box showing The import was successful pops up.

#### Figure 4-118 Import succeeds

Certific	ate Import Wizard 🛛 🔀
Ų,	The import was successful.
	ОК

## 4.8.4.3 Firewall

Configure **Network Access**, **PING prohibited** and **Prevent Semijoin** to enhance network and data security.

- Network Access: Set trusted list and restricted list to limit access.
  - Allowlist: Only when the IP/MAC of your PC in the allowlist, can you access the camera. Ports are the same.
  - **Blocklist**: When the IP/MAC of your PC is in the blocklist, you cannot access the camera. Ports are the same.
- **PING prohibited**: Enable **PING prohibited** function, and the camera will not respond to the ping request.
- **Prevent Semijoin**: Enable **Prevent Semijoin** function, and the camera can provide service normally under Semijoin attack.

Ш

• You cannot set allowlist or blocklist for camera IP or MAC addresses.



- You cannot set allowlist or blocklist for port MAC addresses.
- When the IP addresses of the camera and your PC are in the same LAN, MAC verification takes effect.
- When you access the camera through internet, the camera verifies the MAC address according to the router MAC.

This section takes **Network Access** as an example.

<u>Step 1</u> Select Setting > System > Safety > Firewall.

Figure 4-119 Firewall

Drubie Mode	2 Abund C Bothe			
	dealers W4C are allowed to valitamapsed apports	al fac device		
12	Patron MC attan	tut -	iuusin	Carlo
16	Bolde Top-	Dency All Parts	1	
12	70107-00	Desice 48 Feitz	2	
102	102063-04	Dema Al Peta	1	
×	Vala	Delta 4 Pata	1	•
AREMAC				

<u>Step 2</u> Select **Network Access** from **Rule Type** list, and then select the **Enable** checkbox.

- Enable **PING prohibited** and **Prevent Semijoin**, and click **Save**. You do not need to configure parameters.
- Enable Network Access, and configure allowlist and blocklist.
  - Select the mode: **Allowlist** and **Blocklist**.
  - ◇ Click Add IP/MAC.

Figure 4-120 Add IP/MAC

Add IP/MAC	×
Rule Type	IP Address
IP Version	IPv4
IP Address	1. 8. 8. 1
Device All Ports	
Device Start Server	1
Device End Server	1
ОК	Cancel

<u>Step 3</u> Configure parameters.



Parameter	Description	
	Select IP address, IP segment, MAC address or all IP addresses.	
Rule Type	IP address: Select IP version and enter the IP address of the host to	
	be added.	
	IP segment: Select IP version and enter the start address and end	
	address of the segment to be added.	
	<ul> <li>MAC address: Enter MAC address of the host to be added.</li> </ul>	
	All IP addresses: Set all IP addresses in allowlist or restricted list.	
Device All Ports	Set access ports. You can select all ports or the ports in defined areas.	
Device Start Server	Device all ports: Set all IP port in allowlist or Blocklist. When	
Port	selecting BlocklList in Mode, and All IP Address in Rule Type, you	
	cannot select the <b>Device All Ports</b> checkbox.	
Device End Server Port	Device start server port and Device end server port: Set Device start	
FOIL	server port and device end server port, and the range is $1-65535$ .	

#### Table 4-42 Description of adding IP/MAC parameters

Step 4 Click **OK**, and the **Firewall** interface is displayed.

Step 5 Click Save.

# 4.8.5 Peripheral

## 4.8.5.1 Serial Port Settings

Set the serial port of the external device.

#### <u>Step 1</u> Select Setting > System > Peripheral > Serial Port Setting.

	inguic 4 121 Schurp	Joirt Settings	
Serial Port Settings	External Light	Wiper	
Address	1		
Baud Rate	9600	▼.	
Data Bit	8	•	
Stop Bit	1	•	
Parity	NONE	-	
	Default	Refresh	Save

Figure 4-121 Serial port settings

<u>Step 2</u> Configure serial port settings parameters.



	+ +5 Description of senal port settings parameters
Parameter	Description
Address	The corresponding device address. It is 1 by default. Make sure that the address is the device address; otherwise you cannot control the device.
Baud Rate	Select the baud rate for the camera. It is 9600 by default.
Date Bit	It is 8 by default.
Stop Bit	It is 1 by default.
Parity	It is <b>None</b> by default.

Table 4-43 Description of serial port settings parameters

Step 3 Click Save.

## 4.8.5.2 External Light


You need to configure external light mode when the external light is used.

## Prerequisites

- Connect external light with RS-485 port.
- You have configured serial port parameters. For details, see "4.8.5.1 Serial Port Settings".

### Procedure

#### <u>Step 1</u> Select Setting > System > Peripheral > External Light.



			2000-01-01-00)-46-55	Vronk Mada Auto Moda Light Brightneaa Period setting	Auto Time Sating	• • • 121
190						
Default	Refresh	Save	]			

<u>Step 2</u> Configure external light work mode.



10010	
Parameter	Description
	Off: Turn off the external light.
Work Mode	Manual: Set the light brightness manually.
Work Mode	• <b>Auto</b> : The camera turns on or turns off the light according to the light time and photoresister automatically.
Auto Mode	<ul> <li>Time: When selecting Time in Auto Mode, click Setting to set the arming period. During the arming period, the external light is on. For details of arming period setting, see "5.1.1.1 Setting Period".</li> <li>Photoresister: When you select Photoresister in Auto Mode, the system turns on the external light according to the brightness automatically.</li> </ul>
Light Brightness	Set the brightness of the external light.
Step 3 Click Save	·

#### Table 4-44 Description of external light parameters

Step 3 Click Save.

## 4.8.5.3 Wiper

#### <u>Step 1</u> Select Setting > System > Peripheral > Peripheral > Wiper.

Figure 4-123 Wiper

\$200-01-01-00.50.58	antevol Time 10 s (8-205)
	Ques
	Wash
	Eeryday = 04 : 00
	.0103

<u>Step 2</u> Configure wiper work mode.

Parameter	Description
Interval Time	The interval time between stop mode and start mode. For example, set the time to10 s, and the wiper will work every 10 s.
Start	Set the work status of the wiper.
Stop	• Start: Click <b>Start</b> , and the wiper works as the set interval time.
Once	<ul> <li>Stop: Click <b>Stop</b>, and the wiper stops working.</li> <li>Once: Click <b>Once</b>, and the wiper works once.</li> </ul>



Parameter	Description
Time Wash	Select the <b>Time Wash</b> checkbox and set the time, and then the wiper will work as the set time. Click <b>Once</b> , and the wiper works once. It can be used to check whether the wiper can work normally.

Step 3 Click Save.



# 5 Event

This chapter introduces intelligent event settings, including smart track, panoramic calibration, video detection, audio detection, smart plan, IVS, face detection, face recognition, people counting, heat map, video Metadata, alarm, and abnormality.

# 5.1 Setting Alarm Linkage

# 5.1.1 Alarm Linkage

When configuring alarm events, select alarm linkages (such as record, snapshot). When the corresponding alarm is triggered in the configured arming period, the system will alarm. Interfaces might vary with different events, and the actual interface shall prevail.

Relay-in	Alarm1	,		
Mode	Alarm	٠		
Penad	Setting	ľ.		
Anti-Dither	0	s (0-100)	Sensor Type	NO .
e Record				
Record Delay	10	5 (10-300)		
Relay-out				
Alarm Delay	10	s (10-300)		
Send Email				
🗌 Audio Linkage				
Play Count	3	(1-10)		
File	alarm wav	•		
Warning Light				
Mode	Flicker	•		
Elicker Frequen	cy Medium	•		
Duration	10	s (5~30)		
Period	Setting			
🖌 Snapshot		6.9°		


Figure 5-1 Alarm linkage




## 5.1.1.1 Setting Period

Set arming periods. The system only performs corresponding linkage action in the configured period.







- Method 1: Directly press and drag the left mouse button on the timeline.
- Method 2: Enter an actual time period.
  - 1. Click **Setting** next to a day.
  - 2. Select a time period to be enabled.
  - 3. Enter start time and end time of a time period.

#### 

- Select All or checkboxes of some days to set the time period of multiple days at one time.
- You can set 6 time periods per day.

Step 3 Click Save.

## 5.1.1.2 Record Linkage

The system can link record channel when an alarm event occurs. After alarm, the system stops recording after an extended time period according to the **Record Delay** setting.


To use the record linkage function, set record plan for motion detection alarm and enable auto recording in record control.



#### 5.1.1.2.1 Setting Record Plan

After the corresponding alarm type (**Normal**, **Motion**, and **Alarm**) is enabled, the record channel links recording.





Step 2 Set record plan.

Green represents normal record plan (such as timing recording); yellow represents motion record plan (such as recording triggered by intelligent events); red represents alarm record plan (such as recording triggered by alarm-in).

- Method one: Select a record type, such as **Normal**, and directly press and drag the left mouse button to set the time period for normal record on the timeline.
- Method two: Enter an actual time period.
  - 1. Click **Setting** next to a day.

E) A2	15, 844	JUL S	Mon		11 T4	8. U	0.00	2 🗌 Thu	🖂 Fit	🗋 Bat	E Holday	
Panadt	00 :	00	00	-	23	69	69	T Normal	(V) Notion	(V) Alam		
Period2	0D	00	00		23	59	59	Normal	E Notion	E Alarm		
Period3	00.	00	00	-	23	59	59	Normal	E Notion	E Alaem		
Period4	dD :	00	00	-	23	59	59	E Normal	E Notion	E Aam		
Periudo	00	00	00	-	23	69	59	E) Normal	E Notan	E Alarm		
Penad8	00	00	00	-	23	69	69	1 Normal	E Motion	E Alaem		

2. Select a day, and the alarm type next to a period, and then set the period.

- Select All or checkboxes of some days to set the time period of multiple days at one time.
- ◇ You can set 6 time periods per day.

Step 3 Click Save.



#### 5.1.1.2.2 Setting Record Control

Set parameters such as pack duration, pre-event record, disk full, record mode, and record stream.

 $\square$ 

Make sure that the SD card is authenticated before recording if you use Dahua smart card. For details, see "4.5.2.5 Path".

#### <u>Step 1</u> Select **Setting** > **Storage** > **Record Control**.

Figure 5-5 Record control

sord Control				 	
Pack Dunition	8	58x x1-1200			
the event fieldom	5	0.00-51			
Duriet	Overwrite	Ŧ			
Record Melle	a Auto 🗇 Marca	A D OF			
Record Smart	Main Stream				
Record Melte Record Sinuan	Main Stream	-			
	DHOUR	mittest.	544		

<u>Step 2</u> Set parameters.

Table 5-1 Description of record control parameters

Parameter	Description
Pack Duration	The time for packing each video file.
Pre-event Record	The time to record the video in advance of a triggered alarm event. For example, if the pre-event record is set to be 5 s, the system saves the recorded video of 5 s before the alarm is triggered. When an alarm or motion detection links recording, and the recording is not enabled, the system saves the video data within the pre-event record time to the video file.
Disk Full	<ul> <li>Recording strategy when the disk is full.</li> <li>Stop: Stop recording when the disk is full.</li> <li>Overwrite: Cyclically overwrite the earliest video when the disk is full.</li> </ul>
Record Mode	When you select <b>Manual</b> , the system starts recording; when you select <b>Auto</b> , the system starts recording in the configured time period of record plan.
Record Stream	Select record stream, including Main Stream and Sub Stream.

Step 3 Click Save.

#### 5.1.1.2.3 Setting Record Linkage

On the alarm event setting interface (such as the motion detection interface), select **Record** and set **Record Delay** to set alarm linkage and record delay.

After **Record Delay** is configured, alarm recording continues for an extended period after the alarm ends.

(a)hua			Operation Manual
	Figure 5-6 R	ecord linkage	
	Record		
	Record Delay	10 s (10~300)	
	Record		

## 5.1.1.3 Snapshot Linkage


After snapshot linkage is configured, the system can automatically alarm and take snapshots when an alarm is triggered.

After **Motion** is enabled in **Snapshot**, the system takes snapshots when an alarm is triggered. For querying and setting snapshot storage location, see "4.5.2.5 Path".

#### 5.1.1.3.1 Setting Snapshot Plan

According to the configured snapshot plan, the system enables or disables snapshot at corresponding time.

#### <u>Step 1</u> Select Setting > Storage > Schedule > Snapshot.



<u>Step 2</u> Select snapshot type and set time period.

Green represents normal snapshot plan (such as timing snapshot); yellow represents motion snapshot plan (such as snapshot triggered by intelligent events); red represents alarm snapshot plan (such as snapshot triggered by alarm-in).

- Method one: Select snapshot type, such as **Normal**, and directly press and drag the left mouse button to set time period for normal snapshot on the timeline.
- Method two: Enter an actual time period.
  - 1. Click **Setting** next to a day.



Figure 5-8 Setting (snapshot time period)

16 ( )	I C Bian	A B	Mon		II THE	10	Web	9	E The		DR		10 8#	Holiday
Penodt	00	00	00	-	23	59	59	EL	Normal	1	Motion	$\overline{\mathbb{R}}$	Alarm	
Period2	dD -	0D	00	-	23	59	59	E1	Normal	E	Motors	1	Atarm	
Period3	00 :	00	00		23	59	59	Ð	Normal	0	Motors	Ð	Alatm	
Pariod4	00 :	00	00	-	23	69	59	10	Normal	10	Motion	1	Alarm	
Penads	00 :	00	00	-	23	69	59	1	Normal	1	Motion.		Alarm	
Periode	00 ;	0.0	00	1	23	59	59		Normal	E	Notion	H	Alarm	

2. Select a day, and the alarm type next to a period. Then set the period.

r		 h.	
ш		Ш.	
ш		Ш.	
12	-	5	

- Select All or checkboxes of some days to set the time period of multiple days at one time.
- ◇ You can set 6 time periods per day.
- 3. You can set 6 time periods per day.

Step 3 Click Save.

#### 5.1.1.3.2 Setting Snapshot Linkage

On the alarm event setting interface (such as the motion detection interface), select **Snapshot** and set alarm linkage snapshot.

Figure 5-9 Snapshot linkage

Snapshot

### 5.1.1.4 Relay-out Linkage

When an alarm is triggered, the system can automatically link with relay-out device.

On the alarm event setting interface (such as the motion detection interface), select **Alarm** and set **Alarm Delay**.

When alarm delay is configured, alarm continues for an extended period after the alarm ends.

Figure 5-10 Relay-out linkage

Relay-out		
Alarm Delay	10	s (10~300)

### 5.1.1.5 Email Linkage

When an alarm is triggered, the system will automatically send an email to users. Email linkage takes effect only when SMTP is configured. For details, see "4.6.5 SMTP (Email)".



Figure 5-11 Email linkage	
---------------------------	--

Send Email

## 5.1.1.6 PTZ Linkage

When an alarm is triggered, the system links PTZ to do some operations. For example, the system links PTZ to rotate to the preset X.

	Figure 5-	12 PTZ lin	ikage		
PTZ	Activation	Preset	▼ No.	1	(1~255)

## 5.1.1.7 Warning Light Linkage

When an alarm is triggered, the system can automatically enable the warning light.


#### Set Mode, Flicker Frequency, Duration, and Period.

• **Mode**: The display mode of the warning light when an alarm is triggered. It includes **Normally on** and **Flicker**. When setting **Flicker** as the mode, you need to set the flicker frequency.

 $\square$ 

For the camera with red and blue alarm light, you can only select **Flicker** in **Mode**.

- **Duration**: After setting warning light duration, the warning light is turned off after an extended time of period after an alarm. It is 5 seconds–30 seconds.
- **Period**: The period for using warning light. When an alarm triggered during the configured period, the system links warning light. For the configuration, see "5.1.1.1 Setting Period".



Warning Light	
Mode	Flicker -
Flicker Frequency	Medium 💌
Duration	10 s (5~30)
Period	Setting

## 5.1.1.8 Audio Linkage

The system broadcasts alarm audio file when an alarm event occurs. Select **Setting** > **Camera** > **Audio** > **Alarm Audio** to set alarm audio file.

Figure 5-14	Audio linka	ge	
🔲 Audio Linkage			
Play Duration	10	▼ s	

# 5.1.2 Subscribing Alarm

# 5.1.2.1 About Alarm Types

For alarm types and preparations of alarm events, see Table 5-2.

Table 5-2 Description of alarm types
--------------------------------------

Alarm Type	Description	Preparation
Motion Detection	The alarm is triggered when moving object is detected.	Motion detection is enabled. For details, see "5.4.1 Setting Motion Detection".
Disk Full	The alarm is triggered when the free space of SD card is less than the configured value.	The SD card no space function is enabled. For details, see "5.19.1 Setting SD Card".
Disk Error	The alarm is triggered when there is failure or malfunction in the SD card.	SD card failure detection is enabled. For details, see "5.19.1 Setting SD Card".
Video Tampering	The alarm is triggered when the camera lens is covered or there is defocus in video images.	Video tampering is enabled. For details, see "5.4.2 Setting Video Tampering".
External Alarm	The alarm is triggered when there is external alarm input.	The device has alarm input port and external alarm function is enabled. For details, see "5.18 Setting Relay-in".
Illegal Access	The alarm is triggered when the number of consecutive login password error is up to the allowable number.	Illegal access detection is enabled. For details, see "5.19.3 Setting Illegal Access".
Audio Detection	The alarm is triggered when there is audio connection problem.	Abnormal audio detection is enabled. For details, see "5.6 Setting Audio Detection".
IVS	The alarm is triggered when intelligent rule is triggered.	Enable IVS, crowd map, face detection or people counting, and other intelligent functions.
Scene Changing	The alarm is triggered when the device monitoring scene changes.	Scene changing detection is enabled. For details, see "5.4.3 Setting Scene Changing".
Voltage Detection	The alarm is triggered when the device detects abnormal voltage input.	Voltage detection is enabled. For details, see "5.19.4 Setting Voltage Detection".
Security Exception	The alarm is triggered when the device detects malicious attack.	Voltage detection is enabled. For details, see "5.19.5 Setting Security Exception".

# 5.1.2.2 Subscribing Alarm Information

You can subscribe alarm event. When a subscribed alarm event is triggered, the system records detailed alarm information at the right side of the interface.



 $\square$ 

#### Functions of different devices might vary.

#### Step 1 Click the Alarm tab.

Figure 5-15 Alarm	(subscription)
-------------------	----------------

	0.000	Tite	aure has	Sec. 7	nam Danial
Case Flat     Value Tacquering     Market Tacquering     Market Tacquering     Market Tacquering     Market Tacquering     Decomp Detection					
and some of	1				
	<ul> <li>India tangang</li> <li>India tangang</li> <li>India tangang</li> <li>India tangang</li> <li>India tangang</li> <li>India tangang</li> </ul>	<ul> <li>Index Torquering</li> <li>Ine part matter</li> <li>Ine part matter</li> <li>Internet December</li> </ul>	<ul> <li>Mako harquning</li> <li>Regal motod.</li> <li>Reg</li> <li>Solonti Excedim</li> </ul>	Exection     Section     Section     Section     Section     Section     Section     Section     Section	Description     Section

<u>Step 2</u> Select **Alarm Type** according to the actual need.

- Select **Prompt**. The system prompts and records alarm information according to actual conditions.
  - When the subscribed alarm event is triggered and the Alarm interface is not displayed, the is displayed on the Alarm tab and the alarm information is recorded automatically. Click the Alarm tab, and this icon disappears.
  - When the subscribed alarm event is triggered and the Alarm interface is displayed, the corresponding alarm information is displayed in the alarm list at the right side of the Alarm interface.
- Select Play Alarm Tone, and select the tone path.
   The system would play the selected audio file when the selected alarm is triggered.

# **5.2 Setting Smart Track**

After setting calibration and parameters for smart track, the tracking speed dome can automatically link to a corresponding position and track an object till it is out of the monitoring range or the set tracking time is reached when the intelligent rules for panoramic camera triggers an alarm.

### **5.2.1 Setting Calibration Parameters for Smart Track**

The camera has calibration parameters by default, and you can modify the parameters manually when the effect is not good with default setting.

 $\square$ 

Auto calibration mode is available on some select models.

<u>Step 1</u> Select Setting > Event > Smart Track > Smart Track.

<u>Step 2</u> Configure calibration parameters.




### Auto calibration

#### Select Auto in Calibration Mode, and then click Start Calibration.




Manual calibration

Select **Manual** in **Calibration Mode**, select the channel that you need, and then add calibration point for it in the live image.









1) Adjust the speed dome lens and turn it to the same view as the chosen lens, and then click 4.

The calibration boxes are displayed in both images.

- 2) Pair each box in the two images, and keep the paired boxes at the same spot of the live view.
- 3) Click 屇.

You need at least 4 pairs of calibration boxes to ensure the views of the speed dome and the panoramic camera as similar as possible.

Step 3 Click Save.

# 5.2.2 Enabling Alarm Track

Alarm Track is disabled by default. Smart Track is enabled only after Alarm Track is enabled and intelligent rules of the panoramic camera are configured. Smart Track is supported only when rules of crowd map, intrusion and tripwire are triggered. See "5.8 Setting IVS" and "5.9 Setting Crowd Map".

<u>Step 1</u> Select Setting > Event > Smart Track > Alarm Track.



	Figure 5-19 A	larm track	
Smart Track	Alarm Track		
_			
Enable			
Auto Track	On	◯ Off	
Track Time	Continue till	object disa	
Idle Time	5	s (1~1800)	
Idle Position	Preset1	•	
Default	Refresh	Save	

- Select the Enable checkbox to enable track linkage.
   After enabling the function, manual positioning, manual tacking and auto tracking take effect.
- Step 3 Set parameters.

Table 5-3 Descri	ption of alarm	track parameters

Parameter	Description
Auto Track	Select <b>On</b> , and the speed dome automatically links to a corresponding position and tracks an object when the intelligent rules of the panoramic camera trigger alarms.
Track Time	<ul> <li>Set the alarm track time.</li> <li>Before an object disappears: The speed dome would automatically link to a corresponding position and tracks an object until the object moves out of the monitoring range when the intelligent rules of the panoramic camera trigger alarms.</li> <li>Custom: Set the auto alarm track time of the speed dome.</li> </ul>
Idle Time	It is an interval from the end of alarm track of the speed dome to the start of idle mode.
Idle Position	Set <b>Idle Time</b> and <b>Idle Position</b> . If no event needs to be tracked after the configured idle time, the device automatically rotates to the set idle position. For example, the <b>Idle Time</b> is set to be five seconds and the <b>Idle Position</b> is set to be preset point 1. When the speed dome does not start tracking after five seconds, it automatically rotates to preset 1.
	To set <b>Idle Position</b> , first set a preset point. For preset point, see "4.3.2.1 Preset".

Step 4 Click Save.

# **5.3 Setting Panoramic Calibration**

The device has calibration parameters by default, and you can modify the parameters manually



when the effect is not good with default setting. Before manually calibrating a channel, clear all default calibration parameters.

**Channel 1** is a PTZ camera. You should calibrate the scene coordinates of **Channel 1** and other channels. Take **Channel 2** as an example.


#### <u>Step 1</u> Select Setting > Event > Panoramic Calibration.

Figure 5-20 Panoramic calibration



<u>Step 2</u> Select channel 2, and then select a calibration number under the video images in turns (See Figure 5-21) to add calibration points to the corresponding video images. Take

Calibrate 1 as an example.





- 1) Adjust the PTZ angle of channel 1 through the PTZ control interface to rotate the center of channel 1 to a position aligned with the green point in **Calibrate 1** image, and then click .
  - Calibration box is displayed in images of **Channel 1** and **Calibrate 1**
- 2) Respectively drag calibration boxes on images of **Channel 1** and **Calibrate 1** to the

corresponding positions. Click 🔚 to save this pair of calibration boxes.

You are recommended to drag calibration box to a static position with clear edges in



the image. This can ensure the edges can be accurately distinguished by the camera. After the calibration record is saved, the calibration box is displayed in yellow. Repeat <u>1</u>) to <u>2</u>) to add at least 4 pairs of calibration points to each calibration picture.

Step 3 Click Save.

# **5.4 Setting Video Detection**

Check whether there are considerable changes on the video by analyzing video images. In case of any considerable change on the video (such as moving object, fuzzy image), the system performs an alarm linkage.

## **5.4.1 Setting Motion Detection**

The system performs an alarm linkage when the moving object appears on the image and its moving speed reaches the preset sensitivity.

 $\square$ 

- If you enable motion detection and smart motion detection simultaneously, and configure the linked activities, the linked activities take effect as following:
  - When Motion Detection is triggered, the camera will record and take snapshots, but other configured linkages such as sending emails, PTZ operation will not take effect.
  - When Smart Motion Detection is triggered, all the configured linkages take effect.
- If you only enable motion detection, all the configured linkages take effect when motion detection is triggered.

<u>Step 1</u> Select Setting > Event > Video Detection > Motion Detection.



Working Period	Setup	
Anti-Dither	5	Second (0~100)
Area	Setup	
Record		
Record Delay	10	Second (10~300)
Relay-out		
Alarm Delay	10	Second (10~300)
📃 Send Email		
🔲 Snapshot		
Default	Refresh	Save


<u>Step 2</u> Select the **Enable** checkbox to enable motion detection function.

<u>Step 3</u> Set the area for motion detection.

1) Click Setup next to Area.



Figure 5-23 Area



- 2) Select a color and set the region name. Select an effective area for Motion Detection in the image and set **Sensitivity** and **Threshold**.
  - Select a color on 
     to set different detection parameters
     for each region

for each region.

- **Sensitivity**: Sensitive degree of outside changes. It is easier to trigger the alarm with higher sensitivity.
- **Threshold**: Effective area threshold for Motion Detection. The smaller the threshold is, the easier the alarm is triggered.
- The whole video image is the effective area for Motion Detection by default.
- The red line in the waveform indicates that the Motion Detection is triggered, and the green one indicates that there is no motion detection. Adjust sensitivity and threshold according to the waveform.
- 3) Click Save.
- Step 4Set arming periods and alarm linkage action. For details, see "5.1.1 Alarm Linkage".Anti-dither: After the Anti-dither time is set, the system only records one motion detection<br/>event in the period.
- Step 5 Click Save.

# 5.4.2 Setting Video Tampering

The system performs alarm linkage when the lens is covered or video output is mono-color screen caused by light and other reasons.

- <u>Step 1</u> Select Setting > Event > Video Detection > Video Tamper.
- Step 2 Select the event type.
  - **Video Tampering**: When the percentage of the tampered image and the duration exceed the configured values, an alarm will be triggered.
  - **Defocus Detection**: When the image is blurred, an alarm will be triggered. This



	Fig	ure 5-24 Video	tampering		
Motion Detection	on Video	Tampering	Scene Changing		
Event Typ	pe	Video Tamper			
Tamper A	Area	100	% (1~100)		
Duration		1	s (1~300)		
Anti-Dithe	er	0	s (0~100)		
Period		Setting			
Record					
Record D	elay	10	s (10~300)		
Relay-out	t				
Alarm De	lay	10	s (10~300)		
Send Em	ail				
V Snapshot	t				
		Default	Refresh	Sa	ive

function is available on some select models.

Table 5-4 Description of video temper parameter

Description
When the percentage of the tampered image and the duration
exceed the configured values, an alarm will be triggered. The tamper area is 30% and the duration is 5 s by default.
Only record one alarm event during the anti-dither period.

Step 3Set arming periods and alarm linkage action. For details, see "5.1.1 Alarm Linkage".Step 4Click Save.

### 5.4.3 Setting Scene Changing

The system performs alarm linkage when the image switches from the current scene to another one. <u>Step 1</u> Select **Setting** > **Event** > **Video Detection** > **Scene Changing**.



10 10 10 10 10 DO	Figure 5-25 Scene changin	1150 VILVIE 324
Notion Detection	Video Tampering	Scene Changing
Enable		
Working Peri	od Setup	
Record		
Record Delay	y 10	Second (10~300)
🔽 Relay-out		
Alarm Delay	10	Second (10~300)
🔲 Send Email		
🔲 Snapshot		
Default	Refresh	Save
Set arming periods an Click <b>Save</b> .	nd alarm linkage action. For	details, see "5.1.1 Alarm Link

# **5.5 Setting Smart Motion Detection**

The system performs alarm linkage when human, non-motorized vehicle, or motor vehicle appear on the image and its moving speed reaches the preset sensitivity. Enabling smart motion detection can avoid the alarms triggered by the environment changes, and the function is enabled by default.

### Prerequisites

- Select **Setting** > **Event** > **Video Detection** > **Motion Detection** to enable the motion detection function.
- You have set **Period** and **Area** in **Motion Detection**, and make sure that the sensitivity value is larger than 0, and the threshold value is smaller than 100.

### Procedure

<u>Step 1</u> Select Setting > Event > Smart Motion Detection.



Figure 5-26 Smart motion detection

t Motion Detectio	n		
VI Enable			
Effective object	🗵 Human	<ul> <li>Motor Vehicle</li> </ul>	
Sensitivity	Middle	•	
	Default	Refresh	Save

<u>Step 2</u> Select the **Enable** checkbox to enable the smart motion detection function.

- <u>Step 3</u> Set effective object and sensitivity.
  - Effective object: Includes **Human** and **Motor vehicle**. When you select **Human**, the camera will detect human and non-motorized vehicle.
  - Sensitivity: Includes **Low**, **Middle**, and **High**. The higher the sensitivity is, the easier the alarm will be triggered.
- Step 4 Click **OK**.

# **5.6 Setting Audio Detection**

The system performs alarm linkage when vague voice, tone change, or sound intensity rapid change is detected.

<u>Step 1</u> Select Setting > Event > Audio Detection.



Enable Input Abno	rmal		
Enable Intensity C	hange		
Sensitivity			
		0	
Threshold	<u> </u>	0	+ 50
and the second second		, and the second se	
- 14 - 14			
han an a	modernessal	la seconda	
	non lassa san l	ereseneder 	
Working Period	Setup		
Working Period Anti-Dither	Setup 5	Sec	cond (0~100)
Anti-Dither		Sec	cond (0~100)
		Sec	cond (0~100)
Anti-Dither			cond (0~100)
Anti-Dither	5		
Anti-Dither <ul> <li>Record</li> <li>Record Delay</li> </ul>	5	Sec	
Anti-Dither <ul> <li>Record</li> <li>Record Delay</li> <li>Relay-out</li> <li>Alarm Delay</li> </ul>	5	Sec	cond (10~300)
Anti-Dither  Record Record Delay  Relay-out Alarm Delay  Send Email	5	Sec	cond (10~300)
Anti-Dither <ul> <li>Record</li> <li>Record Delay</li> <li>Relay-out</li> <li>Alarm Delay</li> </ul>	5	Sec	cond (10~300)

#### <u>Step 2</u> Set parameters.

- Input abnormal: Select the **Enable Input Abnormal** checkbox, and the alarm is triggered when the system detects abnormal sound input.
- Intensity change: Select the **Enable Intensity Change** checkbox and then set **Sensitivity** and **Threshold**. The alarm is triggered when the system detects that the sound intensity exceeds the set threshold.
  - It is easier to trigger the alarm with higher sensitivity or smaller threshold. Set a high



threshold for noisy environment.

- The red line in the waveform indicates audio detection is triggered, and the green one indicates no audio detection. Adjust sensitivity and threshold according to the waveform.
- <u>Step 3</u> Set arming periods and alarm linkage action.
- Step 4 Click Save.

# 5.7 Setting Smart Plan

Smart plan includes face detection, heat map, IVS, people counting, face detection, video metadata, stereo analysis and schedule. The intelligent function can be enabled only after the corresponding smart plan is enabled.

## 5.7.1 Basic Smart Plan

#### <u>Step 1</u> Select Setting > Event > Smart Plan.

The Smart Plan interface is displayed. For smart plan icon, see the table below.

lcon	Description	lcon	Description	lcon	Description
	Face detection	00	Stereo vision		Heat map
Ŕ	Stereo analysis		IVS		Face recognition
<b>n n</b>	People counting		Video metadata		Crowd map
00000	ANPR	 () () () () () () () () () ()	Vehicle density	_	

Table 5-5 Description of smart plan icon

<u>Step 2</u> Enable smart functions as need.

Different cameras support different ways to enable smart functions. Select corresponding ways to enable these functions according to the actual interface.

- Select an icon to enable the corresponding smart plan. Click an icon to enable it, and the selected smart function is highlighted. Click it again to cancel the selection.
  - If the icon off on the interface, click it to enable the smart function switch.
- Enable smart plan through Add Plan.



- Select a preset point from the Add Plan the interface. The smart plan for the point is displayed.
- 2. Click the corresponding icon to enable a smart function.

The selected smart function is highlighted. Click it again to cancel the selection.

Step 3 Click Save.

### 5.7.2 Schedule

After enabling this function, you can configure different smart plans at different periods for your camera.

- <u>Step 1</u> Select **Setting > Event > Smart Plan**.
- Step 2 Enable Schedule.

Nu. Catar	_	Nat	ie.	-	-	-	-	Chan	iși î	-	-	-	_	Notty	Detr
Time Settings															
answere a	0	2	4	6	-	10	12	244	36	166	20	22	24		
Sun	E			111	1.11			1111		1111	1111	111		Setting	
Mon														Setting	
- MAN														Setting	
Tue															
														Contractor of the local division of the loca	
Tue														Setting	
Tue Wed														Setting	

Figure 5-28 Schedule

#### Step 3 Click Add Plan.

- 1. Rename the plan as needed.
- 2. Select smart plan. Other plans which are incompatible with the one that you selected would turn gray.
- 3. Click Save.
- 4. (Optional) Follow <u>Step1</u> to <u>Step3</u> to add more plans. You can add 10 plans at most.
  - Click 📝 to modify the plan added.
  - Click 🤤 to delete the plan.



#### Figure 5-29 Add plan (1)

Plan					E
Plan	Plan1	N			
Channel 1	Face Detector	E Heat Mag		People Counting	
		í	Save	Cancel	

Figure 5-30 Add plan (2)

100	Color	Name	Channel 1	Mosily	Deteta
1		Plant	Finde Datection	1	
2		Plan2	Heat Map	1	•
3		Plan3	IVS	2	٠
- 42	1	Flan4	People Counting	1	


<u>Step 4</u> Configure the time settings.

- 1. Click Settings.
- 2. Configure the period. In the **Smart Plan** list, select the type as needed.
- 3. Click Save.
- 4. (Optional) Repeat step 1-4 to add more plans for different time.
  - You can set up to 6 different plans for one day.
  - One period can only add one smart plan.

#### Figure 5-31 Time settings (1)

xxi2         00         00         00         00         00         00         Smart Plan         NONE         V           xxi3         00         00         00         00         00         00         Smart Plan         NONE         V	V	NONE	Smart Plan	00	00	00 :	$\left[ \pm \right]$	00	00	00 :	Periodit
od3 00 00 00 00 00 Smart Plan NONE V		NONE	Smert Plan	00	00	00	1	00	00	00	Period2
od4 00 00 00 00 00 00 00 Smart Plan NONE V		NONE	Smart Plan	00	00	00	ŀ	00	00	00	Period3
DOLL Real and a second se	*	NONE	Smart Plan	00	00 .	00	-	00	00 .	00 :	Period4
octi 00 00 00 00 00 00 smart Plan NONE 🗸	~	NONE	Smart Flam	00	00	00	1	00	00	00	Percett
od8 00 00 00 - 00 00 00 6mint Plan NONE V	~	NONE	Smart Plan	00	00	00	H	00	00	00 0	Periodà





# **5.8 Setting IVS**

This section introduces scene selection requirements, rule configuration, and global configuration for IVS (intelligent video surveillance).

Basic requirements on scene selection are as follows.

- The target should occupy no more than 10% of the whole image.
- The target size in the image should be no more than 10 × 10 pixels. The size of abandoned object in the image should be no less than 15 × 15 pixels (CIF image). The target height and width should no more less than a third of the image height and width. The recommended target height is 10% of the image height.
- The brightness difference of the target and the background should be no less than 10 gray levels.
- The target should be continuously present in the image for no less than two seconds, and the moving distance of the target should be larger than its width and no less than 15 pixels (CIF image) at the same time.
- Reduce the complexity of surveillance scene as much as you can. Intelligent analysis functions are not recommended to be used in scene with dense targets and frequent illumination change.
- Avoid areas such as glass, reflective ground, water surface, and areas interfered by branch, shadow and mosquito. Avoid backlight scene and direct light.

# **5.8.1 Global Configuration**

Set global rules for IVS, including anti-disturb, depth of field calibration, and valid motion parameter for targets.

### **Calibration Purpose**

Determine corresponding relationship between 2D image captured by the camera and 3D actual object according to one horizontal ruler and three vertical rulers calibrated by the user and the



corresponding actual distance.

#### Applicable Scene

- Medium or distant view with installation height of more than three meters. Scenes with parallel view or ceiling-mounted are not supported.
- Calibrate horizontal plane, not vertical walls or sloping surfaces.
- This function is not applicable to scenes with distorted view, such as the distorted views captured by super wide-angle or fisheye camera.

#### Notes

- Calibration Drawing
  - ◇ Calibration area: The calibration area drawn should be on one horizontal plane.
  - Vertical ruler: The bottom of three vertical rulers should be on the same horizontal plane.
     Select three reference objects with fixed height in triangular distribution as vertical rulers, such as vehicle parked at roadside or road lamp poles. Arrange three persons to draw at each of the three positions in the monitoring scene.
  - Horizontal ruler: Select reference object with known length on the ground, such as sign on the road, or use a tape to measure the actual length.
- Calibration Verification

After setting the ruler, draw a straight line on the image, check the estimated value of the straight line, and then compare this value with the value measured in the actual scene to verify calibration accuracy. In case of major difference between the estimated value and the actual one, fine-tune or reset parameters until the error requirement is met.

#### Procedure

1. Select Setting > Event > IVS > Global Setup.

#### Figure 5-33 Global setup of IVS

Рискиет Анориалования 4 ок с от Биталите
Calibrate Regree Calibrate Regree Calibrate Regree Calibrate Regree Calibrate Regree Calibrate Regree Calibrate Regree New Scale Calibrate Regree Regree Calibrate Regree New Scale Calibrate Regree Regree Calibrate Regree Calibrate Regree Ca
Albancel Parameter
Defect Referin

2. Set parameters.



Parameter	Description
Anti-Disturb Enable	A reserved function.
Sensitivity	Adjust the filter sensitivity. With higher value, it is easier to trigger an alarm when low-contrast object and small object are captured, and the false detection rate is higher.
Tracking Overlap Rate	
Valid Tracking Distance	Reserved functions.
Valid Tracking Time	

Table 5-6 Description of global setup (IVS) parameters

- 3. Set calibration area and ruler.
  - a. Click Add Calibration Area and draw a calibration area in the image.
  - b. Select a calibration type and enter the actual length, and then click Add Rulers.
  - c. Draw one horizontal ruler and three vertical rulers in the calibration area.
- 4. Click Save.

### Result

1. Select the verification type, and then click **Calibration Valid**.

To verify vertical ruler and horizontal ruler, respectively select **Height Verification** and **Width Verification**.

2. Draw a straight line in the image to verify whether the rulers are correctly set.

In case of big difference between the estimated value and the actual one, fine-tune or reset parameters until the error requirement is met.

# 5.8.2 Rule Configuration

Set rules for IVS, including cross fence detection, tripwire, intrusion, abandoned object, moving object, fast moving, parking detection, crowd gathering, and loitering detection.

- Select Setting > Event > Smart Plan, and enable IVS.
- Select Setting > Event > IVS > Global Setup to finish global configuration, and then configure Fast Moving rule.

Rule	Description	Applicable Scene
Tripwire	When the target crosses tripwire from the defined motion direction, the system performs alarm linkages.	Scenes with sparse targets and no occlusion among targets, such as the perimeter
Intrusion	When the target enters, leaves, or appears in the detection area, the system performs alarm linkages.	protection of unattended area.

Table 5-7 Description of IVS functions



Rule	Description	Applicable Scene
Abandoned object	When an object is abandoned in the detection area over the set time, the system performs alarm linkages.	<ul> <li>Scenes with sparse targets and without obvious and frequent light change. Simple scene in the detection area is recommended.</li> <li>Missed alarms might increase in the scenes with dense targets, frequent occlusion, and people staying.</li> <li>In scenes with complex foreground and background, false alarm might be triggered for abandoned or missing object.</li> </ul>
Missing object	When an object is taken out of the detection area over the defined time, the system performs alarm linkages.	<ul> <li>Scenes with sparse targets and without obvious and frequent light change. Simple scene in the detection area is recommended.</li> <li>Missed alarm might increase in the scenes with dense targets, frequent occlusion, and people staying.</li> <li>In scenes with complex foreground and background, false alarm might be triggered for abandoned or missing object.</li> </ul>
Fast moving	When the motion speed is higher than the configured speed, the system performs alarm linkages.	Scene with sparse targets and less occlusion. The camera should be installed right above the monitoring area. The light direction should be vertical to the motion direction.
Parking detection	When the target stays over the configured time, the system performs alarm linkages.	Road monitoring and traffic management.



**Operation Manual** 

Rule	Description	Applicable Scene
Crowd gathering	When the crowd gathers or the crowd density is large, the system performs alarm linkages.	Scenes with medium or long distance, such as outdoor plaza, government entrance, station entrance and exit. It is not suitable for short-distance view analysis.
Loitering detection	When the target loiters over the shortest alarm time, the system performs alarm linkages. After alarm is triggered, if the target stays in the area within the time interval of alarm, then alarm will be triggered again.	Scenes such as park and hall.

Configure IVS rules. This section takes tripwire as an example.

#### $\square$

Go to the **Rule Config** interface of the speed dome, and the PTZ lock function is automatically enabled. The locking time is 180 seconds. You can only manually control the PTZ during the locking time. Click **Unlock** at lower left corner of the **Rule Config** interface to manually unlock the PTZ, and click **Lock** again to relock the PTZ.

<u>Step 1</u> Select Setting > Event > IVS > Rule Config.

<u>Step 2</u> Click 🖶 on the **Rule Config** interface, double-click the name to modify the rule name, and then select **Tripwire** from the **Rule Type** drop-down list.

Figure	5-34 Tripv	vire
riguic	5 5 i iiipv	viic

			1 Patert	f	KARA TOPO	
- I			2 1 Padet		Тприте	
			Parameter Servo			
and the second second	and in case of the local division of the loc	and the second se	P600	SUGRA.		
Heren - A		The second		1. 222		
	And and a second	Landon and	Difection	Acot		
	No.	and the second second		Acot		
	ACCOUNTS ON		Charit Mai Record Record Datas	Acot 10		
			Chest Mai			
Inter Found		Citize Terant	Characteries	10	117-000	

<u>Step 3</u> Click **Draw Rule** to draw rule line in the image. Right-click to finish drawing.
 For requirements of drawing rules, see Table 5-7. After drawing rules, drag corners of the detection area to adjust the area range.



#### Table 5-8 Description of IVS analysis

Rule	Description			
Tripwire	Draw a detection line.			
Intrusion	Draw a detection area.			
Abandoned object	<ul> <li>During the detection of abandoned object, the alarm is also</li> </ul>			
Missing object	triggered if pedestrian or vehicle stays for a long time. If the			
Fast moving	abandoned object is smaller than pedestrian and vehicle, set the target size to filter pedestrian and vehicle or properly			
Parking detection	extend the duration to avoid false alarm triggered by transient			
Crowd gathering	staying of pedestrian.			
Loitering detection	<ul> <li>During the detection of crowd gathering, false alarm might be triggered by low installation height, large percentage of single person in an image or obvious target occlusion, continuous shaking of the camera, shaking of leaves and tree shade, frequent opening or closing of retractable door, or dense traffic or people flow.</li> </ul>			

<u>Step 4</u> (Optional) Click **Draw Target** at the right side of **Target Filter**, and then draw the target in the image.

- When the rule of crowd gathering is configured, you do not need to set target filter, but draw the minimum gathering area. Click **Draw Target** to draw the minimum gathering area in the scene. The alarm is triggered when the number of people in the detection area exceeds the minimum area and the duration.
- Click **Clear** to delete all drawn detection lines.
- Click **Draw Target** at the right side of **Pixel Counter**, and then press and hold the left mouse button to draw a rectangle, the **Pixel Counter** then displays its pixel.

#### <u>Step 5</u> Set rule parameters for IVS.

Parameter	Description
	Set the direction of rule detection.
Direction	• When setting cross fence detection and tripwire, select <b>A-&gt;B</b> ,
Direction	<b>B-&gt;A</b> , or <b>A&lt;-&gt;B</b> .
	• When setting intrusion, select Enters, Exits, or Enter&Exit.
Action	When setting intrusion action, select <b>Appears</b> or <b>Cross</b> .
Object tracking	Select <b>Object Tracking</b> to enable this function. When alarm is triggered by a moving object, select 1P+3 or 1P+5 as the object tracking display mode in the <b>Live</b> interface. Then the tracking scene follows the moving object until the object is out of the camera range. For details, see "4.2.4 Window Adjustment Bar".
	This function is available on some select models.
Track linkage	Select AlarmTrack and set the tracking time. When alarm is

#### Table 5-9 Description of IVS parameters



Parameter	Description
Track Time	<ul> <li>triggered, the camera automatically tracks the person or object that triggers the alarm. Tracking time is the duration that the camera automatically tracks the object.</li> <li>Before enabling this function, you need to enable or disable the Alarm Track function under Smart Track as needed.</li> <li>When the Channel is set as 1, disable Alarm Track under Smart Track.</li> <li>When the Channel is set as 2 or 3, enable Alarm Track under</li> </ul>
	Smart Track.
Al Recognition	<ul> <li>Select Al Recognition to enable this function.</li> <li>When you select Person as the alarm target, an alarm will be triggered when the system detects that persons trigger the rule.</li> <li>When you select Vehicle as the alarm target, alarm will be triggered when the system detects that vehicle trigger the rule.</li> </ul>
Duration	<ul> <li>For abandoned object, the duration is the shortest time for triggering an alarm after an object is abandoned.</li> <li>For missing object, the duration is the shortest time for triggering an alarm after an object is missing.</li> <li>For parking detection, crowd gathering, or loitering detection, the duration is the shortest time for triggering an alarm after an object appears in the area.</li> </ul>
Sensitivity	<ul> <li>For fast moving, sensitivity is related to the triggering speed. Lower sensitivity requires faster moving speed to trigger the alarm.</li> <li>For crowd gathering, sensitivity is related to the alarm triggering time. It is easier to trigger the alarm with higher sensitivity.</li> </ul>

Step 6 Set arming periods and alarm linkage action. For details, see "5.1.1 Alarm Linkage".

Step 7 Click Save.

To view alarm information on the **Alarm** tab, you need to subscribe relevant alarm event. For details, see "5.1.2 Subscribing Alarm".

# 5.9 Setting Crowd Map

You can view crowd distribution on the map in real time for timely arming, to prevent stampede and other accidents.

# 5.9.1 Global Configuration

Set the calibration parameters of panoramic cameras.



### **Calibration Purpose**


Determine corresponding relationship between 2D image captured by the camera and 3D actual object according to one horizontal ruler and three vertical rulers calibrated by the user and the corresponding actual distance.

### Notes

When drawing calibration ruler, keep the ruler length consistent with the actual length of the object.

### Procedure

#### 1. Select Setting > Event > Crowd Map > Global Setup



Crowd Map Global Setup	Perameter Installation registi 0.2 m
State All	Rober Settings
	Ruler # Ventical Forecostal Actual Length 1 m
	Add Rubers Rubers Default Refresh Save

- 2. Set calibration area and ruler.
  - a. Click Add Calibration Area and draw a calibration area in the image.
  - b. Select a calibration type and enter the actual length, and then click **Add Rulers**.
  - c. Draw one horizontal ruler and three vertical rulers in the calibration area.
- 3. Click Save.

### 5.9.2 Rule Configuration

When the number of people or the crowd density in the detection area exceeds the configured threshold, the system performs alarm linkages.


Prerequisites

- Select Setting > Event > Smart Plan, and enable Crowd Map.
- Select **Setting** > **Event** > **Crowd Map** > **Global Setup** to configure the crowd map.



### Procedure

<u>Step 1</u>	Select Setting > Event > Crowd Map > Crowd Map.
---------------	---



- <u>Step 2</u> Select the **Enable** checkbox, and then the crowd map function is enabled.
- <u>Step 3</u> Click **Draw Detection Area** to draw global area for detecting crowd distribution in the image.

After drawing a global area, you can draw multiple local statistical areas in the global area as needed.

1) Click 🔛, and then click **Draw Area** to draw local statistical area in global detection area.

You can draw up to eight local statistical areas.

 Double-click the area name and the alarm people amount to set the area name of local statistical area and the threshold of the alarm people amount.
 When the number of people in the statistical area exceeds the alarm people amount,

the system performs alarm linkages. The default alarm people amount is 20.

Step 4 Set parameters.

Parameter	Description
Global	Select the <b>Global</b> checkbox and set the crowd density threshold.
Crowd Density	The system detects crowd distribution in the global area. When the crowd density exceeds the configured threshold, the system performs alarm linkages.

Table 5-10 Description of crowd map parameters



Parameter	Description
Smart track	<ul> <li>Select the Smart Track checkbox, and when alarm is triggered by the panoramic camera, the speed dome automatically turns to the position where alarm is triggered. The tracking time is "idle time + five seconds." For the details of idle time configuration, see "5.2.2 Enabling Alarm Track"</li> <li>Linkage rules: <ul> <li>Detect global alarm only: Turns to crowd with highest density.</li> <li>Detect local alarm only: Turns to local area that triggers alarm first.</li> <li>Detect global alarm + one local alarm: First turns to local area, and then the crowd with highest density when there is no alarm in local area.</li> </ul> </li> <li>Detect global alarm + multiple local alarms: First turns to local area that triggers alarm first, and then the crowd with highest density when there is no alarm in local area.</li> </ul>
	Before enabling this function, you need to configure Smart Track.
	For details, see "5.2 Setting Smart Track".
Pixel Counter	Click <b>Draw Target</b> next to <b>Pixel Counter</b> , and then press and hold the left mouse button to draw a rectangle, the <b>Pixel Counter</b> then displays its pixel.
Step 5 Set arming periods a	and alarm linkage actions. For details, see "5.1.1 Alarm Linkage"

Step 6 Click Save.

### Result

Click **[11]** on the **Live** interface to view the crowd map.

Figure 5-37 Crowd map (1)



Double-click the rendering area at the lower-right corner in the image to view crowd distribution in the area.

Figure 5-38 Crowd map (2)






# **5.10 Setting Face Recognition**

When a face is detected or recognized in the detection area, the system performs alarm linkage and supports searching face detection and recognition results.

- Face Detection: When a face is detected in the area, the system performs alarm linkage, such as recording and sending emails.
- Face Recognition: When a face is detected in the area, the system compares the captured face image with the information in the face database, and links alarm according to the comparison result.

For the process of setting face recognition, see Figure 5-39.

Figure 5-39 Face recognition flowchart



# 5.10.1 Setting Face Detection

When a face is recognized in the detection area, the system performs alarm linkage.

### Prerequisites

Select Setting > Event > Smart Plan, and then enable Face Recognition.

#### Procedure

<u>Step 1</u> Select Setting > Face Recognition > Face Detection.



Figure 5-40 Face detection

Se Detection Face Distabase Config Ala	im Search	thatsie		
		200 Period	Ues.	
	123	Гара Бацансаланта		
= 0 Y	BSC MO	Report		
	1.1.1.1.1.1	Renorm Delay	10	* (10-30)
2M	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	inst Cross		
	Anna 2 1	shappenel		
E CONTRACTOR AND ALL	1000	Tine-Ising Filles	2 11	
		9740 1933 19930	One-ect phot	12
		blue block	Optimized Se	1010
Difedrapor cuse	Oea		Z ATTAK	55 0
Entrate Re Craw Nash	Close		3) ALCON	w
Transferral Francisco			Abasset	
Tagetfiller @ MacSon (1111 = 1111	Draw Target	1		
O Martina (1997)	Clear	Shable Face Exposu		715475310
Pixel Counter 1	5-1MDW-141906	lace Target Brights (oce Exposure Det.		
		Orthut .	Retails	Sitt,A

<u>Step 2</u> Select the **Enable** checkbox to enable the face detection function.

<u>Step 3</u> (Optional) Click **Draw** next to **Detect Region** to draw a face detection area in the image.

- <u>Step 4</u> (Optional) Click **Draw** next to **Exclude Region** to draw a non-face detection area in the **Detect Region**.
- <u>Step 5</u> (Optional) Select **Max Size** or **Min Size**, click **Draw Target** at the right side of **Target filter**, and then draw the target in the image.
- <u>Step 6</u> Set parameters.

#### Table 5-11 Description of face detection parameters

Parameter	Description
OSD	Select the <b>OSD</b> checkbox, and the number of people with face detected and recognized is displayed on the <b>Live</b> interface. Click <b>Reset</b> to recount.
Face Enhancement	Select the <b>Face Enhancement</b> checkbox to preferably guarantee clear face with low stream.
Non-living Filtering	Filter non-living faces in the image, such as a face picture.



Parameter	Description
	Set a range for snapping face image, including face picture, one-inch picture, and custom.
	When selecting <b>Custom</b> , click <b>Setting</b> , configure the parameters on the prompt interface, and then click <b>OK</b> .
	<ul> <li>Customized width: Set snapshot width; enter the times of the original face width. It ranges from 1–5.</li> </ul>
Snap Face Image	<ul> <li>Customized face height: Set face height in snapshot; enter the</li> </ul>
	times of the original face height. It ranges from 1–2.
	<ul> <li>Customized body height: Set body height: in snapshot; enter the</li> </ul>
	times of the original body height. It ranges from 0–4.
	When the value is 0, it means to cutout the face image only.
	Optimized Snapshot: Capture the clearest picture within the
	configured time after the camera detects face.
	Recognition Priority: Repeatedly compare the captured face to
	the faces in the armed face database, and capture the most similar
Snap Mode	face image and send the alarm. It is recommended to use this
	mode in access control scene.
	Click <b>Advanced</b> to set the optimized time.
Attribute	Select the <b>Attribute</b> checkbox, and click <b>O</b> to set the display of face attribute during the face detection.
	Snapshot Angle Filter: Set snapshot angle to be filtered during
	the face detection.
Advanced	<ul> <li>Snapshot Sensitivity: Set snapshot sensitivity during the face</li> </ul>
	detection. It is easier to detect face with higher sensitivity.
	• <b>Optimized Time</b> : Set a time period to capture the clearest picture after the camera detects face.
Enable Face Exposure	Select the <b>Enable Face Exposure</b> checkbox. When a face is detected, the camera can enhance brightness of the face to make the face image clear.
Face Target Brightness	Set the face target brightness. It is 50 by default.
Face Exposure Detection Interval	Set the face exposure detection interval to prevent image flickering caused by constant adjustment of face exposure. It is five seconds by default.
Pixel Counter	Click <b>Draw Target</b> next to <b>Pixel Counter</b> , and then press and hold the left mouse button to draw a rectangle, the <b>Pixel Counter</b> then displays its pixel.
Step 7 Set arming perio	ods and alarm linkage actions. For details, see "5.1.1 Alarm Linkage".

Step 8 Click Save.

# 5.10.2 Setting Face Database

By setting face database, the face database information can be used to compare with the face



detected.

Face database configuration includes creating face database, adding face picture, and face modeling.

### 5.10.2.1 Creating Face Database

Face database includes face picture, face data and other information. It also provides comparison data for the captured face pictures.

#### <u>Step 1</u> Select Setting > Event > Face Recognition > Face Database Config.

Capacity Limit: Shows the usage of the memory.

man Recognition	Pace Database Config	Alam	Search				
di Face Datub	Casacity Lonit	102%					
M0.	Face Database	Frequence Per	Dooragy	Bintianty Timestold	North	ALC: DIST.	Down
1	. m.	10228	18	ч	1441	Q.	•

#### Step 2 Click Add Face Database.

Figure 5-42 Add face database

Add Face Dat	abase	×
Name		
	OK Cancel	

<u>Step 3</u> Set the name of the face database.

Step 4 Click **OK**.



Figure 5-43 Face database successfully added

ace Elelector	Face Database Config	Alem	Search				
il borniai	Deschjürk 🖢	13%					
110	Fishe Distance	Reputer No.	Deptor	Similarly Thraniska	Mandre	Antonian	Gestite
Ť	E.	8111	35	82		- 69	
2	1900111	4144	25 36	12	100	- 0	:
<u>u</u>	Hot	4143	10	82		4	
4	test_new	4599	-81	42		-	
1	Test_1	0	-	42			0

#### <u>Step 5</u> Set parameters.

Table 5-12 Description	of face database	parameters
------------------------	------------------	------------

Parameter	Description
Deploy	Select the <b>Deploy</b> checkbox, and the face database deployment is enabled. The captured face picture is compared to the armed face database.
Similarity Threshold	The detected face matches the face database only when the similarity between the detected face and the face feature in face database reaches the configured similarity threshold. After successful match, the comparison result is displayed on the <b>Live</b> interface.
MoreInfo	Click <b>MoreInfo</b> to manage face database. You can search face images by setting search conditions, register personnel, and modify personnel information.
Arm/Disarm	Set the alarm time period. Alarm event will be triggered only within the defined time. See "5.1.1.1 Setting Period".
Delete	Delete the selected face database.

### 5.10.2.2 Adding Face Picture

Add face picture to the created face database. Single adding and batch importing are supported. Requirements on face pictures.

- A single face picture size is 50K–150K in JPEG format. The resolution is less than 1080p.
- Face size is 30%–60% of the whole picture. Pixel should be no less than 100 pixels between the ears.
- Taken in full-face view directly facing the camera without makeup, beautification, glasses, and fringe. Eyebrow, mouth and other face features must be visible.

#### 5.10.2.2.1 Single Adding

Add face pictures one by one. Select this way when you need to add a small number of face pictures.

- <u>Step 1</u> Select Setting > Event > Face Recognition > Face Database Config.
- <u>Step 2</u> Click 📄 next to the face database to be set.



Figure 5-44 Face database configuration

BADE   Sace	Database Te	st.1							(L)	Fask Litt
REPH.	-	Gurder	Universed		Data scents	1	74		Modeling Status Link water	
Cressellas T.	Univoided	■ 10.90.			Region	Unimited		Baarce		
Hapstotes	14-00-0		A N	lodeli						

#### Step 3 Click Registration.

 $\square$ 

Figure 5-45 Registration (1)

Registratio	n			23
Upfoad Pictur •				
Numu* Genter Date of Birth	Male	•	Upload Picture	
Region City	Unlimited Custom	•		
Credentals ID No Addrass Nemo				

<u>Step 4</u> Click **Upload Picture**, select a face picture to be uploaded, and then click **Open**.

You can manually select the area for a face. After uploading picture, box select a face and click **OK**. When there are multiple faces in a photo, select the target face and click **OK** to save face picture.



Figure 5-46 Registration (2)

Registratio	n				×
Uproad Pictur	6	OK   Cancel	-		
Nama* Gender Date of Birth Region City	Male Unimited Custom		Ţ		
Gredenfisits ID No Address Nerno		<u>[2]]</u> #			
		Add to task fist	Canos	L	

<u>Step 5</u> Enter the information about face picture according to the actual situation.

Step 6 Click **Add to task list**.

Step 7 Click **Disk List** , and then click **OK**.

The **Task List** interface is displayed. See Figure 5-47. Click **Remove All** to remove all tasks by one click.

Figure 5-47 Task list (manually add)

Add	Statos	
-		
	Status	
Deinte	filature	

If adding user fails, the error code is displayed on the interface. For details, see Table 5-13. For face modeling operation, see "5.10.2.4 Face Modeling".

Table 5-13 Description of error code
--------------------------------------

Parameter	Error	Description
0x1134000C	Picture importing error	The picture is too large, and the upper limit is 150K.
0x1134000E		The quality of the added pictures is to the upper limit.
0x11340019		The space of the face database exceeds the upper limit.



Parameter	Error	Description
1		The picture format is not correct. Import the picture in JPG format.
2		No face in the picture or the face is not clear. Change the picture.
3		Multiple faces in the picture. Change the picture.
4	Disture modeling error	Fails to decode the picture. Change the picture.
5	Picture modeling error	The picture is not suitable to be imported to the face database. Change the picture.
6		The database error. Restart the camera and model faces again.
7		Fails to get the picture. Import the picture again.
8		System error. Restart the camera and model faces again.

#### 5.10.2.2.2 Batch Importing

Import face pictures in batches. Select this way when you need to add a large number of face pictures.

Before importing pictures in batches, name face pictures in a format of "Name#SGender#BDate of Birth#NRegion#TCredentials Type#MID No.jpg" (for example, "John#S1#B1990-01-01#T1#M0000). For naming rules, see Table 5-14.

 $\square$ 

- The max. size of a single face picture is 150K, and the resolution is less than 1080p.
- When naming pictures, Name is required, and others are optional.

Table 5-14 Description of naming rules for batch import parameters

Parameter	Description
Name	Enter a name.
Gender	Enter a figure. "1" is male and "2" is female.
Date of Birth	Enter a figure. Format: yyyy-mm-dd, such as 2017-11-23.
Credentials Type	Enter a figure. "1" is ID card and "2" passport.
ID number	Enter ID No.
Step 1 Select Setting >1	Event > Eace Percentition > Eace Database Config

<u>Step 1</u> Select Setting > Event > Face Recognition > Face Database Config.

<u>Step 2</u> Click [ next to the face database that you want to set.

Step 3 Click Batch Registration.



Figure 5-48 Batch add

Task List		
	+ Supported Picture Format(.jpg)	
Naming Format: Nan	ne#SGender#BDate of Birth#NRegion#TCredentials Typ	e#MID No.
Example: John#S1#B	1990-01-01#NCN#T1#M330501199001016222	
Gender: 1.Male 2.Fen	ale	
Credentials Type: 1.IC	2.Passport 4.Other	
	Deserver	
	Browse Cancel	

Step 4 Click +

to select file path.

Figure 5-49 Batch import

Task List				×
Path:	D:\Human Face			
File Size:	370			
		Browse	Cancel	

Step 5 Click Browse.

The interface shows import process. After finishing the import, the interface shown as Figure 5-50 is displayed.

Figure 5-50 Imported successfully

Task List		×
	Picture import completed!	
🤣 Succee	d:0	
G Fail:1	Check Details	

### 5.10.2.3 Managing Face Picture

Add face pictures to face database, and then manage and maintain face pictures to ensure correct information.



#### 5.10.2.3.1 Modifying Face Information

<u>Step 1</u> Go to the **Face Database Config** interface, set filtering condition as needed, and click **Search**.

The search result is displayed.

<u>Step 2</u> Select the row where the face picture or the personnel information is located, and then click or .



Figure 5-51 Face information modification

Step 3Modify face information according to the actual need. Click Add to task list.Step 4Click Task List, and then click OK.

#### 5.10.2.3.2 Deleting Face Picture

Go to the **Face Database Config** interface, and delete the created face picture.

- Single delete: Select the row where the face picture or the personnel information is located, and click i or click clic
- Batch delete: Select at the upper right corner of the face picture or of the row where the personnel information is located. Select the information, click **Add to Deletion List**, **Tail Lett**, and then click **OK** to delete the selected face picture.
- Delete all: When viewing face pictures in a list, click of the row where the serial number is located; when viewing by thumbnail, select All to select all face pictures. Click Add to Deletion List, making, and then click OK to delete all face pictures.

### 5.10.2.4 Face Modeling

Face modeling extracts face picture information and imports the information to a database to



establish relevant face feature models. Through this function, the face recognition and other intelligent detections can be realized.

Ш

- The more the selected face pictures are, the longer time the face modeling takes. Please wait patiently.
- During modeling, some intelligent detection functions (such as face recognition) are not available temporarily, and will be available after modeling.
- <u>Step 1</u> Select Setting > Event > Face Recognition > Face Database Config.

The Face Database Config interface is displayed.

<u>Step 2</u> Click [] next to the face database to be set.



BACK   Face	Datacese: Te	et_1							<u>iii</u>	Fash Lie
TOPN .		Garder,	Uninted		Data streets	1	74		Modeling Statul Linkwater	
Crietice and T.	Unimbed	<ul> <li>(1) NO.</li> </ul>			Region	Unimited	•	Search.		
Hepstein	Both Hay	and have	00.44 II 4	AD DOM IN	a					

#### Step 3 Start modeling.

• Selective modeling.

If there are many face pictures in the face database, you can set search criteria to select the pictures that need to be modeled.

- 1. Set the search criteria, and click **Search**.
- 2. Select the face pictures to be modeled.
- 3. Click **Modeling**.
- All modeling.

Click **Modeling All** to complete modeling of all face pictures in the face database.

- <u>Step 4</u> View the modeling result.
  - Successful modeling.
    - Figure 5-53 Successful modeling

Task List		×
	Modeling completed.	
📀 Succeed:8		
	Previous	

• Failed modeling.



Figure 5-54 Failed modeling

Task List			×
		Modeling completed.	
🥑 Succee	d:0		
🕒 Fail:1	Search		
		Previous	

Click **Search**, and the face details are displayed. Click to view the face picture in list format. See Figure 5-55. Click to view the face picture in thumbnail format. See Figure 5-56.

- When the modeling status is **Valid** in the list or is displayed on the left corner of the thumbnail, it means the modeling succeeded.
- When the modeling status is **Invalid** in the list or is not displayed on the left corner of the thumbnail, it means the modeling failed. Point to the modeling status in the list or the pictures without to view the details of the failure. Change the pictures according to the details.

#### Figure 5-55 Modeling status (list)

									Energy.
ana		· Daven	connect in the		a and a second second				
Destroy ( Determined)	werner Har	mana a							ININ
	and the second se	and the second second	1700	14.73	1000000		100 million (100 million)	1000	and the second second
1. 11	17. RIN				10	100110	- 1981 C		
					1.4		100	1	-
S	- B.S.						-	1.1	
E + +	e i terret							1	44
	Contract (				1.00		1000001		-
							No be des		

#### Figure 5-56 Modeling status (thumbnail)

i habaaa ha	An Terior
en and a second a balance a second a se	
inement / Berninement / Lanemant / Lanemant	Car de restra montes ( R. )

# 5.10.3 Setting Face Recognition Alarm Linkage

When face recognition succeeded or failed, the device links alarm out.

<u>Step 1</u> Select Setting > Event > Face Recognition > Alarm.



Figure 5-57 Alarm (face recognition)						
Face Detection	Face Database Config	Alarm	Search			
Face Database	Please add face databa	•				
Relay-out	Alarm Channel1	•				
Alarm Rule	Face Recognition Su	cceeded 📃 Fac	e Recognition Failed			
Alarm Delay	1 s (1~300	))				
	Refresh	Save				

<u>Step 2</u> Select a face database and an alarm rule.

- Face recognition succeeded: When the detected face matches that in the face database, the device links alarm out.
- Face recognition failed: When the detected face fails to match that in the face database, the device links alarm out.
- Step 3 Set alarm linkage actions. For details, see "5.1.1 Alarm Linkage"
- Step 4 Click Save.

# 5.10.4 Viewing Face Recognition Result

View face recognition result on the **Live** interface or by the search function.

## 5.10.4.1 Viewing Result in the Live Interface

View face recognition result on the **Live** interface. See Figure 5-58.

- Face recognition result is displayed at the left side and the captured face pictures and attribute information at the right side.
- Click a face picture in the display area, and the information is displayed.




Figure 5-58 Face recognition result



# 5.10.4.2 Viewing Result by Search Function

View face recognition or face snapshot result. Take face recognition search as an example.

## Prerequisites

You have installed a SD card in the camera.

## Procedure

<u>Step 1</u> Select Setting > Event > Face Recognition > Search.

Figure 5-59 Face recognition search

ace Detection	n Face Databa	sse C	onto	Á.	3171	ι.	Search							
τηρο	Pace Srapsh +	ŧ.,												
Shat Terre	2019-07-03		4 20	55	EndTo	ne .	2019-07-04	11	14	20	66	- Administrat Par	Search	
ADP	Unimited .	9	inter	U	ni miteri		EIDTESSION	Uni	ritet		Sist	rates Unit mitac	1 E	
Mauth Model	Unirobed in	l a	ROFID	U	dimited									

# <u>Step 2</u> Select **Face Recognition** for **Type**, enter the start time and the end time, and then click **Search**.

The result is displayed. See Figure 5-60.

- Click Advanced Parameters to set more search conditions.
- Click a search result to view details. See Figure 5-61.

Figure 5-60 Search results (face recognition)

Table Cartaviane	Face Database Carry	Alern	Search	1		-
	Para Recog 1 2019-07-11 10 16 67	30 Janmas	2019-07-02	1 <b>1</b> 9 1	19403	
Total One Co	ed page display 20 + here					натта и Г. (а)



Figure 5-61 MoreInfo (face recognition)

MoreInfo			E
Atarm Info	Face Database		
	Similarly 99% Time 2019-07-12 15:50:54		
Adhibula			
	Age: Young	Gender. Male	
0.00	Expression: Confused	Glasses General	
	Mouth Mask, No	Beard No	
Moreinte			
	Name Jhon		
Sec. 1	Cate of Birth: 1991-05-20	Gender: Male	
	Region Brazil	City: Brasilia	
Y	Credentials Type: Passport	ID No.	
NH	Addistes: Unknown		
	Memo: Linknown		

# **5.11 Setting Face Detection**

When a face is detected in the detection area, the system performs an alarm linkage.

## Prerequisites

Select Setting > Event > Smart Plan, and then enable Face Detection.

#### Procedure

<u>Step 1</u> Select Setting > Event > Face Detection.



Figure 5-62 Face detection

e Detection		
	1 Truthe	
Contraction of the state	- 4 Sec 20 ML [] 080	Cnar
And Shines Steel	Period	entres .
	Fice Email	erael#.
	E Retart	
	Racard Dates	40 6 (10-330)
	This at	1 2
Conception of the local division of the loca	Aturn Datay	10 0150-3001
	E Bant Ercal	
	(IC Brasebot	
Detert Region Craw	Citar diamana	Fitering
	Shap Pate Im	age Cne-lach phota 💌
EXCLUSE FOR DRAW MORE	Clear Druss Node	Optimized Snap +
Tarpet filter 🔿 Man Stas Othit - 1141	Draw Target	12 Abroute 😡
C Man Dice 8 1	Clear	Athanoed
C Mar Dea C 1 F	Draw Target	Laterational
	Lizaw Targel	Epicier
	Linaw Target	Epicier

- <u>Step 2</u> Select the **Enable** checkbox to enable the face detection function.
- <u>Step 3</u> (Optional) Click **Draw** next to **Detect Region** to draw a face detection area in the image.
- <u>Step 4</u> (Optional) Click **Draw** next to **Exclude Region**, and then draw an area excluding face detection in the image.
- <u>Step 5</u> (Optional) Select **Max Size** or **Min Size**, click **Draw Target** at the right side of **Target filter**, and then draw the target in the image.
- <u>Step 6</u> Set parameters.

Table 5-15 Description	of face de	etection parameters
------------------------	------------	---------------------

Parameter	Description
OSD	Select the <b>OSD</b> checkbox, and the number people with face detected and recognized is displayed on the <b>Live</b> interface. Click <b>Clear</b> to recount.
Face Enhancement	Select the <b>Face Enhancement</b> checkbox to preferably guarantee clear face with low stream.
Target Box Overlay	Select the <b>Non-living Filtering</b> checkbox to add a target box to the face in the captured picture to highlight the face. The captured face picture is saved in SD card. Click the <b>Snap Face Image</b> tab to view the captured picture.
Non-living Filtering	Filter non-living faces in the image, such as a face picture.



Parameter	Description
	Set a range for snapping face image, including face picture, one-inch picture, and custom.
	When selecting <b>Custom</b> , click <b>Setting</b> , configure the parameters on the prompt interface, and then click <b>OK</b> .
	Customized width: Set snapshot width; enter the times of the
Snap Face Image	original face width. It ranges from 1–5.
	Customized face height: Set face height in snapshot; enter the times
	of the original face height. It ranges from 1–2.
	<ul> <li>Customized body height: Set body height: in snapshot; enter the</li> </ul>
	times of the original body height. It ranges from 0–4.
	When the value is 0, it means to cutout the face image only.
	Optimized Snapshot: Capture the clearest picture within the
	configured time after the camera detects face.
	• <b>Recognition Priority</b> : Repeatedly compare the captured face to the
	faces in the armed face database, and capture the most similar face
Snap Mode	image and send the event. It is recommended to use this mode in
	access control scene.
	$\square$
	Click <b>Advanced</b> to set the optimized time.
Attribute	Select the <b>Attribute</b> checkbox, and click is to set the display of face attribute during the face detection.
	• Snapshot Angle Filter: Set snapshot angle to be filtered during the
	face detection.
Advanced	Snapshot Sensitivity: Set snapshot sensitivity during the face
	detection. It is easier to detect face with higher sensitivity.
	• <b>Optimized Time</b> : Set a time period to capture the clearest picture after the camera detects face.
Enable Face Exposure	Select the <b>Enable Face Exposure</b> checkbox. When a face is detected, the camera can enhance brightness of the face to make the face image clear.
Face Target Brightness	Set the face target brightness. It is 50 by default.
Face Exposure Detection Interval	Set the face exposure detection interval to prevent image flickering caused by constant adjustment of face exposure. It is five seconds by default.
Pixel Counter	Click <b>Draw Target</b> next to <b>Pixel Counter</b> , and then press and hold the left mouse button to draw a rectangle, the <b>Pixel Counter</b> then displays its pixel.
Step 7 Set arming peri	ods and alarm linkage actions. For details, see "5.1.1 Alarm Linkage".
Step 8 Click Save.	

To view alarm information on the **Alarm** tab, subscribe relevant alarm event. For details, see "5.1.2 Subscribing Alarm".




## Result

The face detection result is displayed on the live interface.

- The face pictures captured in real time and their attribute information is displayed.
- Click a face picture in the display area, and the details are displayed.

#### Figure 5-63 Face detection result



# **5.12 Setting People Counting**

People counting (including enter number, leave number and strand number in area), calibration configuration, queuing number, and view the people counting data in report form.

# 5.12.1 People Counting

The system counts the people entering and leaving the detection area. When the number of counted people exceeds the configured value, the system performs an alarm linkage.

## Prerequisites

Select Setting > Event > Smart Plan, and then enable People Counting.

## Procedure

<u>Step 1</u> Select Setting > Event > People Counting.



People Counting Calibration Config Guidang Report	2 Parameter S Obb	Nama PC-1	Hun Tro People Countin In Area No.	and the second second	0 0
Prov Raie	2 1 9 3 Perandor S	PC-1	People Countin	g 🔄	
Pres Rile	21 3	PC-1			100
Draw Rule	-Parameter S		in Area No.		•
Pres Rive					
Draw Rive					
Erme Rive					
Erme Rive	980	arrb			
Internet in the second se		1	Cea		
Construction Construction	Panat	1	Sitter		
Internet in the second se					
Enternance Construction	Fiburata . Enter No.				
Enternance Construction	Leave No		2	-	
Enternance Construction	Standwo		2		
Draw Line Chee	Cenarceo	ss			
	Pacord IV				
	Hecord D	1990 C		0-300)	
	🖂 Balay-but	ų 🕴	1 2		
	Alam Da	Sec. 13	11 (6)1	1-300)	
	E Sunt Em				
	V Shapshot				
	Olubei Setup	Ś.			
	Sensitive	i ie	=0-	-E7	
	Wax Heig	a 3	220 00.0	D-300)	
	Min Heigh	e i	58 en (	D-201)	
	Default	Auto	at. Dava		
	- Surge		en l serie		

## Figure 5-64 People counting



People Counting Calibration Config	Queung	Report						
	-	biosecout.	21 Ma	Num	10	de Type		-
A CONTRACTOR	A SHEW		Q. 1	1000	Poepla C	Counting	•	•
	4 5	9	<b>2</b> 7	PC-1	in Area f	No		0
			Parameter	Satup				
12 1			Period		Setting			
		6	(7) Region	ul Namber S	tadistics Alares			
	A Reported		Trailde 1	Number	2	(0-80)		
1 -2 -			Type		≥Threshold			
	100	21	C Stard	ng Alarm				
Draw Plate		Dear	(Rishi)	ng Time	30	1 (7-18)	977	
			E Record					
			Rabind	Delay	10	1 (10-3	070	
			E Marg-1	tut	1 2			
			Alate	Dalay	10	0.09-3	90)	
			Send &	intell				
			🗹 Snapst	tot				
			Giotal Set	up.				
			Senitr	vty	· (3)	0	<u>ت</u> ]7	
			Nexth	nght	220	nn (0-3	00)	
			Min He	igin (	50	om (1)-2	an	
			Default		freeha	Sove	ł,	

Figure 5-65 In area No.

<u>Step 2</u> Click 🔛 to add the people counting function.

<u>Step 3</u> Double-click the name to modify the rule name. Select **People Counting** or **In Area No**.

- **People Counting**: The system counts the people entering and leaving the detection area. When the number of counted number of people who enter, leave, or stay in the area exceeds the configured value, the system performs an alarm linkage.
- In Area No.: The system counts the people in the detection area and the duration that people stay in the area. When the number of counted number of people in the detection area or the stay duration exceeds the configured value, the system performs an alarm linkage. This function is available on some select models.
- <u>Step 4</u> Click **Draw Area** to draw a detection area in the image.
  - When setting **People Counting**, you need to draw direction lines. When targets enter or leave along the direction line, they will be counted.
  - For the models that support multiple counting rules, different detection areas can be overlapped.

Step 5 Set parameters.



Parameter	Description
OSD	Select the <b>OSD</b> checkbox or select the <b>Enter No.</b> or <b>Leave No.</b> checkbox under <b>OSD</b> to display the people counting data in the image. Click <b>Clear</b> to clear the count.
Flip	Set the viewing angle of the image as <b>Inclined</b> or <b>Vertical</b> .
Flowrate Alarm	Set <b>Enter No.</b> , <b>Leave No.</b> , and <b>Stranded No.</b> The alarm is triggered when the configured value is reached.
Regional People Number Statistics Alarm	Set the number of people in the people counting region. When the people count reaches the threshold or the stay duration exceeds the configured value, the alarm is triggered.
Inside Number	When you set inside number to be 0, and select the type to be $\geq$
Туре	<b>Threshold</b> , the system will not perform the alarm linkage.
Stranding Alarm	Select the Stranding Alarm checkbox, and then set the stranding time,
Stranding Time	when the stay duration exceeds the configured value, the alarm will be triggered.
Sensitivity	Set the alarm-triggered sensitivity. The higher the sensitivity is, the easier the alarm will be triggered.
Max Height	Set the maximum height of the people in detection area. The unit is cm, and the range is 0–300.
Min Height	Set the minimum height of the people in detection area. The unit is cm, and the range is 0–200.

#### Table 5-16 Description of people counting parameters

Step 6 Set arming periods and alarm linkage actions. For details, see "5.1.1 Alarm Linkage".

Step 7 Click Save.

To view alarm information on the **Alarm** tab, subscribe relevant alarm event. For details, see "5.1.2 Subscribing Alarm".

## Result

You can view the counting results on the **Live** interface.

- For **People Counting** rule, the entry and exit numbers are displayed.
- For In Area No. rule, the inside number is displayed.



Figure 5-66 Counting result



# **5.12.2 Calibration Configuration**

After configuring the rule for people counting, set the installation height and angle of the camera through calibration configuration.

## Prerequisites

You have set at least one rule in **Setting** > **Event** > **People counting** > **People Counting**.

## Procedure

<u>Step 1</u> Select Setting > Event > People Counting > Calibration Config.

Figure 5-67 Calibration configuration (stereo analysis)





<u>Step 2</u>	Click <b>Clear</b> to clear the default calibration box.
<u>Step 3</u>	Click <b>Ground</b> to draw a rectangular box in the image.
	Ground should be on the same plane and as big as possible for calibration.
<u>Step 4</u>	Click Save, and then the camera calculates its height above the ground and the angle it
	forms with the ground.
	If the height and angle are quite different from the actual situation, repeat <u>Step2</u> and
	<u>Step3</u> .

# 5.12.3 Queuing


The system counts the queue people in the detection area. When the queue people number exceeds the configured number or the queue time exceeds the configured time, the alarm is triggered, and the system performs an alarm linkage.

## Prerequisites

Select Setting > Event > Smart Plan, and then enable People Counting.

## Procedure

#### <u>Step 1</u> Select **Setting** > **Event** > **Queuing**.



<u>Step 2</u> Click 🔛 to add the queuing function.



# 

You can add 4 rules at most.

<u>Step 3</u> Double-click the name to modify the rule name. Click **Draw Rule** to draw a detection area in the image, and right-click to complete the drawing.

<u>Step 4</u> Set parameters.

#### Table 5-17 Description of people queuing

Parameter	Description	
Queue People No. Alarm	Set the queue people number for triggering the alarm and	
Queue People No.	counting type. When the queue people number reaches the	
Туре	configured value, the alarm is triggered.	
Queue Time Alarm	Set the queue time. When the queue time reaches the configured value, the alarm is triggered.	
Queue Time		
Sensitivity	Set the alarm-triggered sensitivity. The higher the sensitivity is, the easier the alarm will be triggered.	
Max Height	Set the maximum height of the people in detection area. The unit is cm, and the range is 0–300.	
Min Height	Set the minimum height of the people in detection area. The unit is cm, and the range is 0–200.	

<u>Step 5</u> Set arming periods and alarm linkage actions. For details, see "5.1.1 Alarm Linkage".

#### Step 6 Click Save.

To view alarm information on the **Alarm** tab, subscribe relevant alarm event. For details, see "5.1.2 Subscribing Alarm".

## Result

You can view the queuing result on the **Live** interface.

The queuing number and the stranding time of each target are displayed on the interface.



Figure 5-69 Queuing result



# 5.12.4 Viewing People Counting Diagram

You can search and export the heat map and tracking map according to the set searching criteria. This function is available on some fisheye cameras.

Figure 5-70 Diagram

<u>Step 1</u> Select Setting > Event > People Counting > Diagram.

<u>Step 2</u> Select the **Enable** checkbox to enable diagram function. And then you can search the



diagram during the set period.

<u>Step 3</u> Set the searching criteria.

Table 5-18 Description of searching criteria

Parameter	Description		
Report Type	<ul> <li>Select the report type from the following two types:</li> <li>Heat Map: Density statistics of moving object, the color range is from blue to red, blue means the minimum heat value and red means the maximum heat value.</li> <li>Track Map: Tendency statistics of moving object.</li> </ul>		
Start Time	The start time of the report.		
End Time	The end time of the report.		
Number of People	When selecting heat map as the report type, you can select <b>Number</b>		
Threshold	<b>of People</b> , and set the threshold. The system searches the diagram according to the number of people in the area, and shows the heat map.		
Time	When selecting heat map as the report type, you can select <b>Time</b> , and set the threshold. The system searches the diagram according to the queuing time in the area and shows the heat map.		
Threshold			

<u>Step 4</u> Click **Search** to complete the diagram.

Click **Export** to export the report.

#### Figure 5-71 Diagram



•

With the ruler on the right, you can read the diagram clearly.


# **5.12.5 Viewing People Counting Report**

Generate people counting data in report form.

<u>Step 1</u> Select Setting > Event > People Counting > People Counting Report.



Figure 5-72 People counting report



#### <u>Step 2</u> Set search conditions.

Parameter	Description	
Rule	Select the rule of the report from <b>In Area No</b> and <b>Queuing</b> .	
Statistics Type	<ul> <li>The statistical type of people counting report.</li> <li>When you select Number of people, the system generates the report of the number of people that exceeds the configured number of people.</li> <li>When you select Average stranding time, the system generates the report of the average stranding time that exceeds the average stranding time.</li> </ul>	
Time Range	<ul> <li>Select the period for the report.</li> <li>When selecting <b>People Counting</b>, you can view daily report, monthly report and annual report.</li> <li>When selecting <b>In Area No.</b>, you can view daily report and monthly report.</li> </ul>	
Begin Time		
End Time	The begin time and the end time of people counting.	
People Counting Direction	In and out directions of people counting report. You can select <b>Entrance</b> or <b>Leave</b> . Select <b>Display Data</b> , and the statistical quantity is displayed on the report.	
Stranding Time	Count the stay time, select 5 s, 30 s, or 60 s.	
Queue Time	Count the queuing tine, select 1 minute, 5 minutes, or 10 minutes.	
Report Type (Bar Chart/Line Chart)	Includes bar chart and line chart.	
Rule 1, Rule 2	Select the checkbox to search the report of the corresponding rule.	

<u>Step 3</u> Click **Search** to complete the report.

Click **Export** to export the report in .bmp or .csv format.



# 5.13 Setting Heat Map

Make statistics on the cumulative density of object movement and view heat map in report.

# 5.13.1 Heat Map

Detect the distribution of dynamically moving objects in the target area within a certain period and displays the distribution on a heat map. Color varies from blue to red. The lowest heating value is in blue, and the highest heating value is in red. When mirroring occurs on the camera or the viewing angle changes, original data on the heat map will be cleared.

## Prerequisites

```
Select Setting > Setting > Event > Smart Plan, and then enable Heat Map.
```

## Procedure

<u>Step 1</u> Select **Setting > Event > Heat Map > Heat Map**.

Heat Map	Report				
		- 23	Enable		
Statistica .		TRADE ANA TA	Period	Sating	
- 68)-	1				
-	- Bennies	There are the se			
			Defaut	Refresh	Saw

Figure 5-73 Heat map

- <u>Step 2</u> Select the **Enable** checkbox to enable the heat map function.
- Step 3 Set the arming period. For details, see "5.1.1.1 Setting Period".
- Step 4 Click Save.

# 5.13.2 Viewing Heat Map Report

The system can export heat map data as a report. <u>Step 1</u> Select **Setting** > **Event** > **Heat Map** > **Report**.



Figure 5-74 Heat map report

Heat Wap	Report		
that Time 2019		11 - 111 Evel Time 2012-07-12	12 II Hepertmacronge is 1 week
Beach	Lange I		
		lindll	

<u>Step 2</u> Set the start time and end time.

Only some devices support heat map sequence numbers.

<u>Step 3</u> Click **Search** to complete the report. Click **Export** to export the statistical report.

# **5.14 Setting Vehicle Density**

Configure the rules for traffic congestion and parking upper limit, and view the counting data on the **Live** interface.


## Prerequisites

Select Setting > Event > Smart Plan, and then enable Vehicle Density.

## Procedure

<u>Step 1</u> Select **Setting** > **Event** > **Vehicle Density**.





## Figure 5-75 Vehicle density (traffic congestion)

## Figure 5-76 Vehicle density (parking upper limit)

(V) 1 (V) 2	VD-1 VD-2	Traffic Cargi + 0 Parking Uppi + 0
(V) 2	10-2	Parking Lippi +
		Concert of biggs
Parameter Sala		
Pieriod	Setu	1. C
Repeat Alar	n Time 🛛 0	0 (8-360
() Upper Limit	vened	
Threshold	20	vehicles (10-1000)
Rebard Dela	10	1 (10~300)
C Reley-dut	1 2	
Nam Delay	10	a (10~300)
Dand Ernel		
17 Branchel		
	Select	
	Pierod Repait Alar Digest Linity Threadd Record Data Record Data Name Doby	Repeat Nam Time 0 Upper Linit Vend . Threshold 20 Report Data 10 Report Da

- <u>Step 2</u> Click 🚮 to add the vehicle density function.
- <u>Step 3</u> Double-click the name to modify the rule name. Select **Traffic Congestion** or **Parking Upper Limit**.



- **Traffic Congestion**: The system counts the vehicles in the detection area. When the counted vehicle number and the continuous congestion time exceed the configured values, an alarm is triggered and the system performs an alarm linkage.
- **Parking Upper Limit**: The system counts the vehicles in the detection area. When the counted vehicle number exceeds the configured value, an alarm triggered and the system performs an alarm linkage.
- <u>Step 4</u> Click **Draw Area** to draw a detection area in the image.
- <u>Step 5</u> Set parameters.

Parameter	Description
Repeat Alarm Time	After the alarm is triggered, if the status lasts for the configured time in <b>Repeat Alarm Time</b> , the alarm will be triggered again.
Vehicle Congestion Alarm	Select the checkbox, and set the <b>Threshold</b> and <b>Continuous</b> <b>Congestion Time</b> . When the counted vehicle and the continuous congestion time exceed the configured values, an alarm is triggered.
Upper Limit Vehicle Quantity Alarm	Select the checkbox, and set the <b>Threshold</b> . When the counted vehicle exceeds the configured values, an alarm is triggered.
Pixel Counter	Click <b>Draw Target</b> next to <b>Pixel Counter</b> , and then press and hold the left mouse button to draw a rectangle, the <b>Pixel Counter</b> then displays its pixel.

#### Table 5-20 Description of people counting parameters

<u>Step 6</u> Set arming periods and alarm linkage actions. For details, see "5.1.1 Alarm Linkage".

Step 7 Click Save.

To view alarm information on the **Alarm** tab, subscribe relevant alarm event. For details, see "5.1.2 Subscribing Alarm".

## Result

You can view the counting result on the **Live** interface.

- For **Traffic Congestion** rule, the entry and exit numbers are displayed.
- For **Parking Upper Limit** rule, the inside number is displayed.



Figure 5-77 Traffic congestion



Figure 5-78 Parking upper limit



# **5.15 Setting Stereo Analysis**

Stereo analysis includes rule configuration and calibration configuration.

# **5.15.1 Setting Rules for Stereo Analysis**

The rules for stereo analysis include Activation Analysis, Back Detection, Fall Detection, Walking Detection, Blackboard Writing Detection, Violence Detection, People No. Error, Stand Detection, Running Detection, People Approaching Detection, and Strand Detection.

## Prerequisites

Select **Setting** > **Event** > **Smart Plan**, and then enable **Stereo Analysis** For the functions and applications of the rules, see Table 5-21.



Table 5-21 Description of stereo analysis function				
Rule	Function	Applicable Scene		
Activation Analysis	Working with a recording & broadcasting server, the camera monitors the target's positions in the front of the classroom and analyzes the data, and then generates a report.	Classrooms		
Back Detection	When the camera monitors the front of the classroom works with a recording & broadcasting server, and detects a target with back to the camera, an alarm will be triggered.	Classrooms		
Fall Detection	When walking or standing people in the detection area suddenly fall down on the ground, the alarm will be triggered.	Park and hall		
Walking Detection	When the camera that monitors the front of the classroom works with a recording & broadcasting server, and detects a working target, an alarm will be triggered.	Classrooms		
Blackboard Writing Detection	When the camera that monitors the front of the classroom works with a recording & broadcasting server, and detect blackboard writing actions, an alarm will be triggered.	Classrooms		
Violence Detection	When people walking or standing inside or outside the self-service hall or ATM protection cabin have violent movement (such as smashing ATM machine) or fighting, an alarm will be triggered.	Bank halls and ATM protection cabins		
People No. Error (vary from devices.)	The camera can recognize the real-time number of people in the detection area. When the number of people exceeds the configured value, an alarm will be triggered.	Scenic spots and banks		

## Table 5-21 Description of stereo analysis function



Rule	Function	Applicable Scene
	When a recording & broadcasting server is used, the camera that monitors the front of a classroom needs to be configured this function. With this function, the teacher's actions can be traced and enlarged. When the number of people in the image is not 1, the global image is displayed.	Classrooms
Stand Detection	When a recording & broadcasting server is used, the camera that monitors the area where the students stay needs to be configured with this function. When	
Running Detection	When the camera detects a running person, an alarm will be triggered.	Classrooms
People Approaching Detection	When the distance between two walking/standing people reaches the configured value, an alarm will be triggered.	Banks and educational institutions
Strand Detection	When people in the detection area stay longer than the configured stranding time, an alarm will be triggered.	Banks and parks

This section takes Fall Detection as an example to introduce the configuration of stereo analysis rule.

# Procedure

- <u>Step 1</u> Select Setting > Event > Stereo Analysis > Stereo Analysis.
- Step 2 Click 🔂, double-click the name to modify the rule name, and then select **Fall Detection** as **Rule Type**.

Figure 5-79 Fall detection



Stereo Analysis Calibration Config Zoon Calibration	Report				
		D2 H14	Natri	1 you	ę
		121 1	84-1	Fall Detection	0
		Parameter Setap Period	Settag	1	
	N.	Secondary	1	()	
	_	Repeat Alarm.	a	Sec. (0-300)	
Draw Rom	Clear	E Record	1 2	Tel La Section de la	
		Record Delay	12	a (15-500)	
		C Respy out	1 2	1000	
		Atom Delay	11	s (10~300)	
		Seed Entail			
		PTZ     Inepeter	1 2		
		The second		-	
		Detect	Fishout	Serve	

- <u>Step 3</u> (Optional) Click **Clear** to delete the default rule box, and then click **Draw Rule** to draw a detection area in the image.
  - When configuring **People No. Error** for a recording & broadcasting device, draw the front of a classroom as the detection area.
  - When configuring **Stand Detection** for a recording & broadcasting device, draw the area where the students stay as the detection area.
  - When configuring **Activation Analysis**, draw the front of a classroom as the detection area.
  - When configuring **Back Detection**, draw the front of a classroom as the detection area.
  - When configuring **Blackboard Writing Detection**, draw the blackboard as the detection area, and make sure that the detection are larger than the blackboard. Click **Draw Close-up Area** draw the blackboard as the close-up area.
  - For other devices without special requirements, use the default box of the system (draw the full screen as the detection area).

#### <u>Step 4</u> Set parameters.

Parameters for recording device and common device are different. The actual interface shall prevail.

Parameter	Description	
Sensitivity	Set the alarm-triggered sensitivity. The higher the sensitivity is, the easier the alarm will be triggered.	
Alarm People Amount	When configuring <b>People No. Error</b> , set the alarm people amount	



Parameter	Description
	and alarm type. Alarm type includes <b>Greater than</b> , <b>Equal to</b> , <b>Less than</b> , and <b>Unequal to</b> .
Alarm Type	When the real-time number of people in the detection area is greater than, equal to, less than, or unequal to <b>Alarm People Amount</b> , the alarm is triggered.
Duration	<ul> <li>For People Approaching Detection, when the time for people approaching reaches the configured value, the alarm is triggered.</li> <li>For Fall Detection, when the time of people falling down on the ground reaches the configured value, the alarm is triggered.</li> <li>For People No. Error, when the number of people in the area reaches the configured value of alarm people amount and alarm type, and the time reaches the configured value, the alarm is triggered.</li> </ul>
Close-up Mode	<ul> <li>For people No. error function for a recording device, select Tracking Mode as Close-up Mode. Then the camera traces the teacher's walking trajectory. You can view the tracking effect through sub stream 1 of the live interface. When the number of people on the image is not 1, the full screen is displayed.</li> <li>When setting the stand detection function for a recording device, select Fixed Mode as Close-up Mode. Then sub stream 1 enlarges and displays the image of standing people. When the number of standing people is not 1, the full screen is displayed.</li> <li>Defore viewing the tracking or enlargement effect through sub stream 1, ensure that sub stream 1 is enabled and the resolution of the main stream and sub streams, see "4.5.2.1 Video".</li> </ul>
Repeat Alarm Time	After the alarm is triggered, if the status lasts for the configured time in <b>Repeat Alarm Time</b> , the alarm will be triggered again.
Strand Time Threshold	When configuring Strand Detection, you need to set the strand time threshold. When people in the area stay longer than the configured strand time threshold, the alarm is triggered.

Set arming periods and alarm linkage actions. For details, see "5.1.1 Alarm Linkage".Step 6Click Save.

- Select Setting > Event > Stereo Analysis > Calibration Config to finish calibration configuration for other devices, and then the detection rule becomes valid. For details, see "5.15.2 Calibration Configuration".
- To view alarm information on the Alarm tab, you should subscribe relevant alarm



event. For details, see "5.1.2 Subscribing Alarm".

# 5.15.2 Calibration Configuration

After configuring the rule for stereo analysis, set the installation height and angle of the camera through calibration configuration. There are two calibration modes: Calibration mode 1: Directly enter the installation height and angle according to the actual conditions; calibration mode 2: Draw an area in the image to automatically calculate the installation height and the angle. This section takes calibration mode 2 as an example.

## Prerequisites

You have set at least one rule in **Setting > Event > Stereo Analysis > Stereo Analysis**.

## Procedure

#### <u>Step 1</u> Select Setting > Event > Stereo Analysis > Calibration Config.

Stereo Anatysis Calibration Config Zoom Calibration Report			
1	Type	Rectangle Calibrat	kan 💌
	Installation Height	D	cm (0-1000)
	Installation Angle	0	* (0-90)
ALL IN	Refrach	Save	
Grant			

Figure 5-80 Calibration configuration (stereo analysis)

- <u>Step 2</u> Click **Clear** to clear the default calibration box.
- <u>Step 3</u> Click **Ground** to draw a rectangular box in the image.

Ground should be on the same plane and as big as possible for calibration.

<u>Step 4</u> Click **Save**, and then the camera calculates its height above the ground and the angle it forms with the ground.

If the height and angle are quite different from the actual situation, repeat <u>Step2-Step4</u>.

# 5.15.3 Zoom Calibration

When configuring People No. Error and Stand Detection rule, you need to configure the enlarging zoom in the image of sub stream 1. When the number of people in the image is not 1, the global image (sub stream 1) is displayed.

## Prerequisites

You have set at least one rule in Setting > Event > Stereo Analysis > Stereo Analysis.



 $\square$ 

Zoom configuration is only available on recording & broadcasting devices.

## Procedure

#### <u>Step 1</u> Select Setting > Event > Stereo Analysis > Zoom Configuration.

<u>Step 2</u> Configure the zoom.

- Method 1: Click **Calibration Area**, and then draw a rectangular box in the image, which is size of the enlarged image of sub stream 1.
- Method 2: Set the zoom value. For example, if you want the target to be 1/5 of the image, set the zoom value to 5.

- When calibrating the zoom for Stand Detection, make sure that there is 1 person in the image at least.
- When calibrating the zoom for People No. Error, make the calibration box in the center of the image, and the zoom value larger than 3. Some models only support calibration by drawing calibration area.

 Stores Anayse
 Calibration Coords
 Zoom Calibration
 Report

 Stores Anayse
 Coord
 Sove

#### Figure 5-81 Calibration configuration (stereo analysis)



# 5.15.4 Viewing Report

Working with a recording & broadcasting server, the camera monitors the target's positions in the front of the classroom and analyzes the data, and then generates a report.

## Prerequisites

You have set at least one rule in **Setting > Event > Stereo Analysis > Stereo Analysis**.

## Procedure

- <u>Step 1</u> Select Setting > Event > Stereo Analysis > Report.
- <u>Step 2</u> Select the start time and end time.



You can search for reports within the time range of 30 minutes–24 hours.

- Set the number of screen sections.We recommend splitting the window into 2<sup>n</sup> windows.
- Step 4 Click Search.





# 5.16 Setting ANPR

Extract information of motor vehicles and display related attributes on the live interface.

# 5.16.1 Scene Configuration

Configure non-motor vehicle detection.

## Prerequisites

Select Setting > Event > Smart Plan, and then enable ANPR.

## Procedure

<u>Step 1</u> Select Setting > Event > ANPR > Scene Set.



Figure 5-83 Scene set (ANPR)

				12 11	e Dantre	Rule Text
				191	VehicleClet	a 11 And a start of the second s
and an out	and the	and the second	42-22.75			
- Past	- Startes	N. Come	E and			
-	the talkes	The second second	and the st	: Statistical St		
「日本		and the second		Paramitei a		
	· · · · ·	100	and the state	Trafic R	-	12
	調査です。	The second second	and the state	10.050	Q	n ar
1	and the state of	a design of the second	0	Pened	Set	Ding
A REAL PROPERTY.		A DESCRIPTION OF THE OWNER OWNER OF THE OWNER OWNER OF THE OWNER OWNER OF THE OWNER	and the second	These lite	in Data	
Contraction of the local division of the loc				Scap Mo	an Obre	10191 +
	trave.		Gew	🖂 Capturi	Complete Vehicle	
Dated Region	Haw	-1	Clear.	Captoire	and the second second	
Dated Region	iraw Iraw Nedity	]	Clear		1 🗖 2	\$ (10-300)
Dotted Riegion	iraw Medity	] 	-	🗵 Maring-sa Alianti De	e 1 2	3
Dotect Region Exclude Re Target Riter 1	Nective	]  * (115)  * (115)	Gear	🕢 Matter es	1 🗖 2	s (10-300) 

<u>Step 2</u> Click **Draw** to draw a detect region and an exclude region in the image.

- Detect region: The region that needs to be detected.
- Exclude region: The region that does not need to be detected. Click **Modify** to modify the drawn region.

Click **Clear** at the right side to draw the detection area again.

- <u>Step 3</u> Click **Draw Target** next to **Target Filter** to draw the maximum size and minimum size for the detection target in the image.
- <u>Step 4</u> Configure parameters.

#### Table 5-23 Description of scene set parameters (ANPR)

Parameter	Description		
Traffic Flow Statistics	Select Traffic Flow Stat, and the device detects the number of		
OSD	motor vehicles and non-motor vehicles in the detection area and generates the statistical report. If <b>Traffic Flow Stat</b> is disabled, the report has no statistical data.		
	Select <b>OSD</b> to display the statistical result on the preview interface. To clear the statistical result, click <b>Clear</b> .		
Snap Mode	Select the snap mode: Optimized Snap and Tripwire.		
Relay-out	Select the Relay-out checkbox, and when alarm is triggered, the system interacts with the linked alarm devices.		
Alarm Delay	The Alarm linkage keeps running for the configured time after alarm is ended.		
Step 5 Set arming periods an	d alarm linkage action. For details, see "5.1.1 Alarm Linkage".		

<u>Step 5</u> Set arming periods and alarm linkage action. For details, see "5.1.1 Alarm Linkage".

## Result

The ANPR result is displayed on the live interface.

• The plate no. and attribute information of vehicle are displayed at the right side.

Step 6 Click Save.



• Click the picture in the display area, and the detailed information is displayed.



# 5.16.2 Setting Picture Overlay

Set overlay of motor vehicle.

<u>Step 1</u> Select Setting > Event > ANPR > Picture.

Figure 5-85 Picture



- <u>Step 2</u> Select **Motor Vehicle** from the **Type** drop-down list.
- <u>Step 3</u> Set overlay information and box position, such as plate no., time, car color, car type, and car logo.
- Step 4 Click Save.



# 5.16.3 Viewing ANPR Report

Generate data of ANPR in report form.

<u>Step 1</u> Select **Setting > Event > ANPR > Report**.


# Scene Set Picture Report Result Tale Hear Report Stat Tale Hear Report Stat Tale 2019-07-12 Stat Tale 2019-07-12

<u>Step 2</u> Select the report type, start time, end time, and other parameters.

#### Step 3 Click Search.

The statistical results are displayed. Then click **Export** to export the statistical report.

Figure 5-87 Statistical results



# 5.17 Setting Video Metadata

Classify people, non-motor vehicles and motor vehicles in the captured video, and display the relevant attributes on the live interface.



# 5.17.1 Scene Configuration

Set the detection scenes and rules, including rules for people, non-motor vehicles and motor vehicles.

Select Setting > Event > Smart Plan, and then enable Video Metadata.

Take setting of the People Detection rules as an example.

<u>Step 1</u> Select Setting > Event > Video Metadata > Scene Set.

Figure 5-88 Scene set (video metadata)

scene set	Ficture	Report							_
				12	1986	Flarm	Pule Tra	0 in	6
and the second se				10		Rust	People	•	
All	Contraction of	102 V 1928	In-the area	部	1981	RUIRE	Non-motor	1.	.0
all the second		A AL	THE P	R	- 1	Rule)	Notor Veh	•	
4 - 32		North	e T		ter Setus -				
	ini de la	18 PC		C Traff	io Frew Stat.	Ciese			
1.	NAME OF TAXABLE	Canal Distance		Pen	d.	- Setting			
					uNoda Sire Comple	Optimize te vetacie	e(9)		
DelectRieson	raat .		Clear	(2) Rola		1 2			
Exclude Ro . C	VIICON WEX		Orm	Alar	n Delm	16	8 (10~360)		
Targetfilter # 1	Nie Bizo Billi *	8105	Erew Torget	(Hotal)	ielus				
01	10 Stor 11	1	Qea	ELPen	ey Protection	Face			
PostCauster	a  *	1	Draw Target		manani		and a		
				513	Face Imag	e Onelinci	phore 🖃		
				END	Ner Flore Exp	00410			
				Taca	TargelDig	nin. [5]	0 0	1 50	
						H D()-	-	ΞE	
				9.00		Distant	Valence 💌		
				( Defi		Refeat:			

Step 2 Click 🖶, and double-click the name to modify the rule name, and select **People** in **Rule Type** list.

- <u>Step 3</u> Click **Draw** to draw a detect region and an exclude region in the image.
- <u>Step 4</u> Click **Draw Target** next to **Target Filter** to draw the maximum size and minimum size for the detection target in the image.
- Step 5 Set parameters.

Table 5-24 Description	of scene set parameters	(video metadata)
------------------------	-------------------------	------------------

Parameter	Description
People Flow Statistics	Select the <b>People Flow Statistics</b> checkbox to count the number of people in the detection area.
Traffic Flow Stat	Select the <b>Traffic Flow Statistics</b> checkbox to count the number of motor vehicles in the detection area.



Parameter	Description
Capture whole vehicle	Select the <b>Capture Whole Vehicle</b> checkbox to capture whole vehicle. The snapshot is saved in the preset path for monitoring snapshots. For details, see "4.5.2.5 Path".
Non-motor Vehicle Flow Statistics	Select the <b>Non-motor Vehicle Flow Statistics</b> checkbox to count the number of non-motor vehicles in the detection area.
OSD	Select the <b>OSD</b> checkbox, and the numbers of motor vehicles, non-motor vehicles and people in the detection area are displayed. Click <b>Reset</b> to recount.
Pixel Counter	Click <b>Draw Target</b> next to <b>Pixel Counter</b> , and then press and hold the left mouse button to draw a rectangle, the <b>Pixel Counter</b> then displays its pixel.
Privacy Protection	Select the <b>Privacy Protection</b> checkbox and then select <b>Face</b> or <b>Human body</b> from the drop-down list to blur faces or human bodies in the image.
Face Enhancement	Select the <b>Face Enhancement</b> checkbox to preferably guarantee clear face with low stream.
Snap Face Image	Set a range for snapping face image, including face picture and one-inch picture.
Enable Face Exposure	Select the <b>Enable Face Exposure</b> checkbox to make face clearer by adjusting lens aperture and shutter.
Face Target Brightness	Set the face target brightness, and it is 50 by default.
Face Exposure Detection Interval	Set the face exposure detection interval to prevent image flickering caused by constant adjustment of face exposure. It is 5 seconds by default.
Scene	Set scene as <b>Distant View</b> or <b>Close View</b> .

Step 6 Set arming periods and alarm linkage actions. For details, see "5.1.1 Alarm Linkage".

Step 7 Click Save.

Result

Click 🔯 on the live interface to view the detection results of video metadata.

- The plate no. and attributes of motor vehicle are displayed at the right side, and pictures of people and non-motor vehicles and their attributes at the bottom.
- Click the picture in the display area, and the detailed information is displayed.



Figure 5-89 Video metadata result




# **5.17.2 Setting Picture Information**

Set overlay of motor vehicle, non-motor vehicle and people and the box position. This section takes the configuration of motor vehicle overlay as an example.

<u>Step 1</u> Select Setting > Event > Video Metadata > Picture.

Figure 5-90 Picture (video metadata)



<u>Step 2</u> Select **Motor Vehicle** from the **Type** drop-down list.

Select **Non-motor Vehicle** or **People**, and set non-motor vehicle and people overlay.

<u>Step 3</u> Set overlay information and box position, such as plate no., time, car color, car type, and car logo.

Step 4 Click Save.


# 5.17.3 Viewing Video Metadata Report

Generate data of video metadata recognition in report form.

- Step 1Select Setting > Event > Video Metadata > Report.The Report interface is displayed.
- <u>Step 2</u> Select the report type, start time, end time, and other parameters.
- <u>Step 3</u> Click **Search** to complete the report.

The statistical results are displayed. Click **Export** to export the statistical report.

#### Figure 5-91 Video metadata report



# 5.18 Setting Relay-in

When an alarm is triggered at the alarm-in port, the system performs alarm linkage.

 $\square$ 

Functions might vary with different models.

# 5.18.1 Relay-in (1)

<u>Step 1</u> Select **Setting** > **Event** > **Alarm**.



Figure 5-92 Alarm linkage

Enable	
Relay-in	Alarm1
Period	Setting
Anti-Oither	0 s (0-100) Sensor Type NO 💌
7 Record	
Record Delay	10 s (10~300)
7] Relay-out	1 2
Alarm Delay	10 s (10~300)
] Send Email	
7] Snapshot	
	Default Refresh Save

<u>Step 2</u> Select the **Enable** checkbox to enable the alarm linkage function.

<u>Step 3</u> Select a relay-in port and a sensor type.

- Sensor Type: NO or NC.
- Anti-Dither: Only record one alarm event during the anti-dither period.

<u>Step 4</u> Set arming periods and alarm linkage action. For details, see "5.1.1 Alarm Linkage".

Step 5 Click Save.

# 5.18.2 Relay-in (2)

You can select the mode from **Alarm** and **Arming/Disarming**.

Figur	e 5-93 Select the mode	
Alarm		
Enable		
Relay-in	Alarm1 🗸	
Mode	Alarm Arming/Disarming	

- When selecting Alarm, the function is same as Relay-in (1). For details, see "5.18.1 Relay-in (1)".
- When selecting **Arming/Disarming**, you can enable arming or disarming mode through one press on an external alarm system.
- <u>Step 1</u> Select **Enable** checkbox to enable the alarm function.
- <u>Step 2</u> Select a relay-in port, for details, see "5.18.1 Relay-in (1)".
- <u>Step 3</u> In the **Mode** list, select **Arming/Disarming.**



	Figure 5-94 Arming/Disarming	
Alarm		
Enable		
Relay-in	Alarm1 🗸	
Mode	Arming/Disarming V	
Sensor Type	NO V	
Arming/Disarmin	g	
	Default Refresh	Save

The arming/disarming checkbox is selected by default. Do not cancel the selection; otherwise the configuration is invalid.

<u>Step 4</u> Select the sensor type from **NO** and **NC**.

Step 5 Click Save.

## **5.19 Setting Abnormality**

Abnormality includes SD card, network, illegal access, voltage detection, and security exception.

 $\square$ 

Only the device with SD card has the abnormality functions, including **No SD Card**, **SD Card Error**, and **Capacity Warning**.

### 5.19.1 Setting SD Card

In case of SD card abnormality, the system performs alarm linkage. The event types include **No SD Card**, **Capacity Warning**, and **SD Card Error**. The introduction is for reference only, and may differ from the actual interface.

<u>Step 1</u> Select Setting > Event > Exception Handling > SD Card.



	Figure 5-95	SD card	
SD Card	Network	Illegal Access	Security Exception
Event Type	No SD Card	•	
<ul> <li>Relay-out</li> <li>Alarm Delay</li> <li>Send Email</li> </ul>	1 2	s (10~300)	
	Default	Refresh	Save

- Step 2Select the event type from the Event Type drop-down list, and then select the Enable<br/>checkbox to enable the SD card detection function.When setting Capacity Warning as Event Type, set Capacity Limit. When the remaining
- space of SD card is less than this value, the alarm is triggered.
- <u>Step 3</u> Set alarm linkage actions. For details, see "5.1.1 Alarm Linkage".
- Step 4 Click Save.

### 5.19.2 Setting Network

In case of network abnormality, the system performs alarm linkage. The event types include **Disconnection** and **IP Conflict**.

<u>Step 1</u> Select Setting > Event > Abnormality > Network.

Figure 5-96 Network Security Exception SD Card Network Illegal Access Event Type Disconnection Ŧ Enable Record 10 s (10~300) Record Delay 2 Relay-out 1 10 s (10~300) Alarm Delay Default Refresh Save Step 2 Select the event type from the Event Type drop-down list, and then select the Enable



Step 3Set alarm linkage actions. For details, see "5.1.1 Alarm Linkage".Step 4Click Save.

### 5.19.3 Setting Illegal Access

When you enter a wrong login password more than the set times, the system performs alarm linkage.

#### <u>Step 1</u> Select **Setting > Event > Abnormality > Illegal Access**.

	Figure 5-97 Ille	egal access	
SD Card	Network	lllegal Access	Security Exception
Enable			
Login Error	5	time (3~10)	
Relay-out	1 2		
Alarm Delay	10	s (10~300)	
Send Email			
	Default	Refresh	Save

<u>Step 2</u> Select the **Enable** checkbox to enable the illegal access detection function.

Step 3 Set Login Error.

If you consecutively enter a wrong password more than the set value, the account will be locked.

- <u>Step 4</u> Set alarm linkage actions. For details, see "5.1.1 Alarm Linkage".
- Step 5 Click Save.

### **5.19.4 Setting Voltage Detection**

When the input voltage is higher than or lower than the rated value of the device, the system performs alarm linkage.

<u>Step 1</u> Select Setting > Event > Abnormality > Voltage Detection.



SD Card	Network	Illegal Access	Voltage Detection Security Exception
😨 Enable			
Vienar			
📄 Send Email			
	Default	Refresh	Save

<u>Step 2</u> Select the **Enable** checkbox to enable the voltage detection function.

Select **Overlay**, and the alarm icon is displayed by overlapping when the alarm is triggered.

- indicates undervoltage and 🐞 indicates overvoltage.
- Step 3 Set alarm linkage actions. For details, see "5.1.1 Alarm Linkage".
- Step 4 Click Save.

### **5.19.5 Setting Security Exception**

When a hostile attack is detected, the system performs alarm linkage.

- <u>Step 1</u> Select Setting > Event > Abnormality > Security Exception.
- <u>Step 2</u> Select the **Enable** checkbox.

#### Figure 5-99 Security exception

SD Card	Network	Illegal Access	Voltage Detection	Security Exception
Enable				
Event Monitorin	ю			
🔄 Trusted e	nvironment detected pr	ogr 📃 Brute to	rce attack of web path	
Account I	ogin exceeds the set lin	ter 🛛 Session	connection exceeds limit	r.
Session I	D Brute Force Attack			
2 Relay-out	192			
Alarm Delay	10	\$ (10~300)		
Send Email				
	Default	Retresh	Save	7
	14-			

<u>Step 3</u> Select the event to be monitored as needed.



Parameter Description		
Farameter	Description	
Trusted environment detected program	Monitors the programs that run in trusted environment to detect whether there are program running without trusted signature.	
	Select it to prevent the program with trojan and virus.	
Account login exceeds the set	The account tries to login during the period that does not allow user to log in.	
time range	Configure <b>Restricted Login</b> in <b>Setting</b> > <b>System</b> > <b>Account</b> > <b>Account</b> > <b>Username</b> , including the IP address, validity period, and time range.	
Session ID Brute Force Attack	When sessionid false reaches the configured threshold in the defined period, an alarm will be triggered.	
Session ID Brute Force Attack	Select it to monitor attacks in real time, so that attacks can be prevented timely.	
Brute force attack of web path	Generates the web serve directory and send a request through enumeration. When URL false reaches the configured threshold in the defined period, an alarm will be triggered.	
	Select it to monitor attacks in real time, so that attacks can be prevented timely.	
Session connection exceeds limit	The number of users (web, platform or mobile phone client) exceeds the max number of users that can connect to the device simultaneously.	
	Configure the <b>Max Connection</b> in <b>Setting</b> > <b>Network</b> > <b>Port</b> .	

Table 5-25 Security exception description

<u>Step 4</u> Set alarm linkage actions. For details, see "5.1.1 Alarm Linkage".

Step 5 Click Save.

## 5.19.6 Setting Disarming

You can disable the linkage actions through the app on your smart phone, and then the system will not perform any linkage action, but alarm records will still be generated.

<u>Step 1</u> Select **Setting** > **Event** > **Disarming**.



#### Figure 5-100 Disarming

Disarming	Enable O Close	
Disarm by Period Disarm Period	Enable (Disarm by Period will be v	alid after one-click disarm is disabl
Disarm Alarm Linka		
	Select All	
	Relay-out	
	Send Email	
	Audio Linkage	
	Varning Light	
	Default Refresh	Save

- <u>Step 2</u> Select the **Enable** checkbox to disarm.
- <u>Step 3</u> (Optional) Select the **Enable** checkbox next to **Disarm by Period** to enable the Disarm by Period function, and then you can disarm by period. For setting disarm period, see "5.1.1.1 Setting Period".

This function is only valid when **Disarming** is disabled.

- <u>Step 4</u> Select alarm linkage actions as needed.
- Step 5 Click Save.



# 6 Maintenance

## **6.1 Requirements**

To make sure the system runs normally, maintain it as the following requirements:

- Check surveillance images regularly.
- Clear regularly user and user group information that are not frequently used.
- Modify the password every three months. For details, see "4.8.3 Account".
- View system logs and analyze them, and process the abnormity in time.
- Back up the system configuration regularly.
- Restart the device and delete the old files regularly.
- Upgrade firmware in time.

## 6.2 Auto Maintain

You can restart the system manually, and set the time of auto reboot and auto deleting old files. This function is disabled by default.

### <u>Step 1</u> Select Setting > System > Auto Maintain.



Step 2 Configure auto maintain parameters.

- Select the **Auto Reboot** checkbox, and set the reboot time, the system automatically restarts as the set time every week.
- Select the **Auto Delete Old Files** checkbox, and set the time, the system automatically deletes old files as the set time. The time range is 1 to 31 days.

### A

When you enable and confirm the Auto Delete Old Files function, The The deleted files cannot be restored, are you sure? notice is displayed. Operate it carefully.

• Click **Manual Reboot**, and then click **OK** on the displayed interface, the camera will restart.

Step 3 Click OK.

## 6.3 Resetting Password

When you need to reset the password for the admin account, there will be a security code sent to




the entered email address which can be used to reset the password.

### Prerequisites

You have enabled password reset service. For details, see "4.8.4.1 System Service".

### Procedure

<u>Step 1</u> Open IE browser, enter the IP address of the device in the address bar and press Enter.



a	Jhua			
	Username:		_	
	Password.			Forgol pasaword?
	1	Login	Cancel	
	į	Login	Cancel	

#### Step 2 Click Forgot password?

#### Figure 6-3 Prompt

A1954		ã
	THE REPORT OF A DESCRIPTION OF A DESCRIP	
	Conditional Conditional	

Step 3 Click OK.



Clicking **OK** means that you are informed that some of your personal data might be collected to help reset the password, such as phone number, MAC address, and device serial number. Read the prompt carefully to decide whether to authorize the collection activity.



#### Figure 6-4 Reset the password (1)

SR 2004AB9V	AZ00019	
QR code:		telFor attain only: ton 1. Please download Easi/4p and then from Bothings-Recet davice pasaword, scan the left code ton 2. Please use an APP to scan the left QR to get special strings. And then send the rigs to support_rowd@global.dabustech.com
	The security code will be delivered to 1***@qq.com	
Security orde:		

#### <u>Step 4</u> Reset the password.

- <u>Step 5</u> Scan the QR code, and there will be a security code sent to the email address you entered. Enter the security code as instructed.
  - Please use the security code within 24 hours after you receive it. Otherwise, it will become invalid.
  - If you fail to use the security code for two times continuously, there will be fail notice when you try to get a security code for the third time. You have to reset the device to get a security code or wait 24 hours to get it again.
- Step 6 Click Next.

Ŵ

set the passwor	rð(2:2)	
Usemame	adow	
Passwort		
	MARK READE DIVING	
	Use a password that has 8 to 32 characters. #	
	can be a combination of letter(s), number(s) and symbol(s) with at least two kinds of them.	
	(please do not use special symbols like (* _ & )	
Confirm Password	1	
	Cancel Save	

<u>Step 7</u> Reset and confirm the password.

The password must consist of 8 to 32 non-blank characters and contain at least two types of characters among upper case, lower case, number, and special character (excluding ' ";: &).



Step 8 Click Save.

## 6.4 Backup and Default

### 6.4.1 Import/Export

- Export the system configuration file to back up the system configuration.
- Import system configuration file to make quick configuration or recover system configuration.

### <u>Step 1</u> Select Setting > System > Import/Export.

	Figure 6-6 lm	port/Export	
Import/Exp	ort		
Backup Pa	th		
Imp	ort Export		

### Step 2 Click Import or Export.

- Import: Select local configuration file, and click **Open** to import the local system configuration file to the system.
- Export: Select the storage path, and click **Save** to export the system configuration file to local storage.
- <u>Step 3</u> Click **Save** to finish configuration.

### 6.4.2 Default

Restore the device to default configuration or factory settings.

## Ŵ

This function will restore the device to default configuration or factory setting.

### Select Setting > System > Default.

- Click **Default**, and then all the configurations except IP address and account are reset to default.
- Click **Factory Default**, and all the configurations are reset to factory settings.

Figure 6-7 Default

Default	
Default	Other configurations will be recovered to default except network IP address, user management and so on.
Factory Default	Completely recover device parameters to factory default.



## 6.5 Upgrade

Upgrading to the latest system can perfect camera functions and improve stability.

 $\square$ 

If wrong upgrade file has been used, restart the device; otherwise some functions might not work properly.

<u>Step 1</u> Select **Setting** > **System** > **Upgrade**.

Figure 6-8 Upgrade

Galaci Fernivara File		Browne	Linguide	
Online Upgrade				
V Auto-check for applates	Save			
Dyakant Version	2.300.0031000.1.PL Build Cale 2015-2	547	Hamaal Church	

<u>Step 2</u> Select upgrading method according to the actual needs.

- File Upgrade
  - 1. Click **Browse**, and then upload upgrade file.
  - 2. The upgrade file should be a .bin file.
  - 3. Click Upgrade.

The upgrade starts.

- Online Upgrade
  - 1. Select the Auto-check for updates checkbox.

The system checks for upgrade once a day automatically, and there will be system notice if any upgrade is available.



We need to collect the data such as device name, firmware version, and device serial number to proceed auto-check. The collected information is only used for verifying the legality of cameras and upgrade notice.

2. If there is any upgrade available, click **Upgrade**, and then the system starts upgrading.

Click Manual Check to check for upgrade manually.

## 6.6 Information

You can view the information, including version, log and online user, and back up or clear log.



### 6.6.1 Version

You can view device information such as hardware, system version, and web version. Select **Setting** > **Information** > **Version** to view the version information.

### 6.6.2 Log

You can view and back up logs.

<u>Step 1</u>	Select Setting > Information > Log.
---------------	-------------------------------------

Figure 6-9 Log

	And the second second	al management	111 318 4	1 - 11 - 12 - 12	100 March 100	
itat Tine	2019-37-17	19 . 25	and the second second second	8019-87-18	19 19 25	40
111	AL.	E Deved	211	UNATIONE		Long Travel
162		es lina		Operana		Logiter
uded in form	100					
	1501					
NFC.	1841					
ne: Altione	1944					
salad intern raj Amaria pr	1101					
w marke e						
w marie e						
n enore e	-					N 4 11 P N 1

<u>Step 2</u> Configure **Start Time** and **End Time**, and then select the log type.

The start time should be later than January 1st, 2000, and the end time should be earlier than December 31, 2037.

The log type includes All, System, Setting, Data, Event, Record, Account, and Safety.

- **System**: Includes program start, abnormal close, close, program reboot, device closedown, device reboot, system reboot, and system upgrade.
- Setting: Includes saving configuration and deleting configuration file.
- **Data**: Includes configuring disk type, clearing data, hot swap, FTP state, and record mode.
- **Event** (records events such as video detection, smart plan, alarm and abnormality): includes event start and event end.
- **Record**: Includes file access, file access error, and file search.
- Account: Includes login, logout, adding user, deleting user, modifying user, adding group, deleting group, and modifying group.
- Safety: Includes password resetting and IP filter.
- Step 3 Click Search.
  - Click a certain log, and then you can view the detailed information in Detailed



Information area.

• Click **Backup**, and then you can back up all found logs to local PC.

startlina	2015-07-17	* 10	25 42	EvelTimo	2019-87-18	-71	19 2	5 40		
Test.	41		Reamth	Find 79 kig The	w 2019.87.17 18:55:00		2.51.56.8	8.99		
No	44	afirm			Licereates				Log Typi	
1	1919-07	10 10 22 21			807m				Side Thread	
.1	23.92-07	12 12 21 11			admin.				Set Time	
3	20 10-07	10 10 50 51			admin -				Sat Time	
	23 43-07	10 12 10 10			sarin				Lagia	
3	2215-07	-10 10.17.41			#3181				Legest	
	3848-07	10 10 11 11			edmin.				Det Time	
37	13 (3-07	10.10.01.11			63191				Sel Tree	
- 11	25 10-07	11 17.58.51			k3rm				Sel Traie	
1.4	29 10-07	-99 17,31.38			kauwi				Sel Time.	
18	29 10 10	98.7C37.38			adren				Bet THEM	
Decailed Inform toole Solerinatio Type Cardant										
George .	Î								HE # 1711	N E B

## 6.6.3 Remote Log

Configure remote log, and you can get the related log by accessing the set address.

### <u>Step 1</u> Select Setting > Information > Remote Log.

	Figure 6-11 Remote log
Log Re	emote Log
Enable	
IP Address	182. 188. 4 . 188.
Port	514 (1~65534)
Device Number	22 (0~23)
	Default Refresh Save

- <u>Step 2</u> Select the **Enable** checkbox to enable remote log function.
- <u>Step 3</u> Set address, port and device number.
- Step 4 Click Save.

### 6.6.4 Online User

View all the current users logging in to web.



### Select Setting > Information > Online User.

### Figure 6-12 Online user

Online User				
No.	Username	User Local Group	IP Address	User Login Time
1	admin	admin	10.000	2020-01-14 15:02:04
Refresh				



# **Appendix 1 Cybersecurity Recommendations**

Cybersecurity is more than just a buzzword: it's something that pertains to every device that is connected to the internet. IP video surveillance is not immune to cyber risks, but taking basic steps toward protecting and strengthening networks and networked appliances will make them less susceptible to attacks. Below are some tips and recommendations from Dahua on how to create a more secured security system.

### Mandatory actions to be taken for basic equipment network security:

### 1. Use Strong Passwords

Please refer to the following suggestions to set passwords:

- The length should not be less than 8 characters.
- Include at least two types of characters; character types include upper and lower case letters, numbers and symbols.
- Do not contain the account name or the account name in reverse order.
- Do not use continuous characters, such as 123, abc, etc.
- Do not use overlapped characters, such as 111, aaa, etc.

### 2. Update Firmware and Client Software in Time

- According to the standard procedure in Tech-industry, we recommend to keep your equipment (such as NVR, DVR, IP camera, etc.) firmware up-to-date to ensure the system is equipped with the latest security patches and fixes. When the equipment is connected to the public network, it is recommended to enable the "auto-check for updates" function to obtain timely information of firmware updates released by the manufacturer.
- We suggest that you download and use the latest version of client software.

### "Nice to have" recommendations to improve your equipment network security:

### 1. Physical Protection

We suggest that you perform physical protection to equipment, especially storage devices. For example, place the equipment in a special computer room and cabinet, and implement well-done access control permission and key management to prevent unauthorized personnel from carrying out physical contacts such as damaging hardware, unauthorized connection of removable equipment (such as USB flash disk, serial port), etc.

### 2. Change Passwords Regularly

We suggest that you change passwords regularly to reduce the risk of being guessed or cracked.

### 3. Set and Update Passwords Reset Information Timely

The equipment supports password reset function. Please set up related information for password reset in time, including the end user's mailbox and password protection questions. If the information changes, please modify it in time. When setting password protection questions, it is suggested not to use those that can be easily guessed.

#### 4. Enable Account Lock

The account lock feature is enabled by default, and we recommend you to keep it on to guarantee the account security. If an attacker attempts to log in with the wrong password several times, the corresponding account and the source IP address will be locked.



### 5. Change Default HTTP and Other Service Ports

We suggest you to change default HTTP and other service ports into any set of numbers between 1024–65535, reducing the risk of outsiders being able to guess which ports you are using.

### 6. Enable HTTPS

We suggest you to enable HTTPS, so that you visit Web service through a secure communication channel.

### 7. MAC Address Binding

We recommend you to bind the IP and MAC address of the gateway to the equipment, thus reducing the risk of ARP spoofing.

### 8. Assign Accounts and Privileges Reasonably

According to business and management requirements, reasonably add users and assign a minimum set of permissions to them.

### 9. Disable Unnecessary Services and Choose Secure Modes

If not needed, it is recommended to turn off some services such as SNMP, SMTP, UPnP, etc., to reduce risks.

If necessary, it is highly recommended that you use safe modes, including but not limited to the following services:

- SNMP: Choose SNMP v3, and set up strong encryption passwords and authentication passwords.
- SMTP: Choose TLS to access mailbox server.
- FTP: Choose SFTP, and set up strong passwords.
- AP hotspot: Choose WPA2-PSK encryption mode, and set up strong passwords.

### 10. Audio and Video Encrypted Transmission

If your audio and video data contents are very important or sensitive, we recommend that you use encrypted transmission function, to reduce the risk of audio and video data being stolen during transmission.

Reminder: encrypted transmission will cause some loss in transmission efficiency.

### 11. Secure Auditing

- Check online users: we suggest that you check online users regularly to see if the device is logged in without authorization.
- Check equipment log: By viewing the logs, you can know the IP addresses that were used to log in to your devices and their key operations.

### 12. Network Log

Due to the limited storage capacity of the equipment, the stored log is limited. If you need to save the log for a long time, it is recommended that you enable the network log function to ensure that the critical logs are synchronized to the network log server for tracing.

### 13. Construct a Safe Network Environment

In order to better ensure the safety of equipment and reduce potential cyber risks, we recommend:

- Disable the port mapping function of the router to avoid direct access to the intranet devices from external network.
- The network should be partitioned and isolated according to the actual network needs. If there are no communication requirements between two sub networks, it is suggested to use VLAN, network GAP and other technologies to partition the network, so as to achieve the network isolation effect.



- Establish the 802.1x access authentication system to reduce the risk of unauthorized access to private networks.
- Enable IP/MAC address filtering function to limit the range of hosts allowed to access the device.

### More information

Please visit Dahua official website security emergency response center for security announcements and the latest security recommendations.

Поставщик систем безопасности TELECAMERA.RU

### ENABLING A SAFER SOCIETY AND SMARTER LIVING