

RVi

RU



**RVi-IPN16/8-PRO**







	<b>RVi-IPN16/8-PRO</b>
	.264
	16
	1 HDMI, 1 VGA, 1 BNC
( )	1920×1080, 1280×1024, 1280×720, 1024×768, 800×600
/	1 (BNC) / 1 (BNC)
	G.711A
\	16/6
	75 10
( )	5MP(2560x1920) / 3MP(2048x1536) / 1080P(1920x1080) / 720P(1280x720) / D1 (704.576/704x480)
	400 / (1080p), 400 / (720p)
/	, , , 30 / 300
HDD	SATA3 4
HDD	8 HDD SATA+4 HDD eSATA
USB	4 . (2 )
RS485	PTZ
RS232	, , ,
	32 SATA + 16 eSATA
	, / ( , , ),
	1 Gbit Ethernet
	HTTP, IPv4/IPv6, TCP/IP, UPNP, RTSP, UDP, SMTP, NTP, DHCP, DNS, PPPOE, DDNS, FTP, IP
	web- (IE, Google chrome, Firefox Mozilla,Opera) C RVi-PSS Windows XP Windows 7, MAC OS. : S Symbian, S Windows mobile, S Android, S Blackberry, i S.
	IP- RVi
	20
	/
	22 18 , 6
	-10...+55 °C
	100-240 AC, 40 HDD
	440x460x89 ( )
	6 HDD


- SATA 1 .
- USB 8 .
- CD ( 1 .
- 19" 1 .
- 1 .



1.

1

1		.
2		( / ) .
3		.
4	0-9	.
5		USB
6	REC	
7	Fn	
8	ESC	



## HDD

SATA


HDD

HDD.




HDD

SATA



**Enter**



- : admin. : admin. ( , )
- : 888888. : 888888. ( , )
- : default. : default ( )

USB-



( ).


:

## WEB-

web- NVR  
ping \*\*\*.\*\*\*.\*\*\*.\*\*\*(\* IP NVR) 255.  
TTL NVR.  
IE : IP 192.168.1.108.  
http://192.168.1.108 Internet Explorer.

« ».

ActiveX,



»,

« ».

«

».

IP


«  
DVR.

WEB

admin

admin.

« ».



WEB


4

:



WEB

:



:

CD

<http://www.rvi-cctv.ru/>



( , . . ) ,  
69. 5 15150-

NVR  
1 15150-69.

- 36



Web

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

:

\_\_\_\_\_



BY

# RVi- IPN16/8-PRO



	<b>RVi-IPN16/8-PRO</b>
	.264
	16
	1 HDMI, 1 VGA, 1 BNC
( )	1920×1080, 1280×1024, 1280×720, 1024×768, 800×600
/	1 (BNC) / 1 (BNC)
	G.711u
	75 10
( )	5MP(2560x1920) / 3MP(2048x1536) / 1080P(1920x1080) / 720P(1280x720) / D1 (704.576/704x480)
	400 / (1080p), 400 / (720p)
	, , ,
/	30 / 300
HDD	SATA3 4
HDD	8 HDD SATA+4 HDD eSATA
USB	4 (2 )
RS485	PTZ
RS232	
,	32 SATA + 16 eSATA
	, / ( , ),
	1 Gbit Ethernet
	HTTP, IPv4/IPv6, TCP/IP, UPNP, RTSP, UDP, SMTP, NTP, DHCP, DNS, PPPOE, DDNS, FTP, IP i e
	web- (IE, Google chrome, Firefox Mozilla,Opera)
C	RVi PSS Windows XP Windows 7, MAC OS.
	: S Symbian, S Windows mobile, S Android, S Blackberry, i S.
	20
	/
	22 18 , 6
	-10...+55 °C
	100-240 AC, 40 HDD
	440x460x89 ( )
	6 HDD

SATA  
USB

CD (





19 "

1 .  
8 .  
1 .  
1 .  
1 .  
1 .




1.

1

1		.
2		( / ) .
3		.
4	0-9	.
5		USB
6	REC	
7	Fn	
8	ESC	

«RVI»

«RVI»



## HDD

SATA


HDD

HDD.




HDD

SATA




DVR?

Enter



( : 888888. : 888888. ( : admin. : admin. )  
 : default. : default ( )  
 )  
 USB-  
 ( )

WEB-DVR.  
DVR.  
ping \*\*\*.\*\*\*.\*\*\*.\*\*\* (\* IP  
TTL, 255.  
IE, IP  
192.168.1.108, http://192.168.1.108  
Internet Explorer.  
webrec.cab  
ActiveX,



192.168.1.108

(https:)

WEB

admin

admin.

IP

DVR.

# ИНТЕРНЕТ-МАГАЗИН: TELECAMERA.RU

«RVi»



The image shows a login window for RVi Service. It features the RVi logo and the text "Service". Below the logo, there are two input fields: "Имя польз.: admin" and "Пароль:". To the right of the password field is a button labeled "Вход".

WEB

5

:

,


,

,



WEB

:



( , . . ) , , , ,

1 DVR 15150-69. 5 15150-69.

- 36

WEB



**KZ**

# **RVi- IPN16/8-PRO**







	<b>RVi-IPN16/8-PRO</b>
	.264
	16
	1HDMI, 1 VGA, 1 BNC
( )	1920×1080, 1280×1024, 1280×720, 1024×768, 800×600
/	1 (BNC) / 1 (BNC)
	G.711u
	10 75
( )	5MP(2560x1920) / 3MP(2048x1536) / 1080P(1920x1080) / 720P(1280x720) / D1 (704x576)
	400 / (1080p), 400 / (720p)
/	30 / 300
HDD	SATA3 4
HDD	8 HDD + eSaTa
USB	4 ( 2)
RS485	PTZ
RS232	
	32 SATA + 16 eSATA
	, / ( , ),
	1 Gbit Ethernet
	HTTP, IPv4/IPv6, TCP/IP, UPNP, RTSP, UDP, SMTP, NTP, DHCP, DNS, PPPOE, DDNS, FTP, IP
	web- (IE, Google chrome, Firefox Mozilla,Opera) Windows XP Windows 7, MAC OS RVi PSS : S Symbian, S Windows mobile, S Android, S Blackberry, i S.
	20
	/
	22 18 , 6
	-10...+55 °C
	100-240 AC, 40 , HDD
	440x460x89 ( )
	6 , HDD


- SATA
- USB
- CD ( )
- 19"



1

1

1		
2		( / )
3		
4	0-9	
5		USB
6	REC	
7	Fn	
8	ESC	



## HDD

SATA

HDD


HDD



HDD


, SATA

«RVi»



NVR?	NVR ?

Enter



...	

- : admin. : admin. ( , )
  - : 888888. : 888888. ( , )
  - : default. : default ( )
- USB -

( )



·  
:

·  
, -  
·




# ИНТЕРНЕТ-МАГАЗИН: TELECAMERA.RU

RVi

«RVi»	

(https:)	(https:)
...	...

DVR , « IP - . « »  
 WEB admin admin. « »




WEB 5 : , , ,









«RVi»

## WEB



RVi

«RVi»



( ,

, . .)

15150-69 5

.

15150-69 1

NVR

, ,

36 .

—

:



, , ; ; ; ;

:

Web

Four horizontal lines representing a form or signature area.

:

\_\_\_\_\_

« \_\_\_\_\_ » \_\_\_\_\_ 201\_\_\_\_\_