

16/24-Port PoE Gigabit Managed Switch Web Config Manual

V1.0.0

Cybersecurity Recommendations

Mandatory actions to be taken towards cybersecurity

1. Change Passwords and Use Strong Passwords:

The number one reason systems get “hacked” is due to having weak or default passwords. It is recommended to change default passwords immediately and choose a strong password whenever possible. A strong password should be made up of at least 8 characters and a combination of special characters, numbers, and upper and lower case letters.

2. Update Firmware

As is standard procedure in the tech-industry, we recommend keeping NVR, DVR, and IP camera firmware up-to-date to ensure the system is current with the latest security patches and fixes.

“Nice to have” recommendations to improve your network security

1. Enable HTTPS/SSL:

Set up an SSL Certificate to enable HTTPS. This will encrypt all communication between your devices and recorder.

2. Forward Only Ports You Need:

- Only forward the HTTP and TCP ports that you need to use. Do not forward a huge range of numbers to the device. Do not DMZ the device's IP address.
- You do not need to forward any ports for individual cameras if they are all connected to a recorder on site; just the NVR is needed.

3. Limit Features of Guest Accounts:

If your system is set up for multiple users, ensure that each user only has rights to features and functions they need to use to perform their job.

4. SNMP:

Disable SNMP if you are not using it. If you are using SNMP, you should do so only temporarily, for tracing and testing purposes only.

5. Multicast:

Multicast is used to share video streams between two recorders. Currently there are no known issues involving Multicast, but if you are not using this feature, deactivation can enhance your network security.

6. Check the Log:

If you suspect that someone has gained unauthorized access to your system, you can check the system log. The system log will show you which IP addresses were used to login to your system and what was accessed.

7. Physically Lock Down the Device:

Ideally, you want to prevent any unauthorized physical access to your system. The best way to achieve this is to install the recorder in a lockbox, locking server rack, or in a room that is behind a lock and key.

Foreword

General









This Web Config Manual (hereinafter referred to be "the Manual"), introduces operations on web interface of 16/24-Port PoE Gigabit Managed Switch.

Models

Name	Model
16-Port PoE Gigabit Managed Switch (190 W)	PFS4218-16GT-190
16-Port PoE Gigabit Managed Switch (240 W)	PFS4218-16GT-240
24-Port PoE Gigabit Managed Switch (240 W)	PFS4226-24GT-240
24-Port PoE Gigabit Managed Switch (360 W)	PFS4226-24GT-360

Safety Instructions

The following categorized signal words with defined meaning might appear in the Manual.

Signal Words	Meaning
 DANGER	Indicates a high potential hazard which, if not avoided, will result in death or serious injury.
 WARNING	Indicates a medium or low potential hazard which, if not avoided, could result in slight or moderate injury.
 CAUTION	Indicates a potential risk which, if not avoided, could result in property damage, data loss, lower performance, or unpredictable result.
 ELECTRICITY	Indicates dangerous high voltage. Take care to avoid coming into contact with electricity.
 LASER BEAM	Indicates a laser radiation hazard. Take care to avoid exposure to a laser beam.
 ESD	Electrostatic Sensitive Devices. Indicates a device that is sensitive to electrostatic discharge.
 TIPS	Provides methods to help you solve a problem or save you time.
 NOTE	Provides additional information as the emphasis and supplement to the text.

Revision History

No.	Version	Revision Content	Release Time
1	V1.0.0	First Release.	August 9, 2018

Privacy Protection Notice

As the device user or data controller, you might collect personal data of others' such as face, fingerprints, car plate number, Email address, phone number, GPS and so on. You need to be in compliance with the local privacy protection laws and regulations to protect the legitimate rights and interests of other people by implementing measures include but not limited to: providing clear and visible identification to inform data subject the existence of surveillance area and providing related contact.

About the Manual

- The Manual is for reference only. If there is inconsistency between the Manual and the actual product, the actual product shall prevail.
- We are not liable for any loss caused by the operations that do not comply with the Manual.
- The Manual would be updated according to the latest laws and regulations of related regions. For detailed information, see the paper User's Manual, CD-ROM, QR code or our official website. If there is inconsistency between paper User's Manual and the electronic version, the electronic version shall prevail.
- All the designs and software are subject to change without prior written notice. The product updates might cause some differences between the actual product and the Manual. Please contact the customer service for the latest program and supplementary documentation.
- There still might be deviation in technical data, functions and operations description, or errors in print. If there is any doubt or dispute, please refer to our final explanation.
- Upgrade the reader software or try other mainstream reader software if the Guide (in PDF format) cannot be opened.
- All trademarks, registered trademarks and the company names in the Manual are the properties of their respective owners.
- Please visit our website, contact the supplier or customer service if there is any problem occurred when using the device.
- If there is any uncertainty or controversy, please refer to our final explanation.

Important Safeguards and Warnings

The Manual helps you to use our product properly. To avoid danger and property damage, read the Manual carefully before using the product, and we highly recommend you to keep it well for future reference.

Operating Requirements

- Do not expose the device directly to the sunlight, and keep it away from heat.
- Do not install the device in the damp environment, and avoid dust and soot.
- Make sure the device is in horizontal installation, and install the device on solid and flat surface to avoid falling down.
- Avoid liquid spattering on the device. Do not place object full of liquid on the device to avoid liquid flowing into the device.
- Install the device in the well-ventilated environment. Do not block the air vent of the device.
- Use the device at rated input and output voltage.
- Do not disassemble the device without professional instruction.
- Transport, use, and store the device in allowed ranges of humidity and temperature.

Power Supply Requirements

- Use the battery properly to avoid fire, explosion, and other dangers.
- Replace the battery with battery of the same type.
- Use locally recommended power cord in the limit of rated specifications.
- Use the standard power adapter. We will assume no responsibility for any problems caused by nonstandard power adapter.
- The power supply shall meet the SELV requirement. Use the power supply that conforms to Limited Power Source, according to IEC60950-1. Refer to the device label.
- Adopt GND protection for I-type device.
- The coupler is the disconnecting apparatus. Keep it at the angle for easy to operate.

Table of Contents

Cybersecurity Recommendations	I
Foreword	II
Important Safeguards and Warnings	IV
1 Overview	1
2 Login the Switch	2
3 General Settings	3
3.1 Device Information	3
3.2 Local	3
3.3 VLAN	4
3.4 Aggregation	5
3.5 VLAN Interface	7
4 Advanced Settings	9
4.1 Configuration	9
4.1.1 System	9
4.1.2 Port	13
4.1.3 DHCP	14
4.1.4 Security	19
4.1.5 Aggregation	41
4.1.6 Spanning Tree	43
4.1.7 IGMP Snooping	49
4.1.8 LLDP	51
4.1.9 PoE	54
4.1.10 MAC Table	55
4.1.11 VLANs	56
4.1.12 Mirroring	57
4.1.13 Serial Config	58
4.2 Monitor	58
4.2.1 System	58
4.2.2 Ports	60
4.2.3 DHCP	63
4.2.4 Security	65
4.2.5 Aggregation	70
4.2.6 Spanning Tree	70
4.2.7 IGMP Snooping	71
4.2.8 LLDP	72
4.2.9 PoE	74
4.2.10 MAC Table	74
4.2.11 VLANs	75
4.3 Diagnostics	75
4.3.1 Ping	76
4.3.2 Ping6	76
4.4 Maintenance	76

4.4.1 Restart Device	76
4.4.2 Factory Defaults.....	77
4.4.3 Software.....	77
4.4.4 Configuration	78

1

Overview

The 16/24-Port PoE Gigabit Managed Switch supports web access. You can visit the switch on web browser, and configure and manage the switch.

2 Login the Switch


Before login, make sure:

- You already configure the IP address of the switch. By default, the IP address of VLAN 1 is 192.168.1.110.
- The PC with web browser is connected to the network, and the PC can ping the switch successfully.

Step 1 Input the IP address of the switch in the address bar of the web browser. The IP address is 192.168.1.110 by default, and press **Enter** key on the keyboard.

See Figure 2-1 for login interface.

Figure 2-1 Web login interface

The image shows a web browser window displaying a login interface. At the top, there is a dark grey header bar. Below it, the main content area has a light grey background. There are three input fields: 'Username' with an empty text box, 'Password' with an empty text box, and 'Language' with a dropdown menu showing 'English'. Below these fields are two buttons: 'Login' and 'Cancel'.

Step 2 Input user name and password. The user name and the password are “admin” by default.

Step 3 Select the language.

Step 4 Click **Login**.

The web service interface is displayed.

 NOTE

After first time login, you need to modify the password. The new password can be set from 8 characters through 32 characters and contains at least two types from number, letter, and special characters (excluding "", "", ",", ":", and "&"). Modify the password in time.

3 General Settings

3.1 Device Information

You can view the Name, Device Type, Serial Number, and Software Version of the device. And you can view the port status and port information.

Select **General > Device Information**, and you can view the System Information and Port State Overview. See Figure 3-1. In Port Status Overview, if the port is displayed as green, it is connected successfully. And if the port is displayed as white, it is not connected. See Table 3-1 for details about port information.

Figure 3-1 Device information




Table 3-1 Port information

Parameter	Description
Port	Display all the ports. NOTE This switch contains 16/24 ports. Port quantity might vary depending on the model you purchased, and the actual product shall govern.
Port Type	Three types: Access, Hybrid, and Trunk.
Link	Two link states: Up, Down. Up indicated the port is connected successfully, and Down indicates the port is not connected.
Speed/Duplex	Display the port rate and the duplex mode.
VLAN	Display the port VLAN. By default, it is VLAN 1.
PoE	Display the PoE power of the port.
Media Type	Two media types: Copper, Fiber. Copper is the RJ-45 port, and Fiber is the fiber port.

3.2 Local

You can set the system name, IP address, and address mask length.

Select **General > Local**, and the Local interface is displayed. See Figure 3-2.

Figure 3-2 Local

Local

System Name	SWITCH
IP	
Address mask length	16

3.3 VLAN

Add the port to the VLAN, and configure the VLAN. By default, the port belongs to VLAN1.

Step 1 Select **General > Vlan**.

VLAN interface is displayed. See Figure 3-3.

Figure 3-3 Port VLAN configuration

Port VLAN Configuration

Port	Mode	Port VLAN	Allowed VLANs
*	<>	1	1
1	Access	1	1
2	Access	1	1
3	Access	1	1
4	Access	1	1
5	Access	1	1
6	Access	1	1
7	Access	1	1
8	Access	1	1
9	Access	1	1
10	Access	1	1
11	Access	1	1
12	Access	1	1
13	Access	1	1
14	Access	1	1
15	Access	1	1
16	Access	1	1
17	Access	1	1
18	Access	1	1
19	Access	1	1
20	Access	1	1
21	Access	1	1
22	Access	1	1
23	Access	1	1
24	Access	1	1
25	Access	1	1
26	Access	1	1

Save Reset

Step 2 Configure the port VLAN parameters. See Table 3-2.

Table 3-2 Port VLAN configuration parameter

Parameter	Description
Port	Display all the ports.
Mode	Three modes: Access, Hybrid, and Trunk.
Port VLAN	Add the port to a VLAN. By default, the port belongs to VLAN 1. It ranges from 1 through 4094.
Allowed VLANs	Set the allowed VLAN.

Step 3 Click **Save**.

3.4 Aggregation

Add the port to the aggregation. See “4.1.5 Aggregation” for details.

Select **General > Aggregation**, and the Aggregation interface is displayed. See Figure 3-4.

Figure 3-4 Aggregation

Aggregation

Group ID	Port Members																									
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26
Normal	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
Static Group1	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group2	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group3	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group4	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group5	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group6	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group7	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group8	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group9	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group10	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group11	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group12	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group13	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

Step 1 Add the port member to the static group. For example, add port 1 and port 2 to Static Group 1. See Figure 3-5.

 **NOTE**

Up to 13 static groups can be set at the same time.

Figure 3-5 Static group

Aggregation

Group ID	Port Members																									
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26
Normal	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
Static Group1	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group2	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group3	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group4	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group5	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group6	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group7	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group8	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group9	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group10	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group11	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group12	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Static Group13	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

Step 2 Click **Save**.

The port 1 and port 2 form the logical port.

3.5 VLAN Interface

You can add the IP address for VLAN interface, and add new IP route. See “4.1.1.2 VLAN Interface” for configuration details.

Step 1 Select **General > Vlan Interface**.

VLAN interface is displayed. See Figure 3-6.

Figure 3-6 VLAN interface

IP Configuration

Delete	VLAN	IP Address	Mask Length
<input type="checkbox"/>	1	172.3.20.115	16

IP Routes

Delete	Network	Mask Length	Gateway
<input type="checkbox"/>	0.0.0.0	0	172.3.0.1

Step 2 Add the VLAN interface.

1) Click **Add Interface**.

A new record is added. See Figure 3-7.

Figure 3-7 VLAN interface

IP Configuration

Delete	VLAN	IP Address	Mask Length
<input type="checkbox"/>	1	172.3.20.115	16
<input type="button" value="Delete"/>	0		

2) Set the parameters. See Table 3-3.

Table 3-3 VLAN interface

Parameter	Description
VLAN	Input VLAN number.
IP Address	Set the IP address of the VLAN interface.
Mask Length	Set the mask length of the VLAN interface.

Step 3 Add the IP route.

1) Click **Add Routes**.

A new record is added. See Figure 3-8.

Figure 3-8 IP routes

IP Routes

Delete	Network	Mask Length	Gateway
<input type="checkbox"/>	0.0.0.0	0	172.3.0.1
<input type="button" value="Delete"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

- 2) Set the parameters. See Table 3-4.

Table 3-4 IP routes

Parameter	Description
Network	It is the destination address of the IP packet.
Mask Length	Mask length, with destination address, is to identify the IP address of the destination host or the route. After logical AND between destination address and network mask, you can get the IP address of the destination host or the route.
Gateway	The gateway IP address of the route.

Step 4 Click **Save**.

4 Advanced Settings

4.1 Configuration

4.1.1 System

4.1.1.1 Information

You can set the system contact, system name, and system location.

Step 1 Select **Advanced > Configuration > System > Information**.

The Information interface is displayed. See Figure 4-1.

Figure 4-1 System information configuration

System Information Configuration	
System Contact	<input type="text"/>
System Name	SWITCH
System Location	<input type="text"/>
<input type="button" value="Save"/> <input type="button" value="Reset"/>	

Step 2 Set the System Contact, System Name, and System Location.

Step 3 Click **Save**.

4.1.1.2 VLAN Interface

The hosts belong to different VLANs cannot communicate. Route or the layer 3 switch is needed for forwarding. The switch supports layer 3 forwarding through VLAN interface.

VLAN interface is the virtual interface of layer 3 mode, for layer 3 communication between the VLANs. It is not the physical entity on the device. Every VLAN is related to a VLAN interface, and the VLAN interface can forward packet for the VLAN. Generally, because the VLAN can isolate the broadcasting domain, every VLAN corresponds to a network segment. VLAN interface is the gateway of the network segment, and it supports layer 3 forwarding for the packet based on IP address.

Step 1 Select **Advanced > Configuration > System > Vlan Interface**.

VLAN interface is displayed. See Figure 4-2.

Figure 4-2 VLAN interface

IP Configuration											
Delete	VLAN	DHCPv4			IPv4		DHCPv6			IPv6	
		Enable	Fallback	Current Lease	IP Address	Mask Length	Enable	Rapid Commit	Current Lease	IP Address	Mask Length
<input type="checkbox"/>	1	<input type="checkbox"/>	0		172.3.20.115	16	<input type="checkbox"/>	<input type="checkbox"/>			

IP Routes			
Delete	Network	Mask Length	Gateway
<input type="checkbox"/>	0.0.0.0	0	172.3.0.1

Step 2 Add the VLAN interface.

- 1) Click **Add Interface**.
A new record is added. See Figure 4-3.

Figure 4-3 VLAN interface

Delete	VLAN	Enable	Fallback	Current Lease	IP Address	Mask Length	Enable	Rapid Commit	Current Lease	IP Address	Mask Length
<input type="checkbox"/>	1	<input type="checkbox"/>	0		172.3.20.115	16	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	0	<input type="checkbox"/>	0				<input type="checkbox"/>	<input type="checkbox"/>			

Add Interface

- 2) Set the parameters. See Table 4-1.

Table 4-1 VLAN interface

Parameter	Sub-parameter	Description
VLAN	-	Input VLAN number.
IPv4	IP Address	Set the IP address of the VLAN interface.
	Mask Length	Set the mask length of the IP address.

Step 3 Add IP route.

- 1) Click **Add Route**.
A new record is added. See Figure 4-4.

Figure 4-4 IP routes

Delete	Network	Mask Length	Gateway
<input type="checkbox"/>	0.0.0.0	0	172.3.0.1

Add Route

- 2) Set the parameters. See Table 4-2.

Table 4-2 IP routes

Parameter	Description
Network	It is the destination address of the IP packet.
Mask Length	Mask length, with destination address, is to identify the IP address of the destination host or the route. After logical AND between destination address and network mask, you can get the IP address of the destination host or the route.
Gateway	The gateway IP address of the route.

Step 4 Click **Save**.

4.1.1.3 NTP

Enable NTP function, and the switch can synchronize with the network time automatically.

Step 1 Select **Advanced > Configuration > System > NTP**.

NTP Configure interface is displayed. See Figure 4-5.

Figure 4-5 NTP configuration (1)

NTP Configuration	
Mode	Disabled ▼
Server 1	
Server 2	
Server 3	
Server 4	
Server 5	

Save Reset

Step 2 Select the mode as **Enabled** to enable the NTP service. By default, the mode is **Disabled**.

Step 3 Set the IP address of the NTP server. See Figure 4-6.

Figure 4-6 NTP configuration (2)

NTP Configuration	
Mode	Enabled ▼
Server 1	192.168.100.1
Server 2	
Server 3	
Server 4	
Server 5	

Save Reset

Step 4 Click **Save**.

The switch can synchronize with the time of server 1.

4.1.1.4 Time

You can set the time zone and daylight saving time.

Select **Advanced > Configuration > System > Time**. The Time settings interface is displayed. See Figure 4-7.

Figure 4-7 Time settings

Time Zone Configuration	
Time Zone	None
Acronym	(0 - 16 characters)

Daylight Saving Time Configuration	
Daylight Saving Time Mode	
Daylight Saving Time	Disabled

Start Time settings	
Month	Jan
Date	1
Year	2014
Hours	0
Minutes	0

End Time settings	
Month	Jan
Date	1
Year	2097
Hours	0
Minutes	0

Offset settings	
Offset	1 (1 - 1440) Minutes

Save Reset

4.1.1.5 Log

You can configure the system log information, including Server Mode, Server Address, and System Log Level.

Step 1 Select **Advanced > Configuration > System > Log**.

The System Log Configuration interface is displayed. See Figure 4-8.

Figure 4-8 System log configuration

System Log Configuration	
Server Mode	Disabled
Server Address	
Syslog Level	Informational

Save Reset

Step 2 Set the parameters. See Table 4-3.

Table 4-3 System log configuration

Parameter	Description
Server Mode	Select the server mode: Disabled or Enabled.

Parameter	Description
Server Address	Input the IP address of the log server.
System Log Level	Select the system log lever, including: <ul style="list-style-type: none"> • Error • Warning • Notice • Informational

Step 3 Click **Save**.

4.1.2 Port

You can set the port parameters, including speed, duplex, flow control, and so on.

Step 1 Select **Advanced > Configuration > Port**.

The Port Configuration interface is displayed. See Figure 4-9.

Figure 4-9 Port configuration

Port	Link	Speed		Adv Duplex		Adv speed			Flow Control			Maximum Frame Size	Excessive Collision Mode		Frame Length Check
		Current	Configured	Fdx	Hdx	10M	100M	1G	Enable	Curr Rx	Curr Tx		Discard		
*		<>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		9600	<>	<input type="checkbox"/>
1	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
2	1Gfdx	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
3	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
4	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
5	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
6	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
7	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
8	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
9	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
10	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
11	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
12	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
13	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
14	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
15	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
16	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
17	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
18	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
19	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
20	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
21	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
22	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
23	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
24	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
25	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>
26	Down	Auto	Auto	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	9600	Discard	<input type="checkbox"/>

Step 2 Set the parameters. See Table 4-4.

Table 4-4 Port parameter

Parameter	Description
Port	Display all the ports.
Link	If the port link is displayed as green, it is connected successfully. And if the port link is displayed as red, it is not connected.
Speed	Including Current and Configured. In Current list, if it is displayed as Down, the port is not connected, and if it is displayed as a certain speed, the port is connected successfully. In Configured list, you can set the speed from the drop-down list.

Parameter	Description
Duplex	Set the duplex of the port. Full duplex (Fdx) and half duplex (Hdx) are selectable.
Adv Speed	Set the average speed of the port. 10 M, 100 M, and 1 G are selectable.
Flow Control	You can select Enable to enable flow control function.
Maximum Frame Size	Set the Maximum frame size.
Excessive Collision Mode	Select excessive collision mode from the drop-down list.
Frame Length Check	Select the checkbox to enable the function.

Step 3 Click **Save**.

4.1.3 DHCP

4.1.3.1 Server

DHCP Server is the server for managing DHCP standard in the specific network. DHCP Server is to allocate IP address for the workstation and make sure that the IP address for every workstation is different. DHCP Server simplifies the network management task which should be done manually before.

Generally, in the following scenes, DHCP Server is adopted to allocate IP address.

- The network scale is large. The workload is too heavy if manually configured, and centralized management for network will be difficult.
- The quantity of PC is larger than the quantity of IP address in the network, and it is impossible to allocate a static IP address for every PC. For example, the user quantity that can access network at the same time is limited by ISP, and the user needs to acquire the IP address dynamically.
- Only a small number of PC need the static IP address, and most of the PC do not need the static IP address.

There are three parts of DHCP Server configuration: address pool configuration, mode configuration, and excluded IP configuration.

Step 1 Select **Advanced > Configuration > DHCP > Server**.

Address pool configuration interface is displayed. See Figure 4-10.

Figure 4-10 Address pool

Delete	Name	Type	IP	Subnet Mask	Lease Time
<input type="checkbox"/>	vlan2_test	-	-	-	1 days 0 hours 0 minutes

Buttons: Add New Pool, Save, Reset

Step 2 Add a new address pool.

- 1) Click **Add New Pool**.

A new record is added. See Figure 4-11.

Figure 4-11 Add a new pool

IP Configuration											
Delete	VLAN	DHCPv4			IPv4		DHCPv6			IPv6	
		Enable	Fallback	Current Lease	IP Address	Mask Length	Enable	Rapid Commit	Current Lease	IP Address	Mask Length
<input type="checkbox"/>	1	<input type="checkbox"/>	0		172.3.20.115	16	<input type="checkbox"/>	<input type="checkbox"/>			
Delete	0	<input type="checkbox"/>	0				<input type="checkbox"/>	<input type="checkbox"/>			

Add Interface

- 2) Input the pool name. For example, vlan2_test2.
- 3) Click **Save**.
- 4) Click the pool name link. See Figure 4-12.
DHCP Pool Configuration interface is displayed. See Figure 4-13.

Figure 4-12 Name link

Delete	Name	Type	IP	Subnet Mask	Lease Time
<input type="checkbox"/>	vlan2_test2	-	-	-	1 days 0 hours 0 minutes

Figure 4-13 DHCP pool configuration

DHCP Pool Configuration	
Name	vlan2_test2 ▼
Pool Name	vlan2_test2
Type	None ▼
IP	
Subnet Mask	
Lease Time	1 days (0-365) 0 hours (0-23) 0 minutes (0-59)
Domain Name	
Broadcast Address	
Default Router	0.0.0.0 0.0.0.0 0.0.0.0 0.0.0.0
DNS Server	0.0.0.0 0.0.0.0 0.0.0.0
NTP Server	0.0.0.0 0.0.0.0 0.0.0.0
NetBIOS Node Type	None ▼
NetBIOS Scope	
NetBIOS Name Server	0.0.0.0 0.0.0.0 0.0.0.0
NIS Domain Name	
NIS Server	0.0.0.0 0.0.0.0 0.0.0.0
Client Identifier	None ▼
Hardware Address	
Client Name	
Vendor 1 Class Identifier	
Vendor 1 Specific Information	
Vendor 2 Class Identifier	
Vendor 2 Specific Information	
Vendor 3 Class Identifier	
Vendor 3 Specific Information	
Vendor 4 Class Identifier	
Vendor 4 Specific Information	

Save Reset

- 5) Set the parameters in DHCP Pool Configuration interface. See Figure 4-13. And see Table 4-5 for details about the parameters.

Table 4-5 DHCP pool configuration parameter

Parameter	Description
-----------	-------------

Parameter	Description
Type	Two types: network and host. <ul style="list-style-type: none"> • Network: a segment of IP address. • Host: a specific IP address.
IP	Input the IP address of the host or the network.
Subnet Mask	Input the subnet mask.
Lease Time	Input the lease time of the address pool.
Domain Name	Configure the domain name.
Broadcast Address	Configure the broadcast address.
Default Router	Configure the default gateway of the address pool.
DNS Server	Configure the server IP address of the domain name system.
NTP Server	Configure the NTP server IP address.

6) Click **Save**.

Step 3 Configure the mode.

1) Click **Mode** tab.

The Mode interface is displayed. See Figure 4-14.

Figure 4-14 Mode

2) Select the Mode as **Enabled** to enable DHCP Server.

3) Click **Add VLAN Range**.

A new record is added. See Figure 4-15.

Figure 4-15 Add VLAN range

4) Input the VLAN range. For example, 2-4.


5) Click **Save**.

Step 4 Configure the host IP address and the IP address segment.

1) Click **Exclude IP** tab.

Excluded IP interface is displayed. See Figure 4-16.


Figure 4-16 Excluded IP



- 2) Click **Add IP Range**.

A new record is added. See Figure 4-17.

Figure 4-17 Add IP range



- 3) Input the IP address range. For example, 192.168.100.2-192.168.100.50.
4) Click **Save**.

4.1.3.2 DHCP Snooping

DHCP Snooping is a security feature of DHCP to make sure that the client acquires the IP address from the legal server. If there is the illegal server built up privately in the network, the DHCP client might acquire wrong IP address and network configuration parameter, and communication will fail. To make sure that the DHCP client acquires the IP address from the legal DHCP Server, DHCP Snooping security mechanism supports to set the port as **Trusted** and **Untrusted**.

- The trusted port can forward the received DHCP packet normally.
- The untrusted port discards the DHCP-ACK packet and the DHCP-OFFER packet by DHCP Server.

Step 1 Select **Advanced > Configuration > DHCP > Snooping**.

DHCP Snooping interface is displayed. See Figure 4-18.

Figure 4-18 DHCP Snooping configuration

DHCP Snooping Configuration

Snooping Mode

Port Mode Configuration

Port	Mode
*	<>
1	Trusted
2	Trusted
3	Trusted
4	Trusted
5	Trusted
6	Trusted
7	Trusted
8	Trusted
9	Trusted
10	Trusted
11	Trusted
12	Trusted
13	Trusted
14	Trusted
15	Trusted
16	Trusted
17	Trusted
18	Trusted
19	Trusted
20	Trusted
21	Trusted
22	Trusted
23	Trusted
24	Trusted
25	Trusted
26	Trusted

Step 2 Select the Snooping Mode as **Enabled** to enable DHCP Snooping .

Step 3 Set the port as **Trusted** or **Untrusted**.

Step 4 Click **Save**.


4.1.4 Security

4.1.4.1 Users

You can add, edit, and delete the user.

Select **Advanced > Configuration > Security > Users**. Users Configuration interface is displayed. See Figure 4-19.

Figure 4-19 Users configuration



Add a user

Step 1 Click **Add New User**.

The Add User interface is displayed. See Figure 4-20.

Figure 4-20 Add a user.

Step 2 Input the user name and the password, and input the password again to confirm it. The password can be set from 8 characters through 32 characters and contains at least two types from number, letter, and special characters (excluding "", "", ";", ":" and "&"). For example, add the new user: test01.

Step 3 Click **Save**.

The new user test01 is added. See Figure 4-21.

Figure 4-21 New user added



Edit and delete the user

Click the user. For example, test01.

Edit User interface is displayed, and you can edit and delete the user. See Figure 4-22.

 **NOTE**

You can not delete the admin user.

Figure 4-22 Edit user

4.1.4.2 SSH

Secure Shell (SSH) is the security protocol to protect the security in remote login session and other network service, and avoid information leakage problem in remote management. You can enable or disable SSH function.

Select **Advanced > Configuration > Security > SSH**. SSH Configuration is displayed. See Figure 4-23.

Figure 4-23 SSH configuration

4.1.4.3 HTTPS

HTTPS (Hyper Text Transfer Protocol over Secure Socket Layer) is the HTTP channel for security target. SSL layer and TLS layer are added to HTTP, which are the security foundation. And SSL/TLS are needed for encryption. HTTPS is the URI scheme, and the syntax is similar to HTTP. It is used for security HTTP data transmission. Built in the web Netscape Navigator, it provides authentication and encryption communication. It is widely applied in world wide web for security sensitive communication. For example, to protect account security and use information.

Step 1 Select **Advanced > Configuration > Security > HTTPS**.

HTTPS Configuration interface is displayed. See Figure 4-24.

Figure 4-24 HTTPS configuration

HTTPS Configuration	
Mode	Disabled
Certificate Maintain	None
Certificate Status	Switch secure HTTP certificate is presented

Step 2 Select the Mode as **Enabled** to enable HTTPS service.

Step 3 Select the Certificate Maintain from the drop-down list, including **None**, **Delete**, and **Generate**, respectively means no certificate, to delete the certificate, and to create the certificate.

Step 4 Click **Save**.

4.1.4.4 SNMP

SNMP (Simple Network Management Protocol) is the standard protocol for network management in Internet, and it is widely applied for management device to access and manage the managed devices. SNMP has the following features:

- It supports intelligent management for network device. By using the network management platform based on SNMP, the network administrator can query the running status and the parameters of the network device, and can set the parameter, find the error, perform fault diagnosis, and then to plan the capacity and create the report.
- SNMP supports to manage the devices of different physical features. SNMP provides only the most basic function library. It makes the management task and the physical feature and the networking technology of the managed device independent, to manage the devices from different manufacturers.

SNMP network provides two element, NMS and Agent.

- NMS (Network Management System) is the manager in SNMP network, and it provides friendly human-machine interface, to help the network administrator to finish most of the network management work.
- Agent is the managed role in SNMP network, and it receives and handles the request packet from NMS. In some emergency circumstances, for example, if the port status changes, Agent can send alarm packet to NMS proactively.

Enable SNMP Function

Step 1 Select **Advanced > Configuration > Security > SNMP**.

The System interface in SNMP is displayed. See Figure 4-25.

Figure 4-25 System

Delete	Group Name	Security Model	Security Level	Read View Name	Write View Name
<input type="checkbox"/>	default_ro_group	any	NoAuth,NoPriv	default_view	None
<input type="checkbox"/>	default_rw_group	any	NoAuth,NoPriv	default_view	default_view

Step 2 Select the Mode as **Enabled** in SNMP System Configuration to enable SNMP function.

NOTE

Every SNMP v3 agent has an engine ID as its unique identifier.

Trap

Configure Agent, and it can send SNMP Trap packet to NMS. And configure the related information of the target host (generally NMS) for SNMP Trap packet.

Trap packet is the packet that Agent proactively sends to NMP to report some emergent and important events, for example, the manged device roots.

By default, Agent is allowed to send SNMP Trap packet.

Step 1 Select **Advanced > Configuration > Security > SNMP > Trap**.

The Trap interface is displayed. See Figure 4-26.

Figure 4-26 Trap

Step 2 Click **Add New Entry** in Trap Destination Configurations.

The SNMP Trap Configuration interface is displayed. See Figure 4-27.

Figure 4-27 SNMP Trap configuration

Step 3 Set the parameters. See Table 4-6.

Table 4-6 NMP Trap configuration parameter

Parameter	Description
Trap Config Name	Input the Trap Config name.
Trap Mode	Select Enabled or Disabled to enable or disable the function.
Trap Version	Three versions: SNMP v1, SNMP v2c, and SNMP v3.
Trap Community	Input the Trap community name.
Trap Destination Address	Input the Trap destination address.
Trap Destination Port	Input the port number of the target host.

Parameter	Description
Trap Inform Mode	Select Enabled or Disabled to enable or disable the function. Only versions of SNMP v2c and SNMP v3 support the function.
Trap Inform Timeout	Input the timeout. Only versions of SNMP v2c and SNMP v3 support the function.
Trap Inform Retry Times	Input the retry times. Only versions of SNMP v2c and SNMP v3 support the function.
Trap Security Engine ID	Set the engine ID. Only version SNMP v3 supports the function.
Trap Security Name	Input the Trap security name. Only version SNMP v3 supports the function.

Step 4 Click **Save**.

Communities

Add the community, and set the authority for NMS accessing Agent, using the community.

Step 1 Select **Advanced > Configuration > Security > SNMP > Communities**.

Communities interface is displayed. See Figure 4-28.

Figure 4-28 Communities (1)

Delete	Community name	Community secret	Source IP	Source Prefix
<input type="checkbox"/>	public	public	0.0.0.0	0
<input type="checkbox"/>	private	private	0.0.0.0	0

Buttons: Add New Entry, Save, Reset

Step 2 Click **Add New Entry**.

A new record is added. See Figure 4-29.

Figure 4-29 Communities (2)

Delete	Community name	Community secret	Source IP	Source Prefix
<input type="checkbox"/>	public	public	0.0.0.0	0
<input type="checkbox"/>	private	private	0.0.0.0	0
Delete				

Buttons: Add New Entry, Save, Reset

Step 3 Set the community name, community secret, source IP, and the source Prefix.

Step 4 Click **Save**.

Users

Before configuring the SNMP user, you need to configure the SNMP group the user belongs to.

Step 1 Select **Advanced > Configuration > Security > SNMP > Users**.

The Users interface is displayed. See Figure 4-30.

Figure 4-30 Users

Delete	Engine ID	User Name	Security Level	Authentication Protocol	Authentication Password	Privacy Protocol	Privacy Password
<input type="checkbox"/>							

Buttons: Add New Entry, Save, Reset

Step 2 Click **Add New Entry**.

A new record is added. See Figure 4-31.

Figure 4-31 Add a user.

Delete	Engine ID	User Name	Security Level	Authentication Protocol	Authentication Password	Privacy Protocol	Privacy Password
Delete	800019cb039002a9da6d30		Auth, Priv	MD5		DES	

Buttons: Add New Entry, Save, Reset

Step 3 Set the parameters. See Table 4-7.

Table 4-7 User parameter

Parameter	Description
Engine ID	It is created automatically.
User Name	Input the user name.
Security Level	<p>Select the security level from the drop-down list.</p> <ul style="list-style-type: none"> If you select “Auth, Priv”, you need to set the Authentication Protocol and the Authentication Password, Private Protocol and the Private Password. If you select “NoAuth, NoPriv”, you do not need to set the protocol and password. If you select “Auth, NoPriv”, you need to set the Authentication Protocol and the Authentication Password.

Step 4 Click **Save**.

Groups

After SNMP group configured, you can add the SNMP user to the SNMP group when configuring SNMP user. You can manage the users in the group better through managing the group.

Step 1 Select **Advanced > Configuration > Security > SNMP > Groups**.

The Groups interface is displayed. See Figure 4-32.

Figure 4-32 Groups

Delete	Security Model	Security Name	Group Name
<input type="checkbox"/>	v1	public	default_ro_group
<input type="checkbox"/>	v1	private	default_rw_group
<input type="checkbox"/>	v2c	public	default_ro_group
<input type="checkbox"/>	v2c	private	default_rw_group

Buttons: Add New Entry, Save, Reset

Step 2 Click **Add New Entry**.

A new record is added. See Figure 4-33.

Figure 4-33 Add a group

Delete	Security Model	Security Name	Group Name
<input type="checkbox"/>	v1	public	default_ro_group
<input type="checkbox"/>	v1	private	default_rw_group
<input type="checkbox"/>	v2c	public	default_ro_group
<input type="checkbox"/>	v2c	private	default_rw_group

Buttons: Add New Entry, Save, Reset

Step 3 Set the parameters. See Table 4-8.

Table 4-8 Group parameter

Parameter	Description
Security Mode	Select the security mode from the drop-down list, including v1, v2c, and usm.
Security Name	Select the security name from the drop-down list.
Group Name	Input the group name.

Step 4 Click **Save**.

Views

After SNMP views configured, you can specify the SNMP views for the SNMP group to limit the MIB target that the SNMP group can visit.

Step 1 Select **Advanced > Configuration > Security > SNMP > Views**.

The Views interface is displayed. See Figure 4-34.

Figure 4-34 Views

Delete	View Name	View Type	OID Subtree
<input type="checkbox"/>	default_view	included	.1

Buttons: Add New Entry, Save, Reset

Step 2 Click **Add New Entry**.

A new record is added. See Figure 4-35.

Figure 4-35 Add a new view

Delete	View Name	View Type	OID Subtree
<input type="checkbox"/>	default_view	included	.1
<input type="checkbox"/>		included	

Buttons: Add New Entry, Save, Reset

Step 3 Set the parameters. See Table 4-9.

Table 4-9 Views parameter

Parameter	Description
View Name	Input the view name.

Parameter	Description
View Type	Select the view type from the drop-down list to set whether the object decided by OID of MIB subtree and subtree mask is included in the view type.
OID Subtree	Input the OID of MIB subtree root node (for example, 1.4.5.3.1), or the name (for example, system). OID of MIB subtree indicates the node position in the MIB tree, and it can only identify one object in the MIB library.

Step 4 Click **Save**.

4.1.4.5 RMON

RMON (Remote Network Monitoring) is for statistics and alarm function. It is applied for remote monitoring and management in network. Statistics is the function that the managed device can periodically or continuously record the flow information of the network segment which the port connects to, for example, the packet quantity received by the network segment in a period of time. Alarm function is that the managed device can monitor the value of the specific MIB variable, and when the value reaches the alarm threshold (for example, the port rate reached the specific value, or the ratio of broadcasting packet reaches the specific value), it can automatically record the log, and send Trap packet to the management device.

Statistics


The statistics group regulates that the system continuously records the different types of flow information from the port (only supports Ethernet port currently) and stores the statistics result in the Ethernet statistical table (etherStatsTable), and the management can check the result conveniently. The statistics information contains the quantity of network conflicts, quantity of CRC verification error message, quantity of data packet too small or too large, quantity of broadcasting packet or multicasting packet, the received byte count, and the quantity of received packet.

After creating the statistics table in the specific port, the statistics table records the packet quantity from the current port. The statistics result is the continuously accumulated value.

Step 1 Select **Advanced > Configuration > Security > RMON**.

The Statistics interface is displayed. See Figure 4-36.

Figure 4-36 Statistics



Step 2 Click **Add New Entry**.

A new record is added. See Figure 4-37.

Figure 4-37 Add a new statistics group

Delete	ID	Data Source	
Delete		.1.3.6.1.2.1.2.2.1.1.	0

Buttons: Add New Entry, Save, Reset

Step 3 Set the parameters. See Table 4-10.

Table 4-10 Statistics group parameter

Parameter	Description
ID	ID number is user-defined.
Date Source	It is the mapping reference number of switch port in SNMP client.

Step 4 Click **Save**.

History

The history group regulates that the system periodically records the different types of flow information from the port and stores the statistics result in the history table (etherHistoryTable), and the management can check the result conveniently. The data contains bandwidth utilization, error package quantity, and total package quantity.

The history group records the packets that the port receives in every period, and the period length is user-defined.

Step 1 Select **Advanced > Configuration > Security > RMON > History**.

The History interface is displayed. See Figure 4-38.

Figure 4-38 History

Delete	ID	Data Source	Interval	Buckets	Buckets Granted
--------	----	-------------	----------	---------	-----------------

Buttons: Add New Entry, Save, Reset

Step 2 Click **Add New Entry**, and set the ID and the data source.

Step 3 Click **Save**.


Alarm

RMON alarm management can monitor the specific alarm variable (for example, the packet quantity etherStatsPkts that the port receives). After creating the alarm table, the system can periodically acquire the value of the monitored alarm variable according to the defined time. When the value of the alarm variable reaches the upper threshold, one upper threshold alarm event is triggered. And when the value of the alarm variable reaches the lower threshold, one lower threshold alarm event is triggered. The alarm management can process the alarm events according to the event definition.

When the sampling value of alarm variable continuously exceeds the threshold in the same direction, only the first will trigger alarm. The upper threshold alarm event and the lower threshold alarm event are alternate. When one upper threshold alarm event triggers, the next must be the lower threshold alarm event. As the following figure, the value of alarm variable

(shown as the black curve) exceeds the threshold (shown as the blue curve) for several times, and there are several cross points. Only the points marked with red crosses trigger alarm event.

Figure 4-39 Upper threshold and lower threshold alarm



Step 1 Select **Advanced > Configuration > Security > RMON > Alarm**.

The Alarm interface is displayed. See Figure 4-40.

Figure 4-40 Alarm

Delete	ID	Sample interval	Variable	Sample Type	Value	Startup Alarm	Rising Threshold	Rising Index	Falling Threshold	Falling Index
Delete		30	.1.3.6.1.2.1.2.2.1	0.0	Delta	0	RisingOrFalling	0	0	0

Step 2 Click **Add New Entry**, and set the parameters according to the interface, including ID, sample interval, variable, sample type, startup alarm, and so on.

Step 3 Click **Save**.

Event


Event group is for defining the event reference number and the processing mode. The events defined in event group are applied in the alarm configuration. When the monitored target reaches the alarm condition, alarm event is triggered. There are several processing mode:

- **Log:** The corresponding information (the event time and event content) of the alarm event will be recorded in the event log table of the device RMON MIB, and the management device can check the information through SNMP GET operation.
- **SNMP Trap:** Trap packet will be sent to network management station to inform the alarm event.
- **Log and Trap:** The alarm event will be recorded in the event log table of the device, and Trap packet will be sent to network management station .
- **None:** No processing.

Step 1 Select **Advanced > Configuration > Security > RMON > Event**.

The Event interface is displayed. See Figure 4-41.

Figure 4-41 Event



Step 2 Click **Add New Entry**, and set the parameters according to the interface, including ID, Desc, and type.

Step 3 Click **Save**.

4.1.4.6 ACL

ACL (Access Control List) is for flow identification. For filtering the packet, the network device needs to configure a series of matching conditions to classify the packets. The conditions can be the source address, destination address, and the port number of the packet.

When the device port receives the packet, it can analyze the packet field according to the ACL rule of the current port. And after the specific packet is identified, the packet is allowed or forbidden to pass according to the preset rule.

Ports

Step 1 Select **Advanced > Configuration > Security > ACL**.

The ACL interface is displayed. See Figure 4-42.

Figure 4-42 Ports

Port	Policy ID	Action	Rate Limiter ID	Port Redirect	Mirror	Logging	Shutdown	State	Counter
1	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
2	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	2565859
3	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
4	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
5	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
6	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
7	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
8	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
9	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
10	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	473
11	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
12	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
13	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
14	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
15	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
16	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
17	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
18	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
19	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
20	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
21	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
22	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
23	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
24	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
25	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0
26	0	Permit	Disabled	Disabled Port 1 Port 2	Disabled	Disabled	Disabled	Enabled	0

Save Reset

Step 2 Set the parameters including Policy ID, Action, Rate Limiter ID, and so on.

Step 3 Click **Save**.

Rate Limiters

Step 1 Select **Advanced > Configuration > Security > ACL > Rate Limiters**.

The Rate Limiters interface is displayed. See Figure 4-43.

Figure 4-43 Rate limiters

Rate Limiter ID	Rate	Unit
1	1	pps ▼
2	1	pps ▼
3	1	pps ▼
4	1	pps ▼
5	1	pps ▼
6	1	pps ▼
7	1	pps ▼
8	1	pps ▼
9	1	pps ▼
10	1	pps ▼
11	1	pps ▼
12	1	pps ▼
13	1	pps ▼
14	1	pps ▼
15	1	pps ▼
16	1	pps ▼

Save Reset

Step 2 Set the parameters including Rate and Unit.

Step 3 Click **Save**.

Access Control List

Step 1 Select **Advanced > Configuration > Security > ACL > Access Control List**.

The Access Control List interface is displayed. See Figure 4-44.

Figure 4-44 Access control list

ACE	Ingress Port	Policy / Bitmask	Frame Type	Action	Rate Limiter	Port Redirect	Mirror	Counter

+

Step 2 Click .

The ACE Configuration interface is displayed. See Figure 4-45.

Figure 4-45 ACE configuration

ACE Configuration

Ingress Port	All Port 1 Port 2 Port 3 Port 4
Policy Filter	Any
Frame Type	Any

Action	Permit
Rate Limiter	Disabled
Mirror	Disabled
Logging	Disabled
Shutdown	Disabled
Counter	0

VLAN Parameters

802.1Q Tagged	Any
VLAN ID Filter	Any
Tag Priority	Any

Save Reset Cancel

Step 3 Set the parameters.

Step 4 Click **Save**.

4.1.4.7 IP Source Guard

Through IP Source Guard binding function, the packet forwarded in the port can be filtered and controlled, and the illegal packet cannot pass through the port. The illicit use of network resource is limited, and security performance of the port is enhanced.

IP Source Guard

Step 1 Select **Advanced > Configuration > Security > IP Source Guard**.

The IP Source Guard interface is displayed. See Figure 4-46.

Figure 4-46 IP source guard

Configuration | Static Table

IP Source Guard Configuration

Mode: Disabled ▾

Port Mode Configuration

Port	Mode	Max Dynamic Clients
1	Disabled ▾	Unlimited ▾
2	Disabled ▾	Unlimited ▾
3	Disabled ▾	Unlimited ▾
4	Disabled ▾	Unlimited ▾
5	Disabled ▾	Unlimited ▾
6	Disabled ▾	Unlimited ▾
7	Disabled ▾	Unlimited ▾
8	Disabled ▾	Unlimited ▾
9	Disabled ▾	Unlimited ▾
10	Disabled ▾	Unlimited ▾
11	Disabled ▾	Unlimited ▾
12	Disabled ▾	Unlimited ▾
13	Disabled ▾	Unlimited ▾
14	Disabled ▾	Unlimited ▾
15	Disabled ▾	Unlimited ▾
16	Disabled ▾	Unlimited ▾
17	Disabled ▾	Unlimited ▾
18	Disabled ▾	Unlimited ▾
19	Disabled ▾	Unlimited ▾
20	Disabled ▾	Unlimited ▾
21	Disabled ▾	Unlimited ▾
22	Disabled ▾	Unlimited ▾
23	Disabled ▾	Unlimited ▾
24	Disabled ▾	Unlimited ▾
25	Disabled ▾	Unlimited ▾
26	Disabled ▾	Unlimited ▾

Step 2 Select the Mode as **Enabled** to enable IP Source Guard function.

Step 3 Set the parameters. See Table 4-11.

Table 4-11 IP source guard parameter

Parameter	Description
Translate dynamic to static	Click the button to switch dynamic/static. The premise is that the IGMP Snooping is enabled.
Port Mode Configuration	Mode: Disabled and Enabled are selectable. Max Dynamic Clients: Unlimited , 0 , 1 , and 2 are selectable.


Step 4 Click **Save**.

Static Table

Step 1 Select **Advanced > Configuration > Security > IP Source Guard > Static Table**.

The Static Table interface is displayed. See Figure 4-47.


Figure 4-47 Static Table



Step 2 Click **Add New Entry**.

See Figure 4-48 for the Static IP Source Guard Table.

Figure 4-48 Static IP source guard table



Step 3 Set the parameters including Port, VLAN ID, IP Address, and MAC Address.

Step 4 Click **Save**.

4.1.4.8 ARP Inspection

ARP (Address Resolution Protocol) is the protocol to parse the IP address into Ethernet MAC address (the physical address).

In LAN, when the host or other network device needs to forward data to another host or other network device, the IP address of the target host or other network device should be known. Besides IP address, the forwarding station needs to know the physical address of the accepting station, because the IP data packet should be sent through the physical network as packaged frame. A mapping from the IP address to the physical address is needed. ARP is the protocol to realize the function.

Enable ARP Inspection

Step 1 Select **Advanced > Configuration > Security > ARP Inspection**.

The Port Configuration interface is displayed. See Figure 4-49.

Figure 4-49 Port configuration

Port Configuration	VLAN Configuration	Static Table	Dynamic Table																																																																																																												
<p>ARP Inspection Configuration</p> <p>Mode: <input type="text" value="Disabled"/></p> <p><input type="button" value="Translate dynamic to static"/></p>																																																																																																															
<p>Port Mode Configuration</p> <table border="1"> <thead> <tr> <th>Port</th> <th>Mode</th> <th>Check VLAN</th> <th>Log Type</th> </tr> </thead> <tbody> <tr><td>1</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>2</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>3</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>4</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>5</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>6</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>7</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>8</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>9</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>10</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>11</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>12</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>13</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>14</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>15</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>16</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>17</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>18</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>19</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>20</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>21</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>22</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>23</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>24</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>25</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> <tr><td>26</td><td>Disabled</td><td>Disabled</td><td>None</td></tr> </tbody> </table> <p><input type="button" value="Save"/> <input type="button" value="Reset"/></p>				Port	Mode	Check VLAN	Log Type	1	Disabled	Disabled	None	2	Disabled	Disabled	None	3	Disabled	Disabled	None	4	Disabled	Disabled	None	5	Disabled	Disabled	None	6	Disabled	Disabled	None	7	Disabled	Disabled	None	8	Disabled	Disabled	None	9	Disabled	Disabled	None	10	Disabled	Disabled	None	11	Disabled	Disabled	None	12	Disabled	Disabled	None	13	Disabled	Disabled	None	14	Disabled	Disabled	None	15	Disabled	Disabled	None	16	Disabled	Disabled	None	17	Disabled	Disabled	None	18	Disabled	Disabled	None	19	Disabled	Disabled	None	20	Disabled	Disabled	None	21	Disabled	Disabled	None	22	Disabled	Disabled	None	23	Disabled	Disabled	None	24	Disabled	Disabled	None	25	Disabled	Disabled	None	26	Disabled	Disabled	None
Port	Mode	Check VLAN	Log Type																																																																																																												
1	Disabled	Disabled	None																																																																																																												
2	Disabled	Disabled	None																																																																																																												
3	Disabled	Disabled	None																																																																																																												
4	Disabled	Disabled	None																																																																																																												
5	Disabled	Disabled	None																																																																																																												
6	Disabled	Disabled	None																																																																																																												
7	Disabled	Disabled	None																																																																																																												
8	Disabled	Disabled	None																																																																																																												
9	Disabled	Disabled	None																																																																																																												
10	Disabled	Disabled	None																																																																																																												
11	Disabled	Disabled	None																																																																																																												
12	Disabled	Disabled	None																																																																																																												
13	Disabled	Disabled	None																																																																																																												
14	Disabled	Disabled	None																																																																																																												
15	Disabled	Disabled	None																																																																																																												
16	Disabled	Disabled	None																																																																																																												
17	Disabled	Disabled	None																																																																																																												
18	Disabled	Disabled	None																																																																																																												
19	Disabled	Disabled	None																																																																																																												
20	Disabled	Disabled	None																																																																																																												
21	Disabled	Disabled	None																																																																																																												
22	Disabled	Disabled	None																																																																																																												
23	Disabled	Disabled	None																																																																																																												
24	Disabled	Disabled	None																																																																																																												
25	Disabled	Disabled	None																																																																																																												
26	Disabled	Disabled	None																																																																																																												

Step 2 Select the Mode as **Enabled** in ARP Inspection Configuration to enable ARP inspection function.

Step 3 Set the parameters. See Table 4-12.

Table 4-12 ARP inspection parameter

Parameter	Description
Translate dynamic to static	Click the button to switch dynamic/static.
Port Mode Configuration	Mode: Disabled and Enabled are selectable. Check VLAN: Disabled and Enabled are selectable. Log Type: None , Deny , Permit , and All are selectable.

Step 4 Click **Save**.

VLAN Configuration

Step 1 Select **Advanced > Configuration > Security > ARP Inspection > VLAN Configuration**.

The VLAN Configuration interface is displayed. See Figure 4-50.

Figure 4-50 VLAN mode configuration (1)

Step 2 Click **Add New Entry**.

A new record is added. See Figure 4-51.

Figure 4-51 VLAN mode configuration (2)

Step 3 Input the VLAN ID, and select the Log Type from the drop-down list.

Step 4 Click **Save**.

Static Table

The static table is manually configured and maintained. It will not ageing, and it will not be covered by dynamic ARP table.

Static table can enhance the security performance of communication. Static table can regulate that only the specific MAC address can be used in communication between network devices, and the attack packet can not modify the mapping between the IP address and the physical address of the table. Communication between the device and the other device is protected.

Step 1 Select **Advanced > Configuration > Security > ARP Inspection > Static Table**.

The Static Table interface is displayed. See Figure 4-52.

Figure 4-52 Static table

Step 2 Click **Add New Entry**.

A new record is added. See Figure 4-53.

Figure 4-53 Add a new static table

Delete	Port	VLAN ID	MAC Address	IP Address
Delete	1 ▼			

Add New Entry

Save Reset

Step 3 Set the parameters including Port, VLAN ID, MAC Address, and IP Address.

Step 4 Click **Save**.

Dynamic Table

Dynamic table is automatically created and maintained by ARP through ARP packet. It can be aging, and it can be covered by new ARP packet or static ARP table. When reaching ageing and the port is down, the corresponding dynamic table will be deleted.

Select **Advanced > Configuration > Security > ARP Inspection > Dynamic Table**. The Dynamic Table interface is displayed. See Figure 4-54.

Figure 4-54 Dynamic table

Port Configuration | VLAN Configuration | Static Table | Dynamic Table

Dynamic ARP Inspection Table

Start from Port 1 ▼, VLAN 1, MAC address 00-00-00-00-00-00 and IP address 0.0.0.0 with 20 entries per page

Port	VLAN ID	MAC Address	IP Address	Translate to static
No more entries				

Save Reset

4.1.4.9 802.1X

Nas

Step 1 Select **Advanced > Configuration > Security > 802.1X**.

The Nas interface is displayed. See Figure 4-55.

Figure 4-55 Nas

Nas | Radius

Network Access Server Configuration

System Configuration

Mode	Disabled
Reauthentication Enabled	<input type="checkbox"/>
Reauthentication Period	3600 seconds
EAPOL Timeout	30 seconds
Aging Period	300 seconds
Hold Time	10 seconds
RADIUS-Assigned QoS Enabled	<input type="checkbox"/>
RADIUS-Assigned VLAN Enabled	<input type="checkbox"/>
Guest VLAN Enabled	<input type="checkbox"/>
Guest VLAN ID	1
Max. Reauth. Count	2
Allow Guest VLAN if EAPOL Seen	<input type="checkbox"/>

Port Configuration

Port	Admin State	RADIUS-Assigned QoS Enabled	RADIUS-Assigned VLAN Enabled	Guest VLAN Enabled	Port State	Restart
1	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
2	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
3	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
4	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
5	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
6	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
7	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
8	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
9	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
10	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
11	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
12	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
13	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
14	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
15	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
16	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
17	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
18	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
19	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
20	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
21	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
22	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
23	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
24	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
25	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize
26	Force Authorized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Globally Disabled	Reauthenticate Reinitialize

Save Reset

Step 2 Select the Mode as **Enabled** to enable Nas in System Configuration.

Step 3 Set the parameters including Reauthentication Enabled, Reauthentication Period, EAPOL Timeout, Aging Period, and so on in System Configuration.

Step 4 Set the parameters including Admin State, Port State, and so on in Port Configuration.

Step 5 Click **Save**.

Radius

Step 1 Select **Advanced > Configuration > Security > 802.1X. > Radius**.

The Radius interface is displayed. See Figure 4-56.

Figure 4-56 Radius

RADIUS Server Configuration

Global Configuration

Timeout	5	seconds
Retransmit	3	times
Deadtime	0	minutes
Change Secret Key	No ▼	
NAS-IP-Address		
NAS-IPv6-Address		
NAS-Identifier		

Server Configuration

Delete	Hostname	Auth Port	Acct Port	Timeout	Retransmit	Change Secret Key

Step 2 Set the parameters including Timeout, Retransmit, Deadtime, and so on in Global Configuration.

Step 3 Click **Add New Server** in Server Configuration.

A new record is added. See Figure 4-57.

Figure 4-57 Server configuration

Server Configuration

Delete	Hostname	Auth Port	Acct Port	Timeout	Retransmit	Change Secret Key
Delete		1812	1813			

Step 4 Set the parameters including Hostname, Timeout, Retransmit, and so on.

Step 5 Click **Save**.

4.1.4.10 Loop Protection

Step 1 Select **Advanced > Configuration > Security > Loop Protection**.

The Loop Protection interface is displayed. See Figure 4-58.

Figure 4-58 Loop protection

Loop Protection Configuration

General Settings

Global Configuration	
Enable Loop Protection	Disable ▾
Transmission Time	5 seconds
Shutdown Time	180 seconds

Port Configuration

Port	Enable	Action	Tx Mode
*	<input checked="" type="checkbox"/>	↔	↔
1	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
2	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
3	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
4	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
5	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
6	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
7	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
8	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
9	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
10	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
11	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
12	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
13	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
14	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
15	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
16	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
17	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
18	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
19	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
20	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
21	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
22	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
23	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
24	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
25	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾
26	<input checked="" type="checkbox"/>	Shutdown Port	Enable ▾

Save Reset

Step 2 Select Enable Loop Protection as **Enabled** to enable the function. You can set the Transmission Time and the Shutdown Time.

Step 3 Set the parameters in Port Configuration, including Enabled, Action, and Tx Mode.

Step 4 Click **Save**.

4.1.5 Aggregation

Aggregation is to form the multiple physical ports of the switch into the logical port. The multiple links in the same group can be regarded as a logical link with the larger bandwidth.

Through aggregation, the ports in the same group can share the communication flow, to make a larger bandwidth. Besides, the ports in the same group can back up reciprocally and dynamically, to enhance the link reliability.

Static

Step 1 Select **Advanced > Configuration > Aggregation > Static**.

The Statics interface is displayed. See Figure 4-59.

Figure 4-59 Static configuration (1)

The screenshot displays the 'Aggregation Mode Configuration' and 'Aggregation Group Configuration' sections. The 'Hash Code Contributors' section has four checked options: Source MAC Address, Destination MAC Address, IP Address, and TCP/UDP Port Number. The 'Aggregation Group Configuration' section features a table with 13 rows (Group ID 1-13) and 26 columns (Port Members 1-26). The 'Normal' row has all 26 ports selected with blue radio buttons. Groups 1-13 have their respective ports (1-13) selected with blue radio buttons, while other ports are unselected (grey radio buttons). 'Save' and 'Reset' buttons are at the bottom.

Aggregation Mode Configuration																										
Hash Code Contributors																										
Source MAC Address <input checked="" type="checkbox"/>																										
Destination MAC Address <input checked="" type="checkbox"/>																										
IP Address <input checked="" type="checkbox"/>																										
TCP/UDP Port Number <input checked="" type="checkbox"/>																										
Aggregation Group Configuration																										
Group ID	Port Members																									
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26
Normal	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
1	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
2	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
3	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
4	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
5	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
6	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
7	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
8	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
9	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
10	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
11	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
12	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
13	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

Step 2 Select the Hash Code Contributors in Aggregation Mode Configuration. There are four types:

- Source MAC Address: the aggregation load balancing algorithm based on MAC address.
- Destination MAC Address: the aggregation load balancing algorithm based on destination MAC address.
- IP Address: the aggregation load balancing algorithm based on source IPv4 address and destination IPv4 address.
- TCP/UDP Port Number: the aggregation load balancing algorithm based on source and destination TCP/UDP port.

Step 3 Add the port member to the aggregation group in Aggregation Group Configuration. For example, add port 1 and port 2 to Static Group 1. See Figure 4-60.

 NOTE

Up to 13 static groups can be set at the same time.

Figure 4-60 Static configuration (2)

Aggregation Group Configuration

Group ID	Port Members																									
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26
Normal	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
1	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
2	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
3	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
4	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
5	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
6	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
7	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
8	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
9	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
10	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
11	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
12	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
13	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

Save Reset

Step 4 Click **Save**.

The port 1 and port 2 form the logical port.

4.1.6 Spanning Tree

The spanning tree protocol is the protocol of layer 2. It can eliminate the ring cycle of layer 2 by choosing to block the redundant links in the network, and it can back up the links.

Similar to other protocols, the spanning tree protocol is updated with the development of the network: from STP (Spanning Tree Protocol), to RSTP (Rapid Spanning Tree Protocol), and to the latest MSTP (Multiple Spanning Tree Protocol). We introduce the features of STP, RSTP, and MSTP, and the relationship between them progressively in this section.

4.1.6.1 Bridge Settings

There must be the root in tree-model network, and the concept of Root Bridge is introduced in STP. There is only one root bridge in the whole network, and the root bridge changes with the network topology change. The root bridge is not constant.

In network initialization, all devices regard itself as the root bridge, create their own configuration BPDU (Bridge Protocol Data Unit), and send it periodically. After the network topology is steady, only the root bridge device can send configuration BPDU, and other device forward it.

Step 1 Select **Advanced > Configuration > Spanning Tree > Bridge**.

The STP Bridge Configuration is displayed. See Figure 4-61.

Figure 4-61 STP Bridge Configuration

STP Bridge Configuration

Basic Settings

Protocol Version	MSTP ▼
Bridge Priority	32768 ▼
Hello Time	2
Forward Delay	15
Max Age	20
Maximum Hop Count	20
Transmit Hold Count	6

Advanced Settings

Edge Port BPDU Filtering	<input type="checkbox"/>
Edge Port BPDU Guard	<input type="checkbox"/>
Port Error Recovery	<input type="checkbox"/>
Port Error Recovery Timeout	<input type="text"/>

Save Reset

Step 2 Set the parameters, including Basic Settings and Advanced Settings. See Table 4-13 and Table 4-14.

Table 4-13 Basic settings

Parameter	Description
Protocol Version	Select the protocol version. There are three types selectable: <ul style="list-style-type: none"> STP: The most basic spanning tree protocol. RSTP: Improved based on STP, and realizes rapid convergence. MSTP: Remedies the defects of STP and RSTP. MSTP not only realizes rapid convergence, but also provides better load sharing mechanism for the redundant links by forwarding the flow from different VLANs through there own paths.
Bridge Priority	Set the bridge priority. The smaller the value is, the higher the priority level is. And the value of bridge priority should be the multiple of 4096.
Hello Time	Set the period for sending packet.
Forward Delay	Set the delay time of the port forwarding.
Max Age	Set the Maximum life cycle that the packet can be saved in the device.
Maximum Hop Count	Set the Maximum hop count for MST domain, and it decides the scale of the MST domain. Only the Maximum hop count configured in the domain root takes effect in the domain. Otherwise the parameter is invalid.
Transmit Hold Count	Set the Maximum number of times that the address table is updated and forwarded in a period of time after the TC-BPDU packet is received.

Table 4-14 Advanced settings

Parameter	Description
Edge Port BPDU Filtering	You can select the checkbox to enable the edge port BPDU filtering function.

Parameter	Description
Edge Port BPDU Guard	You can select the checkbox to enable the edge port BPDU guard function.
Port Error Recovery	You can select the checkbox to enable the port error recovery function.
Port Error Recovery Timeout	Set the port error recovery timeout value.

Step 3 Click **Save**.

4.1.6.2 MSTI Mapping

In an MST domain, multiple spanning trees can be created through MSTP, and the trees are independent. Every spanning tree can be regarded as an MSTI (Multiple Spanning Tree Instance).

VLAN mapping table is one of the MST domain properties, for describing the mapping relationship between VLAN and spanning tree instance.

MSTP realizes load sharing according to the VLAN mapping table.

Step 1 Select **Advanced > Configuration > Spanning Tree > MSIT Mapping**.

The MSTI Configuration interface is displayed. See Figure 4-62.

Figure 4-62 MSTI configuration

MSTI Configuration
Add VLANs separated by spaces or comma.

Configuration Identification

Configuration Name	90-02-a9-da-6d-30
Configuration Revision	0

MSTI Mapping

MSTI	VLANs Mapped
MSTI1	
MSTI2	
MSTI3	
MSTI4	
MSTI5	
MSTI6	
MSTI7	

Save Reset

Step 2 Set the parameters including Configuration Identification and MSTI Mapping. See Table 4-15 and Table 4-16.

Table 4-15 Configuration identification

Parameter	Description
-----------	-------------

Parameter	Description
Configuration Name	Set the domain name of the MST domain. By default, the domain name of the MST domain is the bridge MAC address of the device.
Configuration Revision	Set the MST domain version.

Table 4-16 MSTI mapping

Parameter	Description
MSTI	Displays the multiple spanning tree instances, 7 instances totally.
VLANs Mapped	Input the VLAN number. For example. VLAN 1.


Step 3 Click **Save**.

4.1.6.3 MSTI Priorities

Set the MSTI priorities. By default, it is 32768.

Select **Advanced > Configuration > Spanning Tree > MSIT Priorities**. The MSTI Priorities interface is displayed. See Figure 4-63.

Figure 4-63 MSTI configuration



4.1.6.4 CIST Ports

Step 1 Select **Advanced > Configuration > Spanning Tree > CIST Ports**.

The STP CIST Port Configuration interface is displayed. See Figure 4-64.

Figure 4-64 STP CIST port configuration

STP CIST Port Configuration

CIST Aggregated Port Configuration

Port	STP Enabled	Path Cost	Priority	Admin Edge	Auto Edge	Restricted Role	TCN	BPDU Guard	Point-to-point
-	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Forced True

CIST Normal Port Configuration

Port	STP Enabled	Path Cost	Priority	Admin Edge	Auto Edge	Restricted Role	TCN	BPDU Guard	Point-to-point
*	<input checked="" type="checkbox"/>	<>	<>	<>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<>
1	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
2	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
3	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
4	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
5	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
6	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
7	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
8	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
9	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
10	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
11	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
12	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
13	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
14	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
15	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
16	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
17	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
18	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
19	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
20	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
21	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
22	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
23	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
24	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
25	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto
26	<input checked="" type="checkbox"/>	Auto	128	Non-Edge	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Auto

Save Reset

Step 2 Set the parameters in CIST Aggregated Port Configuration. See Table 4-17.

Table 4-17 CIST aggregated port configuration

Parameter	Description
STP Enabled	Select the checkbox to enable STP.
Path Cost	Select the Path Cost from the drop-down list. Auto and Specific are selectable. If you select Specific , you can set the path cost value manually.
Priority	Set the priority. By default, it is 128.
Admin Edge	Select from the drop-down list. Non-Edge and Edge are selectable.
Auto Edge	You can select the checkbox to enable auto edge.
Restricted	Role or TCN can be selected.
BPDU Guard	You can select the checkbox to enable BPDU guard.
Point-to-point	Select from the drop-down list. Forced True , Forced False , and Auto are selectable.

Step 3 Set the parameters in CIST Normal Port Configuration. See Table 4-17.


Step 4 Click **Save**.

4.1.6.5 MSTI Ports

Step 1 Select **Advanced > Configuration > Spanning Tree > MSTI Ports**.

The MST1 MSTI Port Configuration interface is displayed. See Figure 4-65.

Figure 4-65 MST1 MSTI port configuration (1)



Step 2 Select MSTI from the drop-down list. 7 types are selectable. For example, you can select MST1.

Step 3 Click **Get**. See Figure 4-66 for the interface.

Figure 4-66 MST1 MSTI port configuration (2)

MST1 MSTI Port Configuration

MSTI Aggregated Ports Configuration

Port	Path Cost	Priority
-	Auto	128

MSTI Normal Ports Configuration

Port	Path Cost	Priority
*	<>	<>
1	Auto	128
2	Auto	128
3	Auto	128
4	Auto	128
5	Auto	128
6	Auto	128
7	Auto	128
8	Auto	128
9	Auto	128
10	Auto	128
11	Auto	128
12	Auto	128
13	Auto	128
14	Auto	128
15	Auto	128
16	Auto	128
17	Auto	128
18	Auto	128
19	Auto	128
20	Auto	128
21	Auto	128
22	Auto	128
23	Auto	128
24	Auto	128
25	Auto	128
26	Auto	128

Save Reset

Step 4 Set the Path Cost and the Priority in MSTI Aggregated Ports Configuration.

Step 5 Set the Path Cost and the Priority in MSTI Normal Ports Configuration.

Step 6 Click **Save**.

4.1.7 IGMP Snooping

IGMP Snooping (Internet Group Management Protocol Snooping) is the multicast constraint mechanism running on the device of layer 2, for managing and controlling the multicast.

Through analyzing the received IGMP packet, the device of layer 2, which runs IGMP Snooping,

creates the mapping between the port and the MAC multicast address, and forwards the multicast data according to the mapping.

4.1.7.1 Basic Configuration

Step 1 Select **Advanced > Configuration > IGMP Snooping > Basic Configuration**.

The IGMP Snooping Configuration is displayed. See Figure 4-67.

Figure 4-67 IGMP snooping configuration

IGMP Snooping Configuration

Global Configuration

Snooping Enabled	<input checked="" type="checkbox"/>
Unregistered IPMCv4 Flooding Enabled	<input checked="" type="checkbox"/>
IGMP SSM Range	232.0.0.0 / 8
Leave Proxy Enabled	<input type="checkbox"/>
Proxy Enabled	<input type="checkbox"/>

Port Related Configuration

Port	Router Port	Fast Leave	Throttling
*	<input type="checkbox"/>	<input type="checkbox"/>	<> ▼
1	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
2	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
3	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
4	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
5	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
6	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
7	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
8	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
9	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
10	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
11	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
12	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
13	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
14	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
15	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
16	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
17	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
18	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
19	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
20	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
21	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
22	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
23	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
24	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
25	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼
26	<input type="checkbox"/>	<input type="checkbox"/>	unlimited ▼

Step 2 Set the global parameters. See Table 4-18.

Table 4-18 Global configuration

Parameter	Description
Snooping Enabled	You can select the checkbox to enable IGMP snooping.

Parameter	Description
Unregistered IPMCv4 Flooding Enabled	You can select the checkbox to enable unregistered IPMCv4 flooding.
IGMP SSM Range	Set the IGMP SSM range.
Leave Proxy Enabled	You can select the checkbox to enable leave proxy.
Proxy Enabled	You can select the checkbox to enable proxy.

Step 3 Set the parameters in Port Related Configuration. See Table 4-19.

Table 4-19 Port related configuration

Parameter	Description
Router Port	Select the checkbox to set the router port.
Fast Leave	You can select the checkbox to enable the fast leave function for the port. Fast leave means when the switch receives the IGMP leave packet from the host through a certain port, the switch deletes the port from the port list in the forward table directly. Then, when the switch receives the IGMP specific group query packet for the multicast, the switch will not forward it to that port. You can enable the port fast leave to reduce bandwidth and resource cost.
Throttling	Set the threshold from the drop-down list.

Step 4 Click **Save**.

4.1.7.2 VLAN Configuration

Step 1 Select **Advanced > Configuration > IGMP Snooping > VLAN Configuration**.

The IGMP Snooping VLAN Configuration is displayed. See Figure 4-68.

Figure 4-68 IGMP snooping VLAN configuration

Step 2 Click **Add New IGMP VLAN**.

A new record is added. See Figure 4-69.

Figure 4-69 Enable IGMP snooping in a certain VLAN.

Step 3 Set the parameters including VLAN ID, Snooping Enabled, and so on.

Step 4 Click **Save**.

4.1.8 LLDP

LLDP (Link Layer Discovery Protocol) is the standard link layer discovery protocol. It can organize the information including main ability, management address, device identification, and interface identification of the device into different TLV (Type Length Value), and package in the

LLDPDU (Link Layer Discovery Protocol Data Unit) to release to the neighbors connected to itself directly. The neighbors receive the information, and save it in standard MIB (Management Information Base) format, for the network management system to query and judge the link communication status.

LLDP

Step 1 Select **Advanced > Configuration > LLDP**.

The LLDP Configuration interface is displayed. See Figure 4-70.

Figure 4-70 LLDP configuration

LLDP Configuration

LLDP Parameters

Tx Interval	30		seconds
Tx Hold	4		times
Tx Delay	2		seconds
Tx Reinit	2		seconds

LLDP Interface Configuration

Interface	Mode				Optional TLVs			
		CDP aware	Trap	Port Descr	Sys Name	Sys Descr	Sys Capa	Mgmt Addr
GigabitEthernet 1/1	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/2	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/3	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/4	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/5	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/6	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/7	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/8	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/9	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/10	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/11	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/12	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/13	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/14	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/15	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/16	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/17	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/18	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/19	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/20	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/21	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/22	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/23	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/24	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/25	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
GigabitEthernet 1/26	Disabled	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Step 2 Set the parameters including Tx Interval, Tx Hold, Tx Delay, and Tx Reinit in LLDP Parameters.

Step 3 Set the parameters including Mode, CDP aware, Trap, and son on in LLDP Interface Configuration.

Step 4 Click **Save**.

LLDP-MED

Step 1 Select **Advanced > Configuration > LLDP > LLDP-MED**.

The LLDP-MED Configuration interface is displayed. See Figure 4-71.

Figure 4-71 LLDP-MED configuration

LLDP-MED Configuration

Fast Start Repeat Count

Fast start repeat count

LLDP-MED Interface Configuration

Interface	Transmit TLVs				Device Type
	Capabilities	Policies	Location	PoE	
GigabitEthernet 1/1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/5	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/6	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/7	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/8	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/9	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/11	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/12	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/13	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/14	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/15	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/16	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/17	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/18	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/19	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/20	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/21	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/22	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/23	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/24	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/25	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾
GigabitEthernet 1/26	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Connectivity ▾

Coordinates Location

Latitude ° North ▾ Longitude ° East ▾ Altitude Meters ▾ Map Datum WGS84 ▾

Civic Address Location

Country code	<input type="text"/>	State	<input type="text"/>	County	<input type="text"/>
City	<input type="text"/>	City district	<input type="text"/>	Block (Neighborhood)	<input type="text"/>
Street	<input type="text"/>	Leading street direction	<input type="text"/>	Trailing street suffix	<input type="text"/>
Street suffix	<input type="text"/>	House no.	<input type="text"/>	House no. suffix	<input type="text"/>
Landmark	<input type="text"/>	Additional location info	<input type="text"/>	Name	<input type="text"/>
Zip code	<input type="text"/>	Building	<input type="text"/>	Apartment	<input type="text"/>
Floor	<input type="text"/>	Room no.	<input type="text"/>	Place type	<input type="text"/>
Postal community name	<input type="text"/>	P.O. Box	<input type="text"/>	Additional code	<input type="text"/>

Emergency Call Service

Emergency Call Service

Policies

Delete	Policy ID	Application Type	Tag	VLAN ID	L2 Priority	DSCP
No entries present						

Step 2 Set the Fast Start Repeat Count.

Step 3 Set the Transmit TLVs and the Device Type in LLDP-MED Interface Configuration.

Step 4 Set the location information in Coordinates Location.

Step 5 Set the parameters including Country code, State, Country, City, City district, and so on in Civic Address Location.

Step 6 Add the emergency phone number in Emergency Call Service.

Step 7 Click **Add New Policy**.

A new record is added. See Figure 4-72.

Figure 4-72 Add new policy

Delete	Policy ID	Application Type	Tag	VLAN ID	L2 Priority	DSCP
Delete	0	Voice	Tagged	1	0	0

Add New Policy

Step 8 Set the parameters including Application Type, Tag, VLAN ID and so on.

Step 9 Click **Save**.

4.1.9 PoE

PoE (Power Over Ethernet) is the function that through Ethernet RJ-45 port, the device can provide power for the external PD remotely with twisted pair. PoE function helps to centralize power supply and facilitate backup. The network terminal does not need the external power source anymore, and one network cable is enough, It conforms to the standards of IEEE 802.3af and IEEE 802.3at, adopting the power interface globally agreed. It can be applied in IP camera, wireless AP (Access Point), portable device charger, card reader, network camera, data collection, and so on.

Step 1 Select **Advanced > Configuration > PoE**.

The Power Over Ethernet Configuration interface is displayed. See Figure 4-73.

Figure 4-73 PoE configuration

Power Over Ethernet Configuration

Reserved Power determined by PD Class LLDP-MED

PoE Power Supply Configuration

Primary Power Supply	System Power Reserved [W]
350	35

PoE Port Configuration

Port	PoE Mode
1	ON
2	ON
3	ON
4	ON
5	ON
6	ON
7	ON
8	ON
9	ON
10	ON
11	ON
12	ON
13	ON
14	ON
15	ON
16	ON
17	ON
18	ON
19	ON
20	ON
21	ON
22	ON
23	ON
24	ON

Save Reset

- Step 2** Select **PD Class** or **LLDP-MED** for Reserved Power. By default, **PD Class** is selected.
- Step 3** Set the Primary Power Supply and the System Power Reserved in PoE Power Supply Configuration.
- Step 4** Select **ON** or **OFF** for PoE Mode from the drop-down list.
- Step 5** Click **Save**.

4.1.10 MAC Table

MAC (Media Access Control) Table records the relationship between the MAC address and the port, and the information including the VLAN that the port belongs to. When the device is forwarding the packet, it queries in the MAC address table for the destination MAC address of the packet. If the destination MAC address of the packet is contained in the MAC address table, the packet is forwarded through the port in the table directly. And if the destination MAC address of the packet is not contained in the MAC address table, the device adopts broadcasting to forward the packet to all the ports except the receiving port in VLAN.

You can set aging configuration, MAC table learning, and static MAC table configuration.

- Step 1** Select **Advanced > Configuration > MAC Table**.

The MAC Address Table Configuration interface is displayed. See Figure 4-74.

Figure 4-74 MAC address table configuration

MAC Address Table Configuration

Aging Configuration

Disable Automatic Aging	<input type="checkbox"/>
Aging Time	300 seconds

MAC Table Learning

	Port Members																									
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26
Auto	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
Disable	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

Static MAC Table Configuration

	Port Members																											
Delete	VLAN ID	MAC Address	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26
Add New Static Entry																												

Save Reset

- Step 2** Select **Disable Automatic Aging**, and set the Aging Time. By default, it is 300 seconds.
- Step 3** Select **Auto** or **Disable** to enable or disable MAC table learning.
- Step 4** Bind the MAC address to the port in the certain VLAN. For example, bind the MAC address 00-00-00-00-00-01 to the port 8 in VLAN 2.
- 1) Click **Add New Static Entry** in Static MAC Table Configuration. A new record is added. See Figure 4-75.

4.1.12 Mirroring

Port mirroring is also called port monitoring. Port monitoring is the data package acquiring technology that through configuring switch, data package from one or several ports (mirroring source ports) can be copied to a specific port (mirroring destination port). The mirroring destination port connects to a PC that data package analyzing software is installed, and it can analyze the received data package for network monitoring and troubleshooting.

Step 1 Select **Advanced > Configuration > Mirroring**.

The Mirror Configuration interface is displayed. See Figure 4-77.

Figure 4-77 Mirror configuration

Mirror Configuration

Global Settings

Mode Disabled ▼

Source VLAN(s) Configuration

VLAN ID

Port Configuration

Port	Source	Destination
Port 1	Disabled ▼	<input type="checkbox"/>
Port 2	Disabled ▼	<input type="checkbox"/>
Port 3	Disabled ▼	<input type="checkbox"/>
Port 4	Disabled ▼	<input type="checkbox"/>
Port 5	Disabled ▼	<input type="checkbox"/>
Port 6	Disabled ▼	<input type="checkbox"/>
Port 7	Disabled ▼	<input type="checkbox"/>
Port 8	Disabled ▼	<input type="checkbox"/>
Port 9	Disabled ▼	<input type="checkbox"/>
Port 10	Disabled ▼	<input type="checkbox"/>
Port 11	Disabled ▼	<input type="checkbox"/>
Port 12	Disabled ▼	<input type="checkbox"/>
Port 13	Disabled ▼	<input type="checkbox"/>
Port 14	Disabled ▼	<input type="checkbox"/>
Port 15	Disabled ▼	<input type="checkbox"/>
Port 16	Disabled ▼	<input type="checkbox"/>
Port 17	Disabled ▼	<input type="checkbox"/>
Port 18	Disabled ▼	<input type="checkbox"/>
Port 19	Disabled ▼	<input type="checkbox"/>
Port 20	Disabled ▼	<input type="checkbox"/>
Port 21	Disabled ▼	<input type="checkbox"/>
Port 22	Disabled ▼	<input type="checkbox"/>
Port 23	Disabled ▼	<input type="checkbox"/>
Port 24	Disabled ▼	<input type="checkbox"/>
Port 25	Disabled ▼	<input type="checkbox"/>
Port 26	Disabled ▼	<input type="checkbox"/>
CPU	Disabled ▼	<input type="checkbox"/>

Save
Reset

Step 2 Select Mode as **Enabled** to enable mirroring function.

Step 3 Input the VLAN ID in Source VLAN(s) Configuration.

Step 4 Configure the Source and the Destination in Port Configuration.

Step 5 Click **Save**.

4.1.13 Serial Config

Set the conversion between the asynchronous serial port and the Ethernet.

Select **Advanced > Configuration > Serial Config**. The Serial Config interface is displayed.

See Figure 4-78.

Figure 4-78 Serial Config

Serial Config	
Serial Index	1
Serial Enable	<input type="radio"/> On <input checked="" type="radio"/> Off
Serial Type	RS232
Protocol Type	TCP
IP Address	192.168.10.10
IP Port	8888
Timed out	100

Save Reset

4.2 Monitor

4.2.1 System

4.2.1.1 Information

You can view the system information of the device, including system, hardware, time, and software.

Select **Advanced > Monitor > System > Information**. The System Information interface is displayed. See Figure 4-79.

Figure 4-79 Information


System Information		Auto-refresh <input type="checkbox"/> Refresh
System		
Contact		
Name	SWITCH	
Location		
Hardware		
MAC Address	90-02-a9-da-6d-30	
Serial Number	00000000000001	
Device Type	PFS4210-8GT-DP	
Time		
System Date	1970-01-01T05:17:16+00:00	
System Uptime	0d 05:17:16	
Software		
Software Version	1.000.0000.9.R	
Software Date	2018-03-02T12:42:42+08:00	

4.2.1.2 CPU Load

You can view the CPU load within the unit interval. The lines of three different colors stand for the CPU load rate in different time intervals.

Select **Advanced > Monitor > System > CPU Load**. The CPU Load interface is displayed. See Figure 4-80.

Figure 4-80 CPU load



4.2.1.3 IP Status

You can view the IP status including IP interfaces, IP routes, and neighbour cache.

Select **Advanced > Monitor > System > IP Status**. The IP Status interface is displayed. See Figure 4-81.

Figure 4-81 IP Status

IP Interfaces			
Interface	Type	Address	Status
VLAN1	LINK	90-02-a9-da-6d-30	<UP BROADCAST MULTICAST>
VLAN1	IPv4	172.3.20.115/16	
VLAN1	IPv6	fe80::9202:a9ff:feda:6d30/64	

IP Routes		
Network	Gateway	Status
0.0.0.0/0	172.3.0.1	<UP GATEWAY>

Neighbour cache	
IP Address	Link Address
172.3.0.1	VLAN1:38-91-d5-6a-76-01
172.3.1.40	VLAN1:90-02-a9-b9-7e-01
172.3.2.117	VLAN1:34-17-eb-99-3a-05
172.3.3.51	VLAN1:b8-ca-3a-8f-f4-1b
172.3.50.161	VLAN1:d4-ae-52-bf-d0-2f

4.2.1.4 Log

You can view the logs according to the Level, and clear the logs as the Clear Level.

Select **Advanced > Monitor > System > Log**. The System Log Information interface is displayed. See Figure 4-82.

Figure 4-82 System log information

System Log Information

Level All ▾
Clear Level All ▾

The total number of entries is 13

Start from ID 1 with 20 entries per page

ID	Level	Time	Message
1	Informational	1970-01-01T00:00:30+00:00	SYS-BOOTING: Switch just made a cold boot.
2	Notice	1970-01-01T00:00:30+00:00	LINK-UPDOWN: Interface Vlan 1, changed state to down.
3	Notice	1970-01-01T00:00:30+00:00	LINK-UPDOWN: Interface Vlan 1, changed state to down.
4	Notice	1970-01-01T00:00:44+00:00	LINK-UPDOWN: Interface GigabitEthernet 1/7, changed state to up.
5	Notice	1970-01-01T00:00:45+00:00	LINK-UPDOWN: Interface GigabitEthernet 1/7, changed state to down.
6	Notice	1970-01-01T00:00:48+00:00	LINK-UPDOWN: Interface GigabitEthernet 1/7, changed state to up.
7	Notice	1970-01-01T00:00:52+00:00	LINK-UPDOWN: Interface Vlan 1, changed state to up.
8	Notice	1970-01-01T05:00:39+00:00	LINK-CHANGED: Interface GigabitEthernet 1/7, changed state to down (Loop).
9	Notice	1970-01-01T05:00:41+00:00	LINK-UPDOWN: Interface GigabitEthernet 1/7, changed state to down.
10	Notice	1970-01-01T05:00:43+00:00	LINK-UPDOWN: Interface Vlan 1, changed state to down.
11	Notice	1970-01-01T05:03:39+00:00	LINK-CHANGED: Interface GigabitEthernet 1/7, changed state to up (Loop).
12	Notice	1970-01-01T05:03:43+00:00	LINK-UPDOWN: Interface GigabitEthernet 1/7, changed state to up.
13	Notice	1970-01-01T05:03:46+00:00	LINK-UPDOWN: Interface Vlan 1, changed state to up.

4.2.1.5 Detailed Log

You can view the detailed information of the logs.

Select **Advanced > Monitor > System > Detailed Log**. The Detailed System Log Information interface is displayed. See Figure 4-83.

Figure 4-83 Detailed system log information

Detailed System Log Information

ID 1

Message

Level	Informational
Time	1970-01-01T00:00:30+00:00
Message	SYS-BOOTING: Switch just made a cold boot.

4.2.2 Ports

4.2.2.1 State

You can view the port information including link, speed/duplex, media type, and VLAN. If the port link is displayed as green, it is connected successfully. And if the port link is displayed as white, it is not connected.

Select **Advanced > Monitor > Ports > State**. The Port State Overview interface is displayed. See Figure 4-84. See Table 4-20 for detailed information of port.

Figure 4-84 Port status overview




Table 4-20 Port information


Parameter	Description
Ports	Display all the ports.
Link	Two link states: Up , Down . Up indicated the port is connected successfully, and Down indicates the port is not connected.
Speed/Duplex	Display the port rate and the duplex mode.
Media Type	Two media types: Copper , Fiber . Copper is the RJ-45 port, and Fiber is the fiber port.
VLAN	Display the port VLAN. By default, it is VLAN 1.

4.2.2.2 Traffic Overview

You can view the packers, bytes, errors, drops, and filterd information of the ports.

Select **Advanced > Monitor > Ports > Traffic Overview**. The Port Statistics Overview interface is displayed. See Figure 4-85.

Figure 4-85 Port statistics overview



4.2.2.3 QoS Statistics

You can view the QoS statistics of the ports.

Select **Advanced > Monitor > Ports > QoS Statistics**. The Queuing Counters interface is displayed. See Figure 4-86.

Figure 4-86 Queuing counters

Port	Q0		Q1		Q2		Q3		Q4		Q5		Q6		Q7	
	Rx	Tx	Rx	Tx	Rx	Tx	Rx	Tx	Rx	Tx	Rx	Tx	Rx	Tx	Rx	Tx
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
2	4593248	9280	0	0	0	0	0	0	0	0	0	0	0	0	0	3828
3	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
4	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
6	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
7	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
8	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
9	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
10	1091	456	0	0	0	0	0	0	0	0	0	0	0	0	0	59
11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
12	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
13	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
15	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
16	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
17	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
18	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
19	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
20	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
21	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
22	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
23	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
24	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
25	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
26	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

4.2.2.4 QCL Status

You can view the QoS control list status, including user name, QCE, port, frame type, action, and conflict.

Select **Advanced > Monitor > Ports > QCL Status**. The QoS Control List Status interface is displayed. See Figure 4-87.

Figure 4-87 QoS control list status

QoS Control List Status								Combined	Auto-refresh	Resolve Conflict	Refresh
User Name	QCE	Port	Frame Type	Action				Conflict			
				CoS	DPL	DSCP	PCP		DEI	Policy	
No entries											

4.2.2.5 Detailed Statistics

You can view the detailed statistics of the port by selecting the port on the upper right in the interface.

Select **Advanced > Monitor > Ports > Detailed Statistics**. The Detailed Port Statistics Port 1 interface is displayed. See Figure 4-88.

Figure 4-88 Detailed Port statistics port 1

Receive Total		Transmit Total	
Rx Packets	0	Tx Packets	0
Rx Octets	0	Tx Octets	0
Rx Unicast	0	Tx Unicast	0
Rx Multicast	0	Tx Multicast	0
Rx Broadcast	0	Tx Broadcast	0
Rx Pause	0	Tx Pause	0
Receive Size Counters		Transmit Size Counters	
Rx 64 Bytes	0	Tx 64 Bytes	0
Rx 65-127 Bytes	0	Tx 65-127 Bytes	0
Rx 128-255 Bytes	0	Tx 128-255 Bytes	0
Rx 256-511 Bytes	0	Tx 256-511 Bytes	0
Rx 512-1023 Bytes	0	Tx 512-1023 Bytes	0
Rx 1024-1526 Bytes	0	Tx 1024-1526 Bytes	0
Rx 1527- Bytes	0	Tx 1527- Bytes	0
Receive Queue Counters		Transmit Queue Counters	
Rx Q0	0	Tx Q0	0
Rx Q1	0	Tx Q1	0
Rx Q2	0	Tx Q2	0
Rx Q3	0	Tx Q3	0
Rx Q4	0	Tx Q4	0
Rx Q5	0	Tx Q5	0
Rx Q6	0	Tx Q6	0
Rx Q7	0	Tx Q7	0
Receive Error Counters		Transmit Error Counters	
Rx Drops	0	Tx Drops	0
Rx CRC/Alignment	0	Tx Late/Exc. Coll.	0
Rx Undersize	0		
Rx Oversize	0		
Rx Fragments	0		
Rx Jabber	0		
Rx Filtered	0		

4.2.3 DHCP

4.2.3.1 Server

Statistics

You can view the DHCP server statistics, including database counters, binding counters, DHCP packet received counters, and DHCP packet sent counters.

Select **Advanced > Monitor > DHCP > Server**. The DHCP Server Statistics interface is displayed. See Figure 4-89.

Figure 4-89 DHCP server statistics


Statistics		Binding		Declined IP	
DHCP Server Statistics					
Database Counters					
Pool	Excluded IP Address	Declined IP Address			
1	0	0			
Binding Counters					
Automatic Binding	Manual Binding	Expired Binding			
0	0	0			
DHCP Message Received Counters					
DISCOVER	REQUEST	DECLINE	RELEASE	INFORM	
0	0	0	0	0	
DHCP Message Sent Counters					
OFFER	ACK	NAK			
0	0	0			

Binding

You can view the DHCP server binding IP address.

Select **Advanced > Monitor > DHCP > Server > Binding**. The DHCP Server Binding IP interface is displayed. See Figure 4-90.

Figure 4-90 DHCP server binding IP



Declined IP

You can view the declined IP.

Select **Advanced > Monitor > DHCP > Server > Declined IP**. The DHCP Server Declined IP interface is displayed. See Figure 4-91.

Figure 4-91 Declined IP




4.2.3.2 Snooping Table

You can view the dynamic DHCP snooping table.

Select **Advanced > Monitor > DHCP > Snooping Table**. The Dynamic DHCP Snooping Table interface is displayed. See Figure 4-92.

Figure 4-92 Dynamic DHCP snooping table



4.2.3.3 Detailed Statistics

You can view the DHCP detailed statistics of the port by selecting the port on the upper right in the interface.

Select **Advanced > Monitor > DHCP > Detailed Statistics**. The DHCP Detailed Statistics Port 1 interface is displayed. See Figure 4-93.

Figure 4-93 DHCP detailed statistics port 1

Receive Packets		Transmit Packets	
Rx Discover	0	Tx Discover	0
Rx Offer	0	Tx Offer	0
Rx Request	0	Tx Request	0
Rx Decline	0	Tx Decline	0
Rx ACK	0	Tx ACK	0
Rx NAK	0	Tx NAK	0
Rx Release	0	Tx Release	0
Rx Inform	0	Tx Inform	0
Rx Lease Query	0	Tx Lease Query	0
Rx Lease Unassigned	0	Tx Lease Unassigned	0
Rx Lease Unknown	0	Tx Lease Unknown	0
Rx Lease Active	0	Tx Lease Active	0
Rx Discarded Checksum Error	0		
Rx Discarded from Untrusted	0		

4.2.4 Security

4.2.4.1 Port Security

Switch

You can view the port security switch status.

Select **Advanced > Monitor > Security > Port Security**. The Port Security Switch Status interface is displayed. See Figure 4-94.

Figure 4-94 Port security switch status

Port Security Switch Status				
Auto-refresh <input type="checkbox"/> Refresh				
User Module Legend				
User Module Name	Abbr			
Limit Control	L			
802.1X	8			
Voice VLAN	V			
Port Status				
Port	Users	State	MAC Count	
			Current	Limit
1	---	Disabled	-	-
2	---	Disabled	-	-
3	---	Disabled	-	-
4	---	Disabled	-	-
5	---	Disabled	-	-
6	---	Disabled	-	-
7	---	Disabled	-	-
8	---	Disabled	-	-
9	---	Disabled	-	-
10	---	Disabled	-	-
11	---	Disabled	-	-
12	---	Disabled	-	-
13	---	Disabled	-	-
14	---	Disabled	-	-
15	---	Disabled	-	-
16	---	Disabled	-	-
17	---	Disabled	-	-
18	---	Disabled	-	-
19	---	Disabled	-	-
20	---	Disabled	-	-
21	---	Disabled	-	-
22	---	Disabled	-	-
23	---	Disabled	-	-
24	---	Disabled	-	-
25	---	Disabled	-	-
26	---	Disabled	-	-

Port

You can view the port information including MAC address, VLAN ID, state, time of addition, and aged/hold.

Select **Advanced > Monitor > Security > Port Security > Port**. The Port interface is displayed. See Figure 4-95.

Figure 4-95 Port



4.2.4.2 NAS

Switch

You can view network access server switch status.

Select **Advanced > Monitor > Security > NAS**. The Network Access Server Switch Status interface is displayed. See Figure 4-96.

Figure 4-96 Network access server switch status

Port	Admin State	Port State	Last Source	Last ID	QoS Class	Port VLAN ID
1	Force Authorized	Globally Disabled	-	-	-	-
2	Force Authorized	Globally Disabled	-	-	-	-
3	Force Authorized	Globally Disabled	-	-	-	-
4	Force Authorized	Globally Disabled	-	-	-	-
5	Force Authorized	Globally Disabled	-	-	-	-
6	Force Authorized	Globally Disabled	-	-	-	-
7	Force Authorized	Globally Disabled	-	-	-	-
8	Force Authorized	Globally Disabled	-	-	-	-
9	Force Authorized	Globally Disabled	-	-	-	-
10	Force Authorized	Globally Disabled	-	-	-	-
11	Force Authorized	Globally Disabled	-	-	-	-
12	Force Authorized	Globally Disabled	-	-	-	-
13	Force Authorized	Globally Disabled	-	-	-	-
14	Force Authorized	Globally Disabled	-	-	-	-
15	Force Authorized	Globally Disabled	-	-	-	-
16	Force Authorized	Globally Disabled	-	-	-	-
17	Force Authorized	Globally Disabled	-	-	-	-
18	Force Authorized	Globally Disabled	-	-	-	-
19	Force Authorized	Globally Disabled	-	-	-	-
20	Force Authorized	Globally Disabled	-	-	-	-
21	Force Authorized	Globally Disabled	-	-	-	-
22	Force Authorized	Globally Disabled	-	-	-	-
23	Force Authorized	Globally Disabled	-	-	-	-
24	Force Authorized	Globally Disabled	-	-	-	-
25	Force Authorized	Globally Disabled	-	-	-	-
26	Force Authorized	Globally Disabled	-	-	-	-

Port

You can view the port status.

Select **Advanced > Monitor > Security > NAS > Port**. The NAS Statistics interface is displayed. See Figure 4-97.

Figure 4-97 NAS statistics

Admin State	Port State
Force Authorized	Globally Disabled

4.2.4.3 ACL Status

You can view the ACL status.

Select **Advanced > Monitor > Security > ACL Status**. The ACL Status interface is displayed. See Figure 4-98.

Figure 4-98 ACL status

ACL Status									
							combined	Auto-refresh <input type="checkbox"/>	Refresh
User Name	ACE	Frame Type	Action	Rate Limiter	Mirror	CPU	Counter	Conflict	
loopProtect	1	EType	Deny	Disabled	Disabled	Yes	1	No	

4.2.4.4 ARP Inspection

You can view dynamic ARP inspection table.

Select **Advanced > Monitor > Security > ARP Inspection**. The Dynamic ARP Inspection Table interface is displayed. See Figure 4-99.

Figure 4-99 Dynamic ARP inspection table

Dynamic ARP Inspection Table										
							Auto-refresh <input type="checkbox"/>	Refresh	<<	>>
Start from	Port 1	VLAN 1	MAC address	00-00-00-00-00-00	and IP address	0.0.0.0	with	20	entries per page	
Port	VLAN ID	MAC Address	IP Address	No more entries						

4.2.4.5 IP Source Guard

You can view the dynamic IP source guard table.

Select **Advanced > Monitor > Security > IP Source Guard**. The Dynamic IP Source Guard Table interface is displayed. See Figure 4-100.

Figure 4-100 Dynamic IP source guard table


Dynamic IP Source Guard Table									
						Auto-refresh <input type="checkbox"/>	Refresh	<<	>>
Start from	Port 1	VLAN 1	and IP address	0.0.0.0	with	20	entries per page		
Port	VLAN ID	IP Address	MAC Address	No more entries					

4.2.4.6 RADIUS Details

You can view the RADIUS details.

Select **Advanced > Monitor > Security > RADIUS Details**. The RADIUS Authentication Statistics for Server #1 interface is displayed. See Figure 4-101.

Figure 4-101 RADIUS authentication statistics for server #1




4.2.4.7 RMON

Statistics

You can view the RMON statistics status.

Select **Advanced > Monitor > Security > RMON**. The RMON Statistics Status Overview interface is displayed. See Figure 4-102.

Figure 4-102 RMON statistics status overview




History

You can view the RMON history.

Select **Advanced > Monitor > Security > RMON > History**. The RMON History Overview interface is displayed. See Figure 4-103.

Figure 4-103 RMON history overview



Alarm

You can view the RMON alarm information.

Select **Advanced > Monitor > Security > RMON > Alarm**. The RMON Alarm Overview interface is displayed. See Figure 4-104.

Figure 4-104 RMON alarm overview

Event

You can view the RMON event information.

Select **Advanced > Monitor > Security > RMON > Event**. The RMON Event Overview interface is displayed. See Figure 4-105.

Figure 4-105 RMON event overview

4.2.4.8 Loop Protection

You can view loop protection status.

Select **Advanced > Monitor > Security > Loop Protection**. The Loop Protection Status interface is displayed. See Figure 4-106.

Figure 4-106 Loop protection status

Port	Action	Transmit	Loops	Status	Loop	Time of Last Loop
1	Shutdown	Enabled	0	Down	-	-
2	Shutdown	Enabled	0	Up	-	-
3	Shutdown	Enabled	0	Down	-	-
4	Shutdown	Enabled	0	Down	-	-
5	Shutdown	Enabled	0	Down	-	-
6	Shutdown	Enabled	0	Down	-	-
7	Shutdown	Enabled	0	Down	-	-
8	Shutdown	Enabled	0	Down	-	-
9	Shutdown	Enabled	0	Down	-	-
10	Shutdown	Enabled	0	Down	-	-
11	Shutdown	Enabled	0	Down	-	-
12	Shutdown	Enabled	0	Down	-	-
13	Shutdown	Enabled	0	Down	-	-
14	Shutdown	Enabled	0	Down	-	-
15	Shutdown	Enabled	0	Down	-	-
16	Shutdown	Enabled	0	Down	-	-
17	Shutdown	Enabled	0	Down	-	-
18	Shutdown	Enabled	0	Down	-	-
19	Shutdown	Enabled	0	Down	-	-
20	Shutdown	Enabled	0	Down	-	-
21	Shutdown	Enabled	0	Down	-	-
22	Shutdown	Enabled	0	Down	-	-
23	Shutdown	Enabled	0	Down	-	-
24	Shutdown	Enabled	0	Down	-	-
25	Shutdown	Enabled	0	Down	-	-
26	Shutdown	Enabled	0	Down	-	-

4.2.5 Aggregation

Static

You can view the aggregation static configuration.

Select **Advanced > Monitor > Aggregation > Static**. The Aggregation Status interface is displayed. See Figure 4-107.

Figure 4-107 Aggregation status

Aggregation Status						Auto-refresh <input type="checkbox"/>	Refresh
Aggr ID	Name	Type	Speed	Configured Ports	Aggregated Ports		
No aggregation groups							

4.2.6 Spanning Tree

4.2.6.1 Bridge Status

You can view the STP bridge status, including MSTI, bridge ID, root, topology flag, and topology change last.

Select **Advanced > Monitor > Spanning Tree > Bridge Status**. The STP Bridge interface is displayed. See Figure 4-108.

Figure 4-108 STP bridge

STP Bridges							Auto-refresh <input type="checkbox"/>	Refresh
MSTI	Bridge ID	Root			Topology Flag	Topology Change Last		
		Root ID	Port	Cost				
CIST	32768.90-02-A9-DA-6D-30	32768.90-02-A9-DA-6D-30	-	0	Steady	-		

4.2.6.2 Port Status

You can view the STP port status.

Select **Advanced > Monitor > Spanning Tree > Port Status**. The STP Port Status interface is displayed. See Figure 4-109.

Figure 4-109 STP port status

STP Port Status				Auto-refresh <input type="checkbox"/>	Refresh
Port	CIST Role	CIST State	Uptime		
1	Disabled	Discarding	-		
2	DesignatedPort	Forwarding	0d 02:16:34		
3	Disabled	Discarding	-		
4	Disabled	Discarding	-		
5	Disabled	Discarding	-		
6	Disabled	Discarding	-		
7	Disabled	Discarding	-		
8	Disabled	Discarding	-		
9	Disabled	Discarding	-		
10	Disabled	Discarding	-		
11	Disabled	Discarding	-		
12	Disabled	Discarding	-		
13	Disabled	Discarding	-		
14	Disabled	Discarding	-		
15	Disabled	Discarding	-		
16	Disabled	Discarding	-		
17	Disabled	Discarding	-		
18	Disabled	Discarding	-		
19	Disabled	Discarding	-		
20	Disabled	Discarding	-		
21	Disabled	Discarding	-		
22	Disabled	Discarding	-		
23	Disabled	Discarding	-		
24	Disabled	Discarding	-		
25	Disabled	Discarding	-		
26	Disabled	Discarding	-		

4.2.6.3 Port Statistics

You can view the STP port statistic.

Select **Advanced > Monitor > Spanning Tree > Port Statistics**. The STP Statistics interface is displayed. See Figure 4-110.

Figure 4-110 STP statistics

STP Statistics											Auto-refresh <input type="checkbox"/>	Refresh	Clear
Port	Transmitted				Received				Discarded				
	MSTP	RSTP	STP	TCN	MSTP	RSTP	STP	TCN	Unknown	Illegal			
7	862	0	0	0	0	0	0	0	0	0			

4.2.7 IGMP Snooping

4.2.7.1 Status

You can view the IGMP Snooping status.

Select **Advanced > Monitor > IGMP Snooping > Status**. The IGMP Snooping Status interface is displayed. See Figure 4-111.

Figure 4-111 IGMP Snooping status

IGMP Snooping Status											Auto-refresh <input type="checkbox"/>	Refresh	Clear
Statistics													
VLAN ID	Querier Version	Host Version	Querier Status	Queries Transmitted	Queries Received	V1 Reports Received	V2 Reports Received	V3 Reports Received	V2 Leaves Received				
Router Port													
Port	Status												
1	-												
2	-												
3	-												
4	-												
5	-												
6	-												
7	-												
8	-												
9	-												
10	-												
11	-												
12	-												
13	-												
14	-												
15	-												
16	-												
17	-												
18	-												
19	-												
20	-												
21	-												
22	-												
23	-												
24	-												
25	-												
26	-												

4.2.7.2 Groups Information

You can view the IGMP Snooping group information.

Select **Advanced > Monitor > IGMP Snooping > Groups Information**. The IGMP Snooping Group Information interface is displayed. See Figure 4-112.

Figure 4-112 IGMP Snooping group information

IGMP Snooping Group Information Auto-refresh Refresh << >>

Start from VLAN 1 and group address 224.0.0.0 with 20 entries per page

VLAN ID	Port Members
	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26

No more entries

4.2.7.3 IPv4 SFM Information

You can view the IGMP SFM information.

Select **Advanced > Monitor > IGMP Snooping > IPv4 SFM Information**. The IPv4 SFM Information interface is displayed. See Figure 4-113.

Figure 4-113 IPv4 SFM Information

IGMP SFM Information Auto-refresh Refresh << >>

Start from VLAN 1 and Group 224.0.0.0 with 20 entries per page

VLAN ID	Group	Port	Mode	Source Address	Type	Hardware Filter/Switch
No more entries						

4.2.8 LLDP

4.2.8.1 Neighbors

You can view the LLDP neighbor information.

Select **Advanced > Monitor > LLDP > Neighbors**. The LLDP Neighbor Information interface is displayed. See Figure 4-114.

Figure 4-114 LLDP neighbor information

LLDP Neighbor Information Auto-refresh Refresh

LLDP Remote Device Summary						
Local Interface	Chassis ID	Port ID	Port Description	System Name	System Capabilities	Management Address
No neighbor information found						

4.2.8.2 LLDP-MED Neighbors

You can view the LLDP-MED neighbor information.

Select **Advanced > Monitor > LLDP > LLDP-MED Neighbors**. The LLDP-MED Neighbor Information interface is displayed. See Figure 4-115.

Figure 4-115 LLDP-MED neighbor information

LLDP-MED Neighbor Information Auto-refresh Refresh

Local Interface
No LLDP-MED neighbor information found

4.2.8.3 PoE

You can view the PoE LLDP neighbor information.

Select **Advanced > Monitor > LLDP > PoE**. The LLDP Neighbor Power Over Ethernet Information interface is displayed. See Figure 4-116.

Figure 4-116 PoE LLDP neighbor information.

LLDP Neighbor Power Over Ethernet Information				
Local Interface	Power Type	Power Source	Power Priority	Maximum Power
No PoE neighbor information found				

4.2.8.4 EEE

You can view the LLDP neighbors EEE information.

Select **Advanced > Monitor > LLDP > EEE**. The LLDP Neighbors EEE Information interface is displayed. See Figure 4-117.

Figure 4-117 LLDP neighbors EEE information

LLDP Neighbors EEE Information									
Local Interface	Tx Tw	Rx Tw	Fallback Receive Tw	Echo Tx Tw	Echo Rx Tw	Resolved Tx Tw	Resolved Rx Tw	EEE in Sync	
No LLDP EEE information found									

4.2.8.5 Port Statistics

You can view the LLDP port statistics information.

Select **Advanced > Monitor > LLDP > Port Statistics**. The LLDP Global Counters interface is displayed. See Figure 4-118.

Figure 4-118 LLDP global counters

LLDP Global Counters		Auto-refresh	Refresh	Clear					
Global Counters									
Clear global counters	<input checked="" type="checkbox"/>								
Neighbor entries were last changed	2022-02-01T03:26:56+00:00 (8534 secs. ago)								
Total Neighbors Entries Added	0								
Total Neighbors Entries Deleted	0								
Total Neighbors Entries Dropped	0								
Total Neighbors Entries Aged Out	0								
LLDP Statistics Local Counters									
Local Interface	Tx Frames	Rx Frames	Rx Errors	Frames Discarded	TLVs Discarded	TLVs Unrecognized	Org. Discarded	Age-Outs	Clear
GigabitEthernet 1/1	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/2	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/3	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/4	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/5	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/6	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/7	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/8	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/9	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/10	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/11	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/12	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/13	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/14	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/15	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/16	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/17	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/18	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/19	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/20	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/21	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/22	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/23	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/24	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/25	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>
GigabitEthernet 1/26	0	0	0	0	0	0	0	0	<input checked="" type="checkbox"/>

4.2.9 PoE

You can view the port PoE status.

Select **Advanced > Monitor > PoE**. The Power Over Ethernet Status interface is displayed. See Figure 4-119.

Figure 4-119 PoE status

Power Over Ethernet Status			
Local Port	PD Class	Power Used	Port Status
1	-	0 [W]	No PD detected
2	-	0 [W]	No PD detected
3	-	0 [W]	No PD detected
4	-	0 [W]	No PD detected
5	-	0 [W]	No PD detected
6	-	0 [W]	No PD detected
7	-	0 [W]	No PD detected
8	-	0 [W]	No PD detected
9	-	0 [W]	No PD detected
10	-	0 [W]	No PD detected
11	-	0 [W]	No PD detected
12	-	0 [W]	No PD detected
13	-	0 [W]	No PD detected
14	-	0 [W]	No PD detected
15	-	0 [W]	No PD detected
16	-	0 [W]	No PD detected
17	-	0 [W]	No PD detected
18	-	0 [W]	No PD detected
19	-	0 [W]	No PD detected
20	-	0 [W]	No PD detected
21	-	0 [W]	No PD detected
22	-	0 [W]	No PD detected
23	-	0 [W]	No PD detected
24	-	0 [W]	No PD detected
Total		0 [W]	

4.2.10 MAC Table

You can view the MAC table of the switch.

Select **Advanced > Monitor > MAC Table**. The MAC Address Table interface is displayed. See Figure 4-120.

Figure 4-120 MAC address table

MAC Address Table			Port Members																										
Type	VLAN	MAC Address	CPU	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26
Dynamic	1	00-00-23-34-45-A0		✓																									
Dynamic	1	00-02-A9-7F-E1-E0		✓																									
Dynamic	1	00-03-31-35-65-9D		✓																									
Dynamic	1	00-0E-AE-A2-CA-A8		✓																									
Dynamic	1	00-0E-AE-A4-12-6C		✓																									
Dynamic	1	00-0E-AE-A4-4C-F1		✓																									
Dynamic	1	00-0E-AE-A4-59-ED		✓																									
Dynamic	1	00-0E-AE-A4-80-61		✓																									
Dynamic	1	00-11-22-33-44-55		✓																									
Dynamic	1	00-12-34-56-78-90		✓																									
Dynamic	1	00-12-3B-5C-78-9A		✓																									
Dynamic	1	00-1E-C9-CF-55-FC		✓																									
Dynamic	1	00-1F-55-11-07-48		✓																									
Dynamic	1	00-1F-55-17-C0-7F		✓																									
Static	1	01-00-5E-00-00-01	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Dynamic	1	02-00-C1-E7-8B-6D		✓																									
Dynamic	1	08-57-00-D6-D1-32		✓																									
Dynamic	1	08-57-00-E5-13-0A		✓																									
Dynamic	1	08-57-00-E5-73-6E		✓																									
Dynamic	1	14-A1-62-B6-54-71		✓																									

4.2.11 VLANs

4.2.11.1 Membership

You can view the VLAN the port belongs to.

Select **Advanced > Monitor > VLANs > Membership**. The VLAN Membership Status interface is displayed. See Figure 4-121.

Figure 4-121 VLAN membership status

VLAN Membership Status		Combined	Auto-refresh	Refresh																																																						
Start from VLAN	1	with	20	entries per page																																																						
<table border="1"> <thead> <tr> <th>VLAN ID</th> <th>1</th> <th>2</th> <th>3</th> <th>4</th> <th>5</th> <th>6</th> <th>7</th> <th>8</th> <th>9</th> <th>10</th> <th>11</th> <th>12</th> <th>13</th> <th>14</th> <th>15</th> <th>16</th> <th>17</th> <th>18</th> <th>19</th> <th>20</th> <th>21</th> <th>22</th> <th>23</th> <th>24</th> <th>25</th> <th>26</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> </tr> </tbody> </table>					VLAN ID	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	1	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
VLAN ID	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26																																
1	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓																																

4.2.11.2 Ports

You can view the VLAN port status, including port type, ingress filtering, frame type, and so on.

Select **Advanced > Monitor > VLANs > Ports**. The VLAN Port Status interface is displayed. See Figure 4-122.

Figure 4-122 VLAN port status

VLAN Port Status								Combined	Auto-refresh	Refresh
Port	Port Type	Ingress Filtering	Frame Type	Port VLAN ID	Tx Tag	Untagged VLAN ID	Conflicts			
1	C-Port	✓	All	1	Untag All		No			
2	C-Port	✓	All	1	Untag All		No			
3	C-Port	✓	All	1	Untag All		No			
4	C-Port	✓	All	1	Untag All		No			
5	C-Port	✓	All	1	Untag All		No			
6	C-Port	✓	All	1	Untag All		No			
7	C-Port	✓	All	1	Untag All		No			
8	C-Port	✓	All	1	Untag All		No			
9	C-Port	✓	All	1	Untag All		No			
10	C-Port	✓	All	1	Untag All		No			
11	C-Port	✓	All	1	Untag All		No			
12	C-Port	✓	All	1	Untag All		No			
13	C-Port	✓	All	1	Untag All		No			
14	C-Port	✓	All	1	Untag All		No			
15	C-Port	✓	All	1	Untag All		No			
16	C-Port	✓	All	1	Untag All		No			
17	C-Port	✓	All	1	Untag All		No			
18	C-Port	✓	All	1	Untag All		No			
19	C-Port	✓	All	1	Untag All		No			
20	C-Port	✓	All	1	Untag All		No			
21	C-Port	✓	All	1	Untag All		No			
22	C-Port	✓	All	1	Untag All		No			
23	C-Port	✓	All	1	Untag All		No			
24	C-Port	✓	All	1	Untag All		No			
25	C-Port	✓	All	1	Untag All		No			
26	C-Port	✓	All	1	Untag All		No			

4.3 Diagnostics

With Ping protocol, you can check whether the device with a specified IP address can be accessed, or you can check whether there is a network connection failure.

4.3.1 Ping

Step 1 Select **Advanced > Diagnostics > Ping**.

The ICMP Ping interface is displayed. See Figure 4-123.

Figure 4-123 ICMP Ping

ICMP Ping	
IP Address	0.0.0.0
Ping Length	56
Ping Count	5
Ping Interval	1
<input type="button" value="Start"/>	

Step 2 Input the IP address, and click **Start**.

4.3.2 Ping6

Step 1 Select **Advanced > Diagnostics > Ping6**.

The ICMPv6 Ping interface is displayed. See Figure 4-124.

Figure 4-124 ICMPv6 Ping

ICMPv6 Ping	
IP Address	0:0:0:0:0:0:0:0
Ping Length	56
Ping Count	5
Ping Interval	1
Egress Interface	
<input type="button" value="Start"/>	

Step 2 Input the IPv6 address, and click **Start**.

4.4 Maintenance

4.4.1 Restart Device

You can reboot the device.

Step 1 Select **Advanced > Maintenance > Restart Device**.

The Restart Device interface is displayed. See Figure 4-125.

Figure 4-125 Restart device

Restart Device	
<input type="button" value="Yes"/>	

Step 2 Click **Yes**, and the device reboots.


4.4.2 Factory Defaults

You can restore all the switch configuration to the factory defaults, except the VLAN IP address of the switch.

Step 1 Select **Advanced > Maintenance > Factory Defaults**.

The Factory Defaults interface is displayed. See Figure 4-126.

Figure 4-126 Factory defaults



Step 2 Click **Yes**, and all the configuration except VLAN IP address of the switch is restored to factory defaults.

4.4.3 Software


4.4.3.1 Upload

You can upgrade the software of the switch.

Step 1 Select **Advanced > Maintenance > Software > Upload**.

The Software Upload interface is displayed. See Figure 4-127.

Figure 4-127 Software upload



Step 2 Click **Browse**, and select the file in .mif format to upload.

Step 3 Click **Upload**.

Please wait for software upgrade, and the device reboots after upgrade finished. Re login the switch, and all the configuration will not change.


4.4.3.2 Image Select

You can activate the alternate image.

Step 1 Select **Advanced > Maintenance > Software > Image Select**.

The Software Image Selection interface is displayed. See Figure 4-128.

Figure 4-128 Software image selection



Step 2 Click **Activate Alternate Image**.

The device reboots. After reboot, the Alternate Image changes to be the Active Image, and the Active Image changes to be the Alternate Image.

4.4.4 Configuration


4.4.4.1 Save startup-config

You can save all the current configuration of the switch.

Step 1 Select **Advanced > Maintenance > Configuration > Save startup-config**.

The Save Running Configuration to startup-config interface is displayed. See Figure 4-129.

Figure 4-129 Save running configuration to startup-config

**Step 2** Click **Save Configuration**.


4.4.4.2 Download

You can download the configuration file.

Step 1 Select **Advanced > Maintenance > Configuration > Download**.

The Download Configuration interface is displayed. See Figure 4-130.

Figure 4-130 Download configuration

**Step 2** Select the configuration file to download. There are three types:

- running-config: currently running configuration file. It is valid at the moment and will be lost if power off.
- default-config: the default configuration.
- startup-config: the configuration running when the switch starts up. It can be saved when power off.

Step 3 Click **Download Configuration**.

4.4.4.3 Upload

You can upload the configuration file.

Step 1 Select **Advanced > Maintenance > Configuration > Upload**.

The Upload Configuration interface is displayed. See Figure 4-131 .

Figure 4-131 Upload configuration

File Name	Parameters
<input type="radio"/> running-config	<input checked="" type="radio"/> Replace <input type="radio"/> Merge
<input type="radio"/> startup-config	
<input type="radio"/> Create new file	

Step 2 Click **Browse**, and select the configuration file to upload.

Step 3 Select the File Name and the Parameters in Destination File.

- running-config
- startup-config
- Create new file

Step 4 Click **Upload Configuration**.

4.4.4.4 Activate

You can activate the configuration file.

Step 1 Select **Advanced > Maintenance > Configuration > Activate**.

The Activate Configuration interface is displayed. See Figure 4-132.

Figure 4-132 Activate configuration

Select configuration file to activate. The previous configuration will be completely replaced, potentially leading to loss of management connectivity.

Please note: The activated configuration file will <u>not</u> be saved to startup-config automatically.

File Name
<input type="radio"/> default-config
<input type="radio"/> startup-config

Step 2 Select the **File Name**, default-config and startup-config are selectable.

Step 3 Click **Activate Configuration**.

4.4.4.5 Delete

You can delete the configuration file.

Step 1 Select **Advanced > Maintenance > Configuration > Delete**.

The Delete Configuration File interface is displayed. See Figure 4-133.

Figure 4-133 Delete configuration file

File Name
<input type="radio"/> startup-config

Step 2 Select the File Name. Only **startup-config** can be selected currently.

Step 3 Click **Delete Configuration File**.